

Parameters:

<Region> ALL | DIALog
*RST: ALL

Example: See [Example "Store a hard copy of the display" on page 299](#).

Manual operation: See ["File Options"](#) on page 125

6.9 KBOard Subsystem

The KBOard system contains the commands to set the external keyboard.

:KBOard:LANGuage.....	304
:KBOard:LAYout.....	304

:KBOard:LANGuage <Language>

This command selects the keyboard language. The assignment of some keys depends on the selected language.

Parameters:

<Language> US | DE
*RST: US

Example: KBO:LANG US
selects keyboard language American English.

Usage: SCPI confirmed

Manual operation: See ["Layout \(USB Keyboard Settings\)" on page 108](#)

:KBOard:LAYout <Layout>

Selects the keyboard language. The assignment of some keys depends on the selected language.

Parameters:

<Layout> CHINese | DANish | DUTCh | DUTBe | ENGLish | ENGUK |
FINNish | FRENch | FREBe | FRECa | GERMan | ITALian |
JAPanese | KOREan | NORwegian | PORTuguese | RUSSian |
SPANish | SWEDish | ENGUS
*RST: n.a. (factory preset: ENGLish)

Example: KBO:LAY US
Activates American English keyboard layout.

Manual operation: See ["Layout \(USB Keyboard Settings\)" on page 108](#)