



Servo requires 6V and 2-5A.
Use a benchtop power supply or equivalent. (PS)

Microcontroller gets its power via USB cable
to the computer.

U1
Teensy4.0

