

Controller controls

Input	Function	Logic
Left Stick Y	Left Motor Throttle	Direct control of Left Wheels.
Right Stick Y	Right Motor Throttle	Direct control of Right Wheels.
Difference (L-R)	Press Wheel Angle	Calculates steering angle based on stick difference.
L1 Button	U-Turn Mode	Sets Press Wheel to steering angle, drives right motor and locks left wheel for a left turn
R1 Button	U-Turn Mode	Sets Press Wheel to steering angle, drives left motor and locks right wheel for a left turn
Triangle (Green)	E-Stop / Brake	Immediately cuts power to all motors.
Circle	Planting (Pulse)	Runs metering plate for one cycle (drop seed).
Cross (Blue)	Cruise Control	Locks both motors to Fixed Forward Speed (e.g., planting speed).