Skoda Octavia 1.8turbo AUQ -2003

30
15
50

X28-I F28 15A
X28-I F43 10A
X28-I F32 10A
X28-I F34 10A
X28-III F5 50A

bl rt
bl ge
rt vi
ge sw
bl
rt
sw
bl rt
br ge

A

17 30 | 19 86 | 22 50 | 24 TK
K20
87 23 | 31 21 | 85 16 | 18
z

A198

ge

bl ge
bl ge
rt vi
rt vi
rt vi
rt vi
ge sw
ge sw
ge sw
vi ws
ge gn
gr ws
ws gr
ws
ws vi

Y104
Y3 I
Y3 II
Y3 III
Y3 IV
Y153
Y68
Y81
B138
A197
B169
M89
A177
S231

ws bl
gr rt
br bl
gr bl
gn ws
bl gn
ws gr
bl ws

vi rt
vi
vi gn
vi rt
vi bl
gr gn
gn br
gn ws
vi ws
ge gn
ws bl
gr rt
br ws
gr bl
gn ws
bl gn
ws gr
bl ws
bl gr
vi ws
vi sw
ws
ws vi
ws gr

64 | 96 | 89 | 97 | 88 | 105 | 104 | 115 | 65 | 73 | 35 | 36 | 34 | 33 | 72 | 22 | 91 | 92 | 84 | 83 | 118 | 117 | 49 | 50

A35

5 | 52 | 71 | 70 | 51 | 63 | 68 | 69 | 27 | 53 | 29 | 9 | 86 | 98 | 101 | 106 | 99 | 108 | 107 | 82 | 90

bl rt
bl ge
ws
gr rt
sw
gn
gr ws
gr ge
gr ws
gr rt
gn
rt vi
sw
br ge
vi ge
vi gn
vi gr
gr
bl
br bl
gn
ge
sw
ws
br

M12
B72-II
B30
Y111
B132
B105
B69-I
B69-II
B54

vi gn
br bl
vi gn
vi gr
br bl
sw
ge
sw
sw

4 | 6 | 2 | 1
B72-I
3 | 5
2 | 3
ws | gr
B72-II
3 | 4
B30
2 | 5
Y111
2
1
2 | 1 | 3
B132
3 | 4 | 1
B105
1 | 2
B69-I
1 | 2
B69-II
3 | 2 | 1
B54

bl rt
br

bl rt
ws
gr ws
bl ge
sw
bl ge
gr rt
sw

B

C

31
EP2
Lhd=EP14
37704

A16	ABS control module
A63	AC control module
S292	AC/heater function control panel
B138	Accelerator pedal position (APP) sensor
G1	Alternator
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
A216	Brake servo control module
Y81	Camshaft position (CMP) actuator
B132	Camshaft position (CMP) sensor
S258	Clutch pedal position (CPP) switch
CAN-H	Controller area network (data bus) high
CAN-L	Controller area network (data bus) low
B54	Crankshaft position (CKP) sensor
S79	Cruise control master switch
S80	Cruise control selector switch
X1	Data link connector (DLC)
A130	Diagnostic module
K46	Engine control (EC) relay
A35	Engine control module (ECM)
A95	Engine coolant blower motor control module
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
Y104	Evaporative emission (EVAP) canister purge valve
M12	Fuel pump (FP)
K20	Fuel pump (FP) relay
F	Fuse
X28-III	Fuse box/relay plate, engine bay 1
X28-IV	Fuse box/relay plate, engine bay 2
X28-I	Fuse box/relay plate, fascia 1
B72-I	Heated oxygen sensor (HO2S) 1
B72-II	Heated oxygen sensor (HO2S) 2
A52	Ignition amplifier
T1	Ignition coil
15	Ignition switch - ignition ON
50	Ignition switch - start signal
A162	Immobilizer control module
Y3	Injector
A5	Instrument panel
A75	Instrumentation control module
B25	Intake air temperature (IAT) sensor
B69-I	Knock sensor (KS) 1
B69-II	Knock sensor (KS) 2
B30	Mass air flow (MAF) sensor
S231	Power steering pressure (PSP) switch
M73	Secondary air injection (AIR) pump
K152	Secondary air injection (AIR) pump relay
Y111	Secondary air injection (AIR) solenoid
W3	Spare cable
A198	Supplementary restraint system (SRS) control module
P7	Tachometer

H101	Throttle control system warning lamp
A177	Throttle control unit
M89	Throttle motor
B169	Throttle motor position sensor
A57	Transmission control module (TCM)
B105	Turbocharger (TC) boost pressure sensor
Y153	Turbocharger (TC) intake divert valve
Y68	Turbocharger (TC) wastegate regulating valve
B33	Vehicle speed sensor (VSS)
P9	Vehicle speedometer