A16 ABS control module B161 A Crefigerant pressure sensor B138 Accelerator pedal position (APP) sensor G1 Alternator 30 Battery - 30 Battery - 31 Battery - 31 Battery - 31 Battery - 32 Carnshaft position (BPP) switch W181 Carnshaft position (CMP) actuator B132 Carnshaft position (CMP) sensor S258 Cluch pedal position (CPP) switch CAN-L Controller area network (data bus) high CAN-L Controller area network (data bus) high CAN-L Controller area network (data bus) high CAN-L Controller area network (data bus) low B44 Crarkshaft position (CKP) sensor S288 Cruise control throttle switch X1 Data link connector (DLC) A207 Electronic stability program (ESP) control module A35 Engine control module (ECM) M6 Engine coolant blower motor relay K12-L Engine coolant blower motor relay 1 K12-LI Engine coolant blower motor relay 2 R46 Engine coolant blower motor relay 1 K12-LI Engine coolant blower motor relay 1 LI Evaporative emission (EVAP) canister purge valve M12 Fuel pump F F Fuse Fuse box/relay plate - engine bay 1 X28-LII Fuse box/relay plate - engine bay 2 X28-LI Fuse box/relay plate - engine bay 2 X28-LI Fuse box/relay plate - fascia 1 Hadrough expension (HOZS) 2 Hadroug				
B138 Accelerator pedal position (APP) sensor G1 Alternator 30 Battery + S13 Brake pedal position (BPP) switch Y81 Camshaft position (CMP) actuator H312 Camshaft position (CMP) sensor S258 Clutch pedal position (CMP) sensor CAN-H Controller area network (data bus) high CAN-L Controller area network (data bus) low B54 Crankshaft position (CKP) sensor S298 Cruise control throttle switch X1 Data link connector (DLC) A207 Electronic stability program (ESP) control module A35 Engine coolant blower motor K12 Engine coolant blower motor relay K14-L Engine coolant blower motor relay 1 K12-LII Engine coolant blower motor relay 2 K12-LII Engine coolant blower motor relay 2 K14-LII Engine coolant blower motor relay 2 K14-LII Engine coolant blower motor relay 2 K16-LII Engine coolant blower motor relay 2 K16-LII Engine coolant blower motor relay 2 K17-LII Engine coolant blower motor relay 2 K18-LII Engine coolant blower motor relay 2 K19-LII Engine coolant blower motor relay 2 K19-LII Engine coolant blower motor relay 2 K19-LII Engine coolant blower motor relay 1 K19-LII Engine coolant blower motor relay 2 K19-LII Engine coolant blower motor relay 2 K19-LII Engine coolant blower motor relay 1 K19-LII Engine coolant blower motor relay 2 K19-LII Engine coolant blower motor relay 1 K19-LII Engine coolant blower motor relay 2 K19-LII Engine coolant blower motor relay 1 K19-LII Engine coolant blower motor relay 2 K19-LII Engine coolant temperature (ECT) sensor K19-LII Engine coolant	A16	ABS control module		
G1 Alternator 31 Battery + 31 Battery + 31 Brake pedal position (BPP) switch W181 Camshaft position (CMP) actuator B132 Camshaft position (CMP) sensor S258 Clutch pedal position (CMP) sensor S258 Clutch pedal position (CMP) sensor W192 Camshaft position (CMP) sensor S258 Clutch pedal position (CMP) sensor W193 Cannot (CMP) sensor W194 Cannot (CMP) sensor W195 Cannot (C	B161			
31 Battery - 313 Battery - 313 Brake pedal position (BPP) switch Y81 Camshaft position (CMP) actuator B132 Camshaft position (CMP) sensor S258 Clutch pedal position (CPP) switch CAN-H Controller area network (data bus) high CAN-L Controller area network (B138	Accelerator pedal position (APP) sensor		
Battery + S13 Brake pedal position (CMP) switch Y14 Camshaft position (CMP) setuator B132 Camshaft position (CMP) sensor S258 Clutch pedal position (CMP) sensor S258 Clutch pedal position (CMP) sensor CAN-H Controller area entwork (data bus) high CAN-L Controller area entwork (data bus) high CAN-L Controller area network ALI Controller area network CAN-L Controller area network CAN-L Controller area network ALI Controller area network CAN-L Controller area network CA	G1	Alternator		
S13 Brake pedal position (BPP) switch Y81 Camshaft position (CMP) actuator B132 Camshaft position (CMP) sensor S258 Clutch pedal position (CPP) switch CAN-H Controller area network (data bus) high CAN-L Controller area network (data bus) low B54 Crankshaft position (CKP) sensor S298 Cruise control throttle switch X1 Data link connector (DLC) A207 Electronic stability program (ESP) control module A35 Engine control module (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay K12-I Engine coolant blower motor relay K12-I Engine coolant blower motor relay 2 R48 Engine coolant blower motor relay 2 R49 Engine coolant temperature (ECT) sensor H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M10 Evaporative emission (EVAP) canister purge valve X28-II Fuse box/relay plate - engine bay 1 X28-III Fuse box/relay plate - engine bay 2 X28-II Fuse box/relay plate - engine bay 2 X28-II Fuse box/relay plate - engine bay 1 Ignition switch Ignition switch Ignition switch Ignition switch - ignition ON N7 Injector N5 Instrument panel N6 Instrument position sensor WAN Vehicle area network	31	Battery -		
Y81 Camshaft position (CMP) sensor S258 SLitch pedal position (CPP) switch CAN-H Controller area network (data bus) high CAN-L Controller area network (data bus) low B54 Crankshaft position (CKP) sensor S298 Cruise control throttle switch X1 Data link connector (DLC) A207 Electronic stability program (ESP) control module A35 Engine control module (ECM) M6 Engine coolant blower motor K12-L Engine coolant blower motor relay K12-L Engine coolant blower motor relay 1 K12-L Engine coolant blower motor relay 2 R46 Engine coolant blower motor resistor B24 Engine maifunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-III Fuse box/relay plate - engine bay 1 X28-III Fuse box/relay plate - fascia 1 B72-I	30	Battery +		
B132 Camshaft position (CMP) sensor \$258 Clutch pedal position (CPP) switch CAN-H Controller area network (data bus) high CAN-L Controller area network (data bus) low B54 Crankshaft position (CKP) sensor \$298 Cruise control throttle switch X1 Data link connector (DLC) A207 Electronic stability program (ESP) control module A35 Engine corlor Imodule (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay K12-L Engine coolant blower motor relay K12-L Engine coolant blower motor relay 2 R46 Engine coolant blower motor relay 2 R46 Engine coolant thower motor relay 2 R46 Engine coolant thower motor relay 2 R46 Engine coolant indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate - engine bay 1 X28-III Fuse box/relay plate - engine bay 2 X28-II Fuse box/relay plate - fascia 1 B72-II Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y39 Idle air control (IAC) valve T1 Ignition switch 15 Ignition switch ignition ON Y3 Injector A5 Instrument panel A75 Instrument panel A75 Instrument panel A76 Instrument ation control module B26 Intake air temperature (IAT) sensor M89 Manifold absolute pressure (MAP) sensor A11-II Multifunction control module 2 P7 Tachometer M89 Throtte motor position sensor VAN Vehicle area network	S13	Brake pedal position (BPP) switch		
S258 Clutch pedal position (CPP) switch CAN-H. Controller area network (data bus) low B54 Crankshaft position (CKP) sensor S298 Cruise control throttle switch A1 Data link connector (DLC) A207 Electronic stability program (ESP) control module A35 Engine control module (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay K12-I Engine coolant blower motor relay Engine coolant blower motor relay K12-I Engine coolant blower motor relay K12-I Engine coolant blower motor relay Engine maifunction indicator lamp (MIL) Fuse program and the motor lamp (MIL) Fuse box/relay plate - engine bay 1 X28-II Fuse box/relay plate - engine bay 1 X28-II Fuse box/relay plate - engine bay 2 X28-I Fuse box/relay plate - engine bay 2 X28-I Fuse box/relay plate - fascia 1 B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition switch I5 Ignition switch I6 Ignition switch I6 Ignition switch I6 Ignition switch I7 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B88 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-II Multifunction control module 2 P7 Tachometer M89 Throttle motor position sensor VAN Vehicle area network	Y81	Camshaft position (CMP) actuator		
CAN-H CAN-L Controller area network (data bus) low CAN-L CAN-L Controller area network (data bus) low S5298 Cruise control throttle switch X1 Data link connector (DLC) A207 Electronic stability program (ESP) control module A35 Engine control module (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay K12-I Engine coolant blower motor relay K12-I Engine coolant blower motor relay K12-I Engine coolant blower motor relay 2 R46 Engine coolant blower motor relay 2 R46 Engine coolant blower motor resistor B24 Engine coolant blower motor resistor B24 Engine coolant indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F F Use X28-II Fuse box/relay plate - engine bay 1 X28-III Fuse box/relay plate - engine bay 2 X28-II Fuse box/relay plate - engine bay 2 X28-II Fuse box/relay plate - engine bay 2 X28-II Fuse box/relay plate - fascia 1 B72-I Heated oxygen sensor (HO2S) 1 B72-II B72-II Heated oxygen sensor (HO2S) 2 Y99 Ide air control (IAC) valve T1 Ignition coil Instrument panel A75 Instrument panel Instrumentation control module Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor M89 Throttle motor position sensor VAN Vehicle area network	B132	Camshaft position (CMP) sensor		
CAN-L Controller area network (data bus) low B54 Crankshaft position (CKP) sensor S298 Cruise control throttle switch X1 Data link connector (DLC) A207 Electronic stability program (ESP) control module A35 Engine control module (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay K12-I Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 R46 Engine coolant blower motor resistor B24 Engine coolant blower motor resistor B24 Engine coolant blower motor resistor B25 Engine maifunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F F Fuse X28-II Fuse box/relay plate - engine bay 1 X28-III Fuse box/relay plate - engine bay 2 X28-I Fuse box/relay plate - fascia 1 B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve I1 Ignition coil S1 Ignition switch - ignition ON Injector A5 Instrument panel A75 Instrument panel A75 Instrument panel A76 Instrument panel A77 Instrumentation control module Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-II Multifunction control module 2 P7 Tachometer M89 Throtte motor position sensor VAN Vehicle area network	S258	Clutch pedal position (CPP) switch		
B54 Crankshaft position (CKP) sensor S298 Cruise control throttle switch X1 Data link connector (DLC) A207 Electronic stability program (ESP) control module A35 Engine control module (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay K12-II Engine coolant blower motor relay K12-II Engine coolant blower motor relay 2 K12-II Engine coolant blower motor relay 2 ER46 Engine coolant blower motor relay 2 ER46 Engine coolant thower motor relay 2 ER46 Engine coolant temperature (ECT) sensor B24 Engine coolant temperature (ECT) sensor B44 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve F12 Fuse pump F F Fuse X28-II Fuse box/relay plate - engine bay 1 X28-III Fuse box/relay plate - engine bay 2 X28-II Fuse box/relay plate - engine bay 2 X28-II Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 If ela air control (IAC) valve I1 Ignition switch - Ignition coil I1 Ignition switch - Ignition ON I1 Injector A5 Instrumentation control module Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor M89 Throttle motor B169 Throttle motor B170 Tachometer M89 Throttle motor position sensor VAN Vehicle area network	CAN-H	Controller area network (data bus) high		
B54 Crankshaft position (CKP) sensor S298 Cruise control throttle switch X1 Data link connector (DLC) A207 Electronic stability program (ESP) control module A35 Engine control module (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay K12-I Engine coolant blower motor relay K12-I Engine coolant blower motor relay 2 K12-I Engine coolant blower motor relay 2 Engine coolant blower motor relay 2 Engine coolant thower motor relay 2 Engine coolant temperature (ECT) sensor B24 Engine coolant temperature (ECT) sensor H63 Engine maffunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve Fuse pump F Fuse X28-II Fuse box/relay plate - engine bay 1 X28-II Fuse box/relay plate - engine bay 2 X28-II Fuse box/relay plate - fascia 1 B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch - ignition ON Injector A5 Instrumentation control module Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor M89 Trrottle motor B169 Trrottle motor B169 Trrottle motor position sensor VAN Vehicle area network	CAN-L	Controller area network (data bus) low		
S298 Cruise control throttle switch X1 Data link connector (DLC) A207 Electronic stability program (ESP) control module A35 Engine control module (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay K12-II Engine coolant blower motor relay K12-II Engine coolant blower motor relay 2 R46 Engine coolant blower motor resistor B24 Engine coolant blower motor resistor B24 Engine coolant temperature (ECT) sensor B25 Engine anafluction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuel X28-II Fuse box/relay plate - engine bay 1 X28-III Fuse box/relay plate - engine bay 2 X28-II Fuse box/relay plate - fascia 1 B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch Is Ignition switch Is Ignition switch Instrument panel India dasolute pressure (MAP) sensor M30 Manifold absolute pressure (MAP) sensor M41-I Multifunction control module 1 M41-II Multifunction control module 2 P7 Tachometer M89 Throttle motor position sensor VAN Vehicle area network	B54	·		
X1 Data link connector (DLC) A207 Electronic stability program (ESP) control module A35 Engine control module (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay K12-I Engine coolant blower motor relay K12-I Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 Engine coolant blower motor relay 2 Engine coolant blower motor resistor B24 Engine coolant blower motor resistor B25 Engine coolant blower motor resistor B26 Engine coolant temperature (ECT) sensor B27 Engine coolant temperature (ECT) sensor B28 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve F1 Fuse X28-II Fuse box/relay plate - engine bay 1 X28-III Fuse box/relay plate - engine bay 2 X28-II Fuse box/relay plate - engine bay 2 X28-II Fuse box/relay plate - fascia 1 B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch 15 Ignition switch 15 Ignition switch 16 Instrument panel A75 Instrument panel A76 Mock sensor (KS) B88 Manifold absolute pressure (MAP) sensor B89 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network	S298			
A207 Electronic stability program (ESP) control module A35 Engine control module (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay K12-II Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 R46 Engine coolant blower motor relay 2 R46 Engine coolant blower motor resistor B24 Engine coolant temperature (ECT) sensor H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate - engine bay 1 X28-III Fuse box/relay plate - engine bay 2 X28-II Fuse box/relay plate - engine bay 2 X28-II Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve I1 Ignition coil S1 Ignition switch I5 Ignition switch I5 Ignition switch - ignition ON Y3 Injector A5 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-II Multifunction control module 1 A11-III Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network				
A35 Engine control module (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay K12-II Engine coolant blower motor relay 1 K12-III Engine coolant blower motor relay 2 R46 Engine coolant blower motor relay 2 R46 Engine coolant blower motor relay 2 R46 Engine coolant temperature (ECT) sensor H43 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-III Fuse box/relay plate - engine bay 1 X28-IIII Fuse box/relay plate - engine bay 2 X28-II Fuse box/relay plate - engine bay 2 X28-II Fuse box/relay plate - fascia 1 B72-I Heated oxygen sensor (HO2S) 1 B72-III Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B40 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 2 P7 Tachometer M89 Throttle motor position sensor VAN Vehicle area network				
M6 Engine coolant blower motor K12 Engine coolant blower motor relay K12-I Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 R46 Engine coolant blower motor relay 2 R46 Engine coolant blower motor resistor B24 Engine coolant temperature (ECT) sensor H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate - engine bay 1 X28-III Fuse box/relay plate - engine bay 2 X28-II Fuse box/relay plate - fascia 1 B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 P7 Tachometer M89 Throttle motor position sensor VAN Vehicle area network				
K12 Engine coolant blower motor relay K12-I Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 R46 Engine coolant blower motor relay 2 R54 Engine coolant blower motor resistor R54 Engine coolant themperature (ECT) sensor R54 Engine coolant temperature (ECT) sensor R55 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-III Fuse box/relay plate - engine bay 1 X28-III Fuse box/relay plate - engine bay 2 X28-II Fuse box/relay plate - fascia 1 R52-I Heated oxygen sensor (HO2S) 1 R52-II Heated oxygen sensor (HO2S) 1 R52-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch S1 Ignition switch - ignition ON Injector A5 Instrument panel A75 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network				
K12-I Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 R46 Engine coolant blower motor resistor B24 Engine coolant temperature (ECT) sensor H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate - engine bay 1 X28-III Fuse box/relay plate - engine bay 2 X28-II Fuse box/relay plate - engine bay 2 X28-II Fuse box/relay plate - fascia 1 B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 2 P7 Tachometer M89 Throttle motor position sensor VAN Vehicle area network				
K12-II Engine coolant blower motor relay 2 R46 Engine coolant blower motor resistor B24 Engine coolant temperature (ECT) sensor H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate - engine bay 1 X28-III Fuse box/relay plate - fascia 1 B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch S1 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-II Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network		·		
R46 Engine coolant blower motor resistor B24 Engine coolant temperature (ECT) sensor H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-III Fuse box/relay plate - engine bay 1 X28-IIII Fuse box/relay plate - engine bay 2 X28-III Fuse box/relay plate - fascia 1 B72-II Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-II Multifunction control module 1 A11-II Multifunction control module 2 P7 Tachometer M89 Throttle motor position sensor VAN Vehicle area network		·		
B24 Engine coolant temperature (ECT) sensor H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate - engine bay 1 X28-III Fuse box/relay plate - engine bay 2 X28-II Fuse box/relay plate - fascia 1 B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrument panel B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network		·		
H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-III Fuse box/relay plate - engine bay 1 X28-III Fuse box/relay plate - engine bay 2 X28-II Fuse box/relay plate - fascia 1 B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Injector A5 Instrument panel A75 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-II Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network		•		
Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate - engine bay 1 X28-III Fuse box/relay plate - engine bay 2 X28-II Fuse box/relay plate - fascia 1 B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch I5 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network				
M12 Fuel pump F Fuse X28-II Fuse box/relay plate - engine bay 1 X28-III Fuse box/relay plate - engine bay 2 X28-I Fuse box/relay plate - fascia 1 B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network				
F Fuse X28-II Fuse box/relay plate - engine bay 1 X28-III Fuse box/relay plate - engine bay 2 X28-I Fuse box/relay plate - fascia 1 B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network				
X28-II Fuse box/relay plate - engine bay 1 X28-III Fuse box/relay plate - engine bay 2 X28-I Fuse box/relay plate - fascia 1 B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network				
X28-III Fuse box/relay plate - engine bay 2 X28-I Fuse box/relay plate - fascia 1 B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network				
X28-I Fuse box/relay plate - fascia 1 B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network				
B72-II Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network				
B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network				
Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network				
T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network				
S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network				
15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network				
Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network	S1			
A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network				
A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network	Y3	Injector		
B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network	A5	Instrument panel		
B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network	A75	Instrumentation control module		
B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network	B25	Intake air temperature (IAT) sensor		
A11-I Multifunction control module 1 A11-II Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network	B69	Knock sensor (KS)		
A11-II Multifunction control module 2 P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network	B83	Manifold absolute pressure (MAP) sensor		
P7 Tachometer M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network	A11-I	Multifunction control module 1		
M89 Throttle motor B169 Throttle motor position sensor VAN Vehicle area network	A11-II	Multifunction control module 2		
B169 Throttle motor position sensor VAN Vehicle area network	P7	Tachometer		
VAN Vehicle area network	M89	Throttle motor		
VAN Vehicle area network	B169	Throttle motor position sensor		
P9 Vehicle speedometer	VAN	Vehicle area network		
	P9	Vehicle speedometer		

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

Manufacturer: Peugeot
Engine code: ET3JP4 (KFU)
Tuned for: R-Cat

Model: 307 1,4 16V **Output:** 65 (90) 5250

Year: 2004-08

© Autodata Limited 2010



