





K143	AC compressor clutch relay
	AC compressor clutch relay
B138	Accelerator pedal position (APP) sensor
G1	Alternator
31	Battery -
30	Battery +
S13	Brake pedal position (BPP) switch
B132	Camshaft position (CMP) sensor
S258	Clutch pedal position (CPP) switch
CAN-H	Controller area network (data bus) high
CAN-L	Controller area network (data bus) low
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
B161	Digital multifunction display
K46	Engine control (EC) relay
A35	Engine control module (ECM)
K12-I	Engine coolant blower motor relay 1
K12-II	Engine coolant blower motor relay 2
K12-III	Engine coolant blower motor relay 3
B187	Engine coolant blower motor temperature sensor
B24	Engine coolant temperature (ECT) sensor
R96	Engine coolant thermostat
B86	Engine oil level sensor
S389-I	Engine oil pressure switch 1
S389-II	Engine oil pressure switch 2
Y104	Evaporative emission (EVAP) canister purge valve
Y151	Exhaust gas recirculation (EGR) valve actuator
B149	Exhaust gas recirculation (EGR) valve position sensor
M12	Fuel pump (FP)
K20	Fuel pump (FP) relay
F	Fuse
X28-I	Fuse box/relay plate 1
X28-II	Fuse box/relay plate 2
B72-I	Heated oxygen sensor (HO2S) 1
B72-II	Heated oxygen sensor (HO2S) 2
T1	Ignition coil
K79	Ignition main circuits relay
15	Ignition switch - ignition ON
Y3	Injector
B25	Intake air temperature (IAT) sensor
Y179	Intake manifold air control actuator
B155	Intake manifold air control actuator position sensor
B69	Knock sensor (KS)
B83	Manifold absolute pressure (MAP) sensor
A11	Multifunction control module
A236	Steering column function control module
A177	Throttle control unit
M89	Throttle motor
B169	Throttle motor position sensor
פטום	Throate motor position sensor