K143	AC compressor clutch relay
X88	AC connector
31	Battery -
30	Battery +
B54	Crankshaft position (CKP) sensor
X1	Data link connector (DLC)
A35	Engine control module (ECM)
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
Y104	Evaporative emission (EVAP) canister purge valve
M12	Fuel pump
K20	Fuel pump relay
F	Fuse
Y56	Idle speed control (ISC) actuator
A52	Ignition amplifier
T1	Ignition coil
15	Ignition switch - ignition ON
A162	Immobilizer control module
Y3	Injector
A5	Instrument panel
B25	Intake air temperature (IAT) sensor
B83	Manifold absolute pressure (MAP) sensor
B72	Oxygen sensor (O2S)
P7	Tachometer
B147	Throttle position (TP) sensor
X79	Transmission connector
A57	Transmission control module (TCM)
A19	Trip computer
B33	Vehicle speed sensor (VSS)
S8	Windscreen wash/wipe switch