B161 AC refrigerant pressure sensor G1 Alternator 31 Battery + 30 Battery + 30 CAN-H Controller area network (data bus) high CAN-L Controller area network (data bus) low B54 Crankshaft position (CKP) sensor X1 Data link connector (DLC) A207 Electronic stability program (ESP) control module A35 Engine collant blower motor K12 Engine coolant blower motor K12 Engine coolant blower motor relay K12-I Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 R46 Engine coolant blower motor relay 2 R46 Engine coolant blower motor resistor B24 Engine coolant temperature (ECT) sensor S186 Engine coolant temperature (ECT) switch H63 Engine coolant temperature (ECT) switch H63 Engine malfunction indicator lamp (MILL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuse box/relay plate, engine bay 1 X28-III Fuse box/relay plate, engine bay 2 X28-II Fuse box/relay plate, engine bay 2 X28-II Fuse box/relay plate, fascia B72-I Heated oxygen sensor (HOZS) 1 Ingrition coil S1 Ignition switch Ingrition switch Ingrition switch Ingrition switch Instrumentation control module B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (ITP) sensor	A16	ABS control module			
G1 Alternator 31 Battery - 30 Battery - 30 Battery - 41 Controller area network (data bus) high 42 CAN-L Controller area network (data bus) high 53 Carakshaft position (CKP) sensor 44 Data link connector (DLC) 4207 Electronic stability program (ESP) control module 435 Engine corlorl module (ECM) 436 Engine corloant blower motor 44 Engine coolant blower motor relay 45 Engine coolant blower motor relay 46 Engine coolant blower motor relay 47 Engine coolant blower motor relay 48 Engine coolant blower motor relay 2 48 Engine coolant blower motor relay 2 48 Engine coolant blower motor relay 2 49 Engine coolant themperature (ECT) switch 40 Engine coolant temperature (ECT) switch 41 Engine anfunction indicator lamp (MIL) 47 Evaporative emission (EVAP) canister purge valve 48 Engine malfunction indicator lamp (MIL) 47 Evaporative emission (EVAP) canister purge valve 48 Engine purple plate, engine bay 1 48 Engine box/relay plate, engine bay 2 48 Ense box/relay plate, engine bay 2 48 Ense box/relay plate, sensor (HOZS) 1 48 Engine in control (IAC) valve 49 Ingilition coil 51 Ignition switch 51 Ignition switch 53 Ignition switch 54 Ignition switch 55 Ignition switch 56 Instrumentation control module 57 Instrumentation control module 58 Knock sensor (KS) 58 Manifold absolute pressure (MAP) sensor 41-1 Multifunction control module 1 41-1 Multifunction control module 2 58 Engine Control Engine Cys Powitch 57 Instrumentation control module 1 58 Throttle position (TP) sensor					
31 Battery - 30 Battery - 30 Battery - CAN-H Controller area network (data bus) high CAN-L Controller area network (data bus) low B54 Crankshaft position (CKP) sensor X1 Data link connector (DLC) A207 Electronic stability program (ESP) control module A35 Engine control module (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay K12-I Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 R46 Engine coolant blower motor relay 2 E46 Engine coolant blower motor relay 2 E46 Engine coolant temperature (ECT) sensor E48 Engine coolant temperature (ECT) sensor E48 Engine coolant temperature (ECT) sensor E48 Engine coolant temperature (ECT) sensor E49 Engine coolant temperature (ECT) sensor E40 Engine coolant temperature (ECT) sensor E41 Evaluation (EVAP) Canister purge valve E40 Engine malfunction indicator lamp (MIL) E40 Engine malfunction indicator lamp (MIL) E40 Engine box/relay plate, engine bay 1 E42-III Fuse box/relay plate, engine bay 1 E42-III Fuse box/relay plate, engine bay 2 E42-III Fuse box/relay plate, engine bay 2 E42-III Fuse box/relay plate, engine bay 2 E42-III Heated oxygen sensor (HO2S) 1 E572-II Heated oxygen sensor (HO2S) 2 E499 Idle air control (IAC) valve E41 Ignition switch E45 Ignition switch E45 Instrumentation control module E46 Knock sensor (KS) E47 Instrumentation control module E48 Knock sensor (KS) E48 Manifold absolute pressure (MAP) sensor E41-II Multifunction control module 1 E41-III Multifunction control module 2 E43 Power steering pressure (PSP) switch E47 Throttle position (TP) sensor					
30 Battery + CAN-H Controller area network (data bus) high CAN-L Controller area network (data bus) low B54 Crankshaft position (CKP) sensor X1 Data link connector (DLC) A207 Electronic stability program (ESP) control module A35 Engine corol module (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay K12-I Engine coolant blower motor relay K12-I Engine coolant blower motor relay EN12-I Engine coolant blower motor relay R46 Engine coolant blower motor relay 2 R46 Engine coolant blower motor resistor B24 Engine coolant temperature (ECT) sensor S186 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F F use X28-II Fuse box/relay plate, engine bay 1 X28-III Fuse box/relay plate, engine bay 2 X28-II Fuse box/relay plate, fascia B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Ide air control (IAC) valve T1 Ignition switch 15 Ignition switch 15 Ignition switch 16 Instrument panel A75 Instrument panel A75 Instrument panel M11-I Multifunction control module 1 M11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor					
CAN-H CAN-L COntroller area network (data bus) low B54 Crankshaft position (CKP) sensor X1 Data link connector (DLC) A207 Electronic stability program (ESP) control module A35 Engine control module (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay K12-I Engine coolant blower motor relay K12-I Engine coolant blower motor relay 1 K12-I Engine coolant blower motor relay 2 R46 Engine coolant blower motor relay 2 R47 Engine coolant temperature (ECT) sensor S186 Engine coolant temperature (ECT) sensor S186 Engine coolant temperature (ECT) sensor F187 F188 Engine maffunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-III Fuse box/relay plate, engine bay 2 X28-II Fuse box/relay plate, engine bay 2 X29-II Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 1 B72-II I fention oxilic I ignition switch ignition ON V3 Injector A5 Instrumentation control module B69 Knock sensor (KS) Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor		 			
CAN-L Controller area network (data bus) low B54 Crankshaft position (CKP) sensor X1 Data link connector (DLC) A207 Electronic stability program (ESP) control module A35 Engine control module (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay K12-II Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 R46 Engine coolant blower motor resistor B24 Engine coolant blower motor resistor B24 Engine coolant temperature (ECT) sensor S186 Engine coolant temperature (ECT) switch H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve Fuel pump F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-III Fuse box/relay plate, engine bay 2 X28-II Fuse box/relay plate, fascia B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch Instrument panel A75 Instrument panel A71-II Multifunction control module 1 A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor					
B54 Crankshaft position (CKP) sensor X1 Data link connector (DLC) A207 Electronic stability program (ESP) control module A35 Engine control module (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay K12-I Engine coolant blower motor relay 1 K12-I Engine coolant blower motor relay 2 R46 Engine coolant blower motor relay 2 R46 Engine coolant blower motor resistor B24 Engine coolant blower motor resistor B34 Engine coolant temperature (ECT) sensor S186 Engine coolant temperature (ECT) sensor S186 Engine and incurrent (EVAP) canister purge valve M13 Fuel pump F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-III Fuse box/relay plate, engine bay 2 X28-II Fuse box/relay plate, fascia B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition switch Ignition switch ignition ON T3 Injector A5 Instrument panel Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A41-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor					
X1 Data link connector (DLC) A207 Electronic stability program (ESP) control module A35 Engine control module (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay K12-I Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 R46 Engine coolant blower motor resistor B24 Engine coolant temperature (ECT) sensor S186 Engine coolant temperature (ECT) switch H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-III Fuse box/relay plate, engine bay 2 X28-II Fuse box/relay plate, fascia B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition switch 15 Ignition switch 15 Ignition switch 16 Instrument panel A75 Instrument panel Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-II Multifunction control module 1 A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor					
A207 Electronic stability program (ESP) control module A35 Engine control module (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay K12-I Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 R46 Engine coolant blower motor relay 2 R46 Engine coolant blower motor resistor B24 Engine coolant temperature (ECT) sensor S186 Engine coolant temperature (ECT) switch H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-III Fuse box/relay plate, engine bay 1 X28-III Fuse box/relay plate, engine bay 2 X28-II Fuse box/relay plate, engine bay 2 X28-II Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch Is Ignition switch ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor					
A35 Engine control module (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay K12-I Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 R46 Engine coolant blower motor relay 2 R46 Engine coolant temperature (ECT) sensor S186 Engine coolant temperature (ECT) switch H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-III Fuse box/relay plate, engine bay 2 X28-I Fuse box/relay plate, fascia B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve 11 Ignition coil S1 Ignition switch 15 Ignition switch 15 Ignition switch 16 Instrument panel A75 Instrument panel A76 Instrument panel A77 Injector A89 Manifold absolute pressure (MAP) sensor A11-II Multifunction control module 1 A11-II Multifunction control module 2 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor					
M6 Engine coolant blower motor K12 Engine coolant blower motor relay K12-I Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 R46 Engine coolant blower motor resistor B24 Engine coolant temperature (ECT) sensor S186 Engine coolant temperature (ECT) switch H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-III Fuse box/relay plate, engine bay 2 X28-II Fuse box/relay plate, engine bay 2 X28-II Fuse box/relay plate, engine bay 2 X28-II Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 1 B72-II Ignition coil S1 Ignition coil S1 Ignition switch - ignition ON Injector A5 Instrument panel A75 Instrument panel Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-II Multifunction control module 1 A35 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor					
K12 Engine coolant blower motor relay K12-II Engine coolant blower motor relay 1 K12-III Engine coolant blower motor relay 2 R46 Engine coolant blower motor relay 2 R46 Engine coolant blower motor resistor B24 Engine coolant temperature (ECT) sensor S186 Engine coolant temperature (ECT) switch H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-III Fuse box/relay plate, engine bay 1 X28-III Fuse box/relay plate, engine bay 2 X28-I Fuse box/relay plate, fascia B72-I Heated oxygen sensor (HO2S) 1 B72-III Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch ignition oN Injector A5 Instrument panel A75 Instrumentation control module B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-II Multifunction control module 1 A11-III Multifunction control module 1 A11-III Multifunction control module 1 S2231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor					
K12-I Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 R46 Engine coolant blower motor resistor B24 Engine coolant temperature (ECT) sensor S186 Engine coolant temperature (ECT) switch H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-III Fuse box/relay plate, engine bay 2 X28-I Fuse box/relay plate, fascia B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-II Multifunction control module 1 A11-II Multifunction control module 1 A11-II Multifunction control module 1 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor					
K12-II Engine coolant blower motor relay 2 R46 Engine coolant blower motor resistor B24 Engine coolant temperature (ECT) sensor S186 Engine coolant temperature (ECT) switch H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-III Fuse box/relay plate, engine bay 2 X28-I Fuse box/relay plate, engine bay 2 X28-I Fuse box/relay plate, fascia B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrument panel A75 Instrumentation control module B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-II Multifunction control module 1 A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor					
R46 Engine coolant blower motor resistor B24 Engine coolant temperature (ECT) sensor S186 Engine coolant temperature (ECT) switch H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-III Fuse box/relay plate, engine bay 2 X28-II Fuse box/relay plate, engine bay 2 X28-I Fuse box/relay plate, fascia B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch I5 Ignition switch ignition oN Y3 Injector A5 Instrument panel A75 Instrumentation control module B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor					
Engine coolant temperature (ECT) sensor S186 Engine coolant temperature (ECT) switch H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-III Fuse box/relay plate, engine bay 2 X28-I Fuse box/relay plate, fascia B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor		·			
Engine coolant temperature (ECT) switch H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-III Fuse box/relay plate, engine bay 2 X28-I Fuse box/relay plate, fascia B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrument panel B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor					
H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-III Fuse box/relay plate, engine bay 1 X28-III Fuse box/relay plate, engine bay 2 X28-II Fuse box/relay plate, engine bay 2 X28-I Fuse box/relay plate, engine bay 2 X28-I Fuse box/relay plate, fascia B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor					
Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-III Fuse box/relay plate, engine bay 2 X28-I Fuse box/relay plate, fascia B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor					
M12 Fuse pump F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-III Fuse box/relay plate, engine bay 2 X28-I Fuse box/relay plate, fascia B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor					
F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-III Fuse box/relay plate, engine bay 2 X28-I Fuse box/relay plate, fascia B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor					
X28-II Fuse box/relay plate, engine bay 1 X28-III Fuse box/relay plate, engine bay 2 X28-I Fuse box/relay plate, fascia B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor	M12	Fuel pump			
X28-III Fuse box/relay plate, engine bay 2 X28-I Fuse box/relay plate, fascia B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor	F	Fuse			
X28-I Fuse box/relay plate, fascia B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch I5 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor	X28-II	Fuse box/relay plate, engine bay 1			
B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor	X28-III				
B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor	X28-I	Fuse box/relay plate, fascia			
Y99 Idle air control (IAC) valve T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor	B72-I	Heated oxygen sensor (HO2S) 1			
T1 Ignition coil S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor	B72-II	Heated oxygen sensor (HO2S) 2			
S1 Ignition switch 15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor	Y99	Idle air control (IAC) valve			
15 Ignition switch - ignition ON Y3 Injector A5 Instrument panel A75 Instrumentation control module B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor	T1	Ignition coil			
Y3 Injector A5 Instrument panel A75 Instrumentation control module B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor	S1	Ignition switch			
A5 Instrument panel A75 Instrumentation control module B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor	15	Ignition switch - ignition ON			
A75 Instrumentation control module B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor	Y3	Injector			
B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor	A5	Instrument panel			
B83 Manifold absolute pressure (MAP) sensor A11-I Multifunction control module 1 A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor	A75	Instrumentation control module			
A11-I Multifunction control module 1 A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor	B69	Knock sensor (KS)			
A11-II Multifunction control module 2 S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor	B83	Manifold absolute pressure (MAP) sensor			
S231 Power steering pressure (PSP) switch M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor	A11-I	Multifunction control module 1			
M73 Secondary air injection (AIR) pump B147 Throttle position (TP) sensor	A11-II	Multifunction control module 2			
B147 Throttle position (TP) sensor	S231	Power steering pressure (PSP) switch			
	M73	Secondary air injection (AIR) pump			
····· l····	B147	Throttle position (TP) sensor			
VAN Vehicle area network	VAN	Vehicle area network			
B33 Vehicle speed sensor (VSS)	B33	Vehicle speed sensor (VSS)			

-25 - 24 - 23 - 22 - 21 - 20 - 19 - 18 - 17 - 16 - 15 - 14 -13 - 12 - 11 - 10 - 9 - 8 - 7 - 6 - 5 - 4 - 3 - 2 - 1

AD71596

Manufacturer: PeugeotModel: 206 1,1Engine code: TU1JP (HFX)Output: 44 (60) 5500Tuned for: BoschYear: 2000-05

© Autodata Limited 2010

Valid forever. 07.10.2020

V8 500- // Autodata

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	


NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

Manufacturer: Peugeot
Engine code: TU1JP (HFX)
Tuned for: Bosch

Model: 206 1,1 Output: 44 (60) 5500

Year: 2000-05

© Autodata Limited 2010




Manufacturer: Peugeot
Engine code: TU1JP (HFX)
Tuned for: Bosch

Model: 206 1,1 Output: 44 (60) 5500 Year: 2000-05 © Autodata Limited 2010

Valid forever. 07.10.2020

V8 500- / Autodata





Manufacturer: Peugeot Engine code: TU1JP (HFX) Tuned for: Bosch Model: 206 1,1 Output: 44 (60) 5500 Year: 2000-05 © Autodata Limited 2010 **Valid forever.** 07.10.2020

Valid forever. 07.10.2020