K143 AC compressor clutch relay  S341 AC refrigerant triple pressure switch  31 Battery +  B54 Crankshaft position (CKP) sensor  X1 Data link connector (DLC)  A35 Engine control module (ECM)  M6 Engine coolant blower motor  K12 Engine coolant blower motor relay  Engine coolant temperature (ECT) sensor  S186 Engine coolant temperature witch  H63 Engine coolant temperature witch  H63 Engine maiffunction indicator lamp (MILL)  Y104 Evaporative emission (EVAP) canister purge valve  M12 Fuse  X28-II Fuse box/relay plate, engine bay  X28-I Fuse box/relay plate, fascia  B72 Heated oxygen sensor (HO2S)  B72-I Heated oxygen sensor (HO2S) 1  H22-II Heated oxygen sensor (HO2S) 2  Y99 Idle air control (IAC) valve  A52 Ignition amplifier  T1 Ignition switch - ignition ON  A162 Immobilizer control module  S39 Inertia fusel shut-off (IFS) switch  Instrument panel  A75 Instrument panel  A76 Instrument ation control module  B26 Knock sensor (KS)  B83 Manifold absolute pressure (MSP) switch  A11 Relay module  B147 Throttle position (TP) sensor  A57 Transmission control module (TCM)  Wehicle speed sensor (VSS)					
31 Battery + B54 Crankshaft position (CKP) sensor X1 Data link connector (DLC) A35 Engine control module (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay B24 Engine coolant temperature (ECT) sensor S186 Engine coolant temperature switch H63 Engine maifunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve Fuel pump F F Fuse X28-II Fuse box/relay plate, engine bay X28-I Fuse box/relay plate, fascia B72 Heated oxygen sensor (HO2S) B72-II Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve A52 Ignition amplifier T1 Ignition coil T5 Ignition coil S39 Inertia fuel shut-off (IFS) switch N73 Injector A56 Instrument panel Instrumentation control module B25 Intake air temperature (IAT) sensor B383 Manifold absolute pressure (MAP) sensor A11 Multifunction control module S31 Power steering pressure (PSP) switch A17 Relay module T7 Throttle position (TP) sensor A57 Transmission control module (TCM)	K143	AC compressor clutch relay			
30 Battery + B54 Crankshaft position (CKP) sensor X1 Data link connector (DLC) A35 Engine control module (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay B24 Engine coolant temperature (ECT) sensor S186 Engine coolant temperature switch H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F F Isus X28-II Fuse box/relay plate, engine bay X28-II Fuse box/relay plate, fascia B72 Heated oxygen sensor (HO2S) B72-II Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve A52 Ignition amplifier T1 Ignition coil 15 Ignition switch - ignition ON A162 Immobilizer control module S39 Inertia fuel shut-off (IFS) switch Y3 Injector A5 Instrument panel A75 Instrument panel A75 Instrumentation control module S231 Power steering pressure (MAP) sensor A11 Multifunction control module S231 Power steering pressure (PSP) switch A11 Multifunction control module S231 Power steering pressure (PSP) switch A11 Relay module B147 Throttle position (TP) sensor A57 Transmission control module (TCM)	S341				
B54 Crankshaft position (CKP) sensor X1 Data link connector (DLC) A35 Engine control module (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay B24 Engine coolant temperature (ECT) sensor S186 Engine coolant temperature switch H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate, engine bay X28-I Fuse box/relay plate, fascia B72 Heated oxygen sensor (HO2S) B72-II Heated oxygen sensor (HO2S) B72-II Heated oxygen sensor (HO2S) 2 Idle air control (IAC) valve A52 Ignition amplifier I1 Ignition coil I5 Ignition switch - ignition ON A162 Immobilizer control module S39 Inertia fuel shut-off (IFS) switch Instrument panel Instrument panel Instrument panel Instrument panel Instrument air temperature (IAT) sensor A51 Multifunction control module S231 Power steering pressure (PSP) switch A11 Multifunction control module S231 Power steering pressure (PSP) switch A17 Relay module Transmission control module (TCM)	31	Battery -			
X1 Data link connector (DLC) A35 Engine control module (ECM) M6 Engine coolant blower motor K12 Engine coolant blower motor relay B24 Engine coolant temperature (ECT) sensor S186 Engine coolant temperature switch H63 Engine malfunction indicator lamp (MILL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate, engine bay X28-II Fuse box/relay plate, fascia B72 Heated oxygen sensor (HO2S) B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve Ignition amplifier I1 Ignition coil I5 Ignition switch - ignition ON A162 Immobilizer control module S39 Inertia fuel shut-off (IFS) switch Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11 Multifunction control module S231 Power steering pressure (PSP) switch R17 Relay module B17 Throttle position (TP) sensor A57 Transmission control module (TCM)	30	Battery +			
A35 Engine control module (ECM)  M6 Engine coolant blower motor  K12 Engine coolant blower motor relay  B24 Engine coolant temperature (ECT) sensor  S186 Engine coolant temperature switch  H63 Engine malfunction indicator lamp (MIL)  Y104 Evaporative emission (EVAP) canister purge valve  M12 Fuel pump  F Fuse  X28-II Fuse box/relay plate, engine bay  X28-II Fuse box/relay plate, engine bay  X28-II Fuse box/relay plate, fascia  B72 Heated oxygen sensor (HO2S)  B72-II Heated oxygen sensor (HO2S) 1  B72-II Heated oxygen sensor (HO2S) 2  Y99 Idle air control (IAC) valve  A52 Ignition amplifier  T1 Ignition coil  15 Ignition switch - ignition ON  A162 Immobilizer control module  S39 Inertia fuel shut-off (IFS) switch  Injector  A5 Instrument panel  A75 Instrument panel  A75 Instrumentation control module  B25 Intake air temperature (IAT) sensor  B69 Knock sensor (KS)  B83 Manifold absolute pressure (MAP) sensor  A11 Multifunction control module  S231 Power steering pressure (PSP) switch  A171 Relay module  B147 Throttle position (TP) sensor  A57 Transmission control module (TCM)	B54	Crankshaft position (CKP) sensor			
M6 Engine coolant blower motor K12 Engine coolant blower motor relay B24 Engine coolant temperature (ECT) sensor S186 Engine coolant temperature switch H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate, engine bay X28-II Fuse box/relay plate, fascia B72 Heated oxygen sensor (HO2S) B72-II Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve A52 Ignition amplifier T1 Ignition coil 15 Ignition switch - ignition ON A162 Immobilizer control module S39 Inertia fuel shut-off (IFS) switch Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11 Multifunction control module S231 Power steering pressure (PSP) switch A171 Relay module B147 Throttle position (TP) sensor A57 Transmission control module (TCM)	X1	Data link connector (DLC)			
K12 Engine coolant blower motor relay B24 Engine coolant temperature (ECT) sensor S186 Engine coolant temperature switch H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate, engine bay X28-I Fuse box/relay plate, engine bay X28-I Fuse box/relay plate, fascia B72 Heated oxygen sensor (HO2S) B72-II Heated oxygen sensor (HO2S) 1 B72-III Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve A52 Ignition ampifier T1 Ignition coil Ignition switch - ignition ON A162 Immobilizer control module S39 Inertia fuel shut-off (IFS) switch Y3 Injector A5 Instrument panel Instrument panel Instrument panel Instrument air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11 Multifunction control module S231 Power steering pressure (PSP) switch A171 Relay module B147 Throttle position (TP) sensor Transmission control module (TCM)	A35	Engine control module (ECM)			
B24 Engine coolant temperature (ECT) sensor S186 Engine coolant temperature switch H63 Engine malifunction indicator lamp (MIL.) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate, engine bay X28-I Fuse box/relay plate, fascia B72 Heated oxygen sensor (HO2S) B72-II Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve A52 Ignition amplifier T1 Ignition coil 15 Ignition switch - ignition ON A162 Immobilizer control module S39 Inertia fuel shut-off (IFS) switch Y3 Injector A5 Instrument panel A75 Instrument panel B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11 Multifunction control module S23 Power steering pressure (PSP) switch A111 Relay module Throttle position (TP) sensor Throttle position (TP) sensor Transmission control module (TCM)	M6	Engine coolant blower motor			
S186 Engine coolant temperature switch H63 Engine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate, engine bay X28-I Fuse box/relay plate, fascia B72 Heated oxygen sensor (HO2S) B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve A52 Ignition amplifier T1 Ignition coil 15 Ignition switch - ignition ON A162 Immobilizer control module S39 Inertia fuel shut-off (IFS) switch Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11 Multifunction control module B231 Power steering pressure (PSP) switch A171 Relay module B147 Throttle position (TP) sensor	K12	Engine coolant blower motor relay			
H63 Eggine malfunction indicator lamp (MIL) Y104 Evaporative emission (EVAP) canister purge valve M12 Fuel pump F Fuse X28-II Fuse box/relay plate, engine bay X28-I Fuse box/relay plate, fascia B72 Heated oxygen sensor (HO2S) B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve A52 Ignition amplifier T1 Ignition coil 15 Ignition switch - ignition ON A162 Immobilizer control module S39 Inertia fuel shut-off (IFS) switch N73 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11 Multifunction control module S231 Power steering pressure (PSP) switch A171 Relay module B147 Throttle position (TP) sensor Transmission control module (TCM)	B24	Engine coolant temperature (ECT) sensor			
Y104 Evaporative emission (EVAP) canister purge valve  M12 Fuel pump  F Fuse  X28-II Fuse box/relay plate, engine bay  X28-I Fuse box/relay plate, fascia  B72 Heated oxygen sensor (HO2S)  B72-I Heated oxygen sensor (HO2S) 1  B72-II Heated oxygen sensor (HO2S) 2  Y99 Idle air control (IAC) valve  A52 Ignition amplifier  T1 Ignition coil  15 Ignition switch - ignition ON  A162 Immobilizer control module  S39 Inertia fuel shut-off (IFS) switch  Y3 Injector  A5 Instrument panel  A75 Instrumentation control module  B25 Intake air temperature (IAT) sensor  B69 Knock sensor (KS)  B83 Manifold absolute pressure (MAP) sensor  A11 Multifunction control module  S231 Power steering pressure (PSP) switch  A171 Relay module  B147 Throttle position (TP) sensor  A57 Transmission control module (TCM)	S186	Engine coolant temperature switch			
M12 Fuel pump F Fuse  X28-II Fuse box/relay plate, engine bay  X28-I Fuse box/relay plate, fascia  B72 Heated oxygen sensor (HO2S)  B72-I Heated oxygen sensor (HO2S) 1  B72-II Heated oxygen sensor (HO2S) 2  Y99 Idle air control (IAC) valve  A52 Ignition amplifier  T1 Ignition coil  15 Ignition switch - ignition ON  A162 Immobilizer control module  S39 Inertia fuel shut-off (IFS) switch  Y3 Injector  A5 Instrument panel  A75 Instrumentation control module  B25 Intake air temperature (IAT) sensor  Knock sensor (KS)  B83 Manifold absolute pressure (MAP) sensor  A11 Multifunction control module  S231 Power steering pressure (PSP) switch  A171 Relay module  B147 Throttle position (TP) sensor  A57 Transmission control module (TCM)	H63	Engine malfunction indicator lamp (MIL)			
F Fuse  X28-II Fuse box/relay plate, engine bay  X28-I Fuse box/relay plate, fascia  B72 Heated oxygen sensor (HO2S)  B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve  A52 Ignition amplifier  T1 Ignition coil  15 Ignition switch - ignition ON  A162 Immobilizer control module  S39 Inertia fuel shut-off (IFS) switch  Y3 Injector  A5 Instrument panel  A75 Instrumentation control module  B25 Intake air temperature (IAT) sensor  B69 Knock sensor (KS)  B83 Manifold absolute pressure (MAP) sensor  A11 Multifunction control module  S231 Power steering pressure (PSP) switch  A171 Relay module  B147 Throttle position (TP) sensor  Transmission control module (TCM)	Y104	Evaporative emission (EVAP) canister purge valve			
X28-II Fuse box/relay plate, engine bay X28-I Fuse box/relay plate, fascia B72 Heated oxygen sensor (HO2S) B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve A52 Ignition amplifier T1 Ignition coil 15 Ignition switch - ignition ON A162 Immobilizer control module S39 Inertia fuel shut-off (IFS) switch Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11 Multifunction control module S231 Power steering pressure (PSP) switch A171 Relay module B147 Throttle position (TP) sensor Transmission control module (TCM)	M12	Fuel pump			
X28-I Fuse box/relay plate, fascia B72 Heated oxygen sensor (HO2S) B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve A52 Ignition amplifier T1 Ignition coil 15 Ignition switch - ignition ON A162 Immobilizer control module S39 Inertia fuel shut-off (IFS) switch Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11 Multifunction control module S231 Power steering pressure (PSP) switch A171 Relay module B147 Throttle position (TP) sensor A57 Transmission control module (TCM)	F	Fuse			
B72-I Heated oxygen sensor (HO2S) B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve A52 Ignition amplifier T1 Ignition coil 15 Ignition switch - ignition ON A162 Immobilizer control module S39 Inertia fuel shut-off (IFS) switch Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11 Multifunction control module S231 Power steering pressure (PSP) switch A171 Relay module B147 Throttle position (TP) sensor A57 Transmission control module (TCM)	X28-II	Fuse box/relay plate, engine bay			
B72-I Heated oxygen sensor (HO2S) 1 B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve A52 Ignition amplifier T1 Ignition coil 15 Ignition switch - ignition ON A162 Immobilizer control module S39 Inertia fuel shut-off (IFS) switch Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11 Multifunction control module S231 Power steering pressure (PSP) switch A171 Relay module B147 Throttle position (TP) sensor A57 Transmission control module (TCM)	X28-I	Fuse box/relay plate, fascia			
B72-II Heated oxygen sensor (HO2S) 2 Y99 Idle air control (IAC) valve A52 Ignition amplifier T1 Ignition coil 15 Ignition switch - ignition ON A162 Immobilizer control module S39 Inertia fuel shut-off (IFS) switch Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11 Multifunction control module S231 Power steering pressure (PSP) switch A171 Relay module B147 Throttle position (TP) sensor	B72	Heated oxygen sensor (HO2S)			
Y99 Idle air control (IAC) valve A52 Ignition amplifier T1 Ignition coil 15 Ignition switch - ignition ON A162 Immobilizer control module S39 Inertia fuel shut-off (IFS) switch Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11 Multifunction control module S231 Power steering pressure (PSP) switch A171 Relay module B147 Throttle position (TP) sensor A57 Transmission control module (TCM)	B72-I	Heated oxygen sensor (HO2S) 1			
A52 Ignition amplifier T1 Ignition coil 15 Ignition switch - ignition ON A162 Immobilizer control module S39 Inertia fuel shut-off (IFS) switch Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11 Multifunction control module S231 Power steering pressure (PSP) switch A171 Relay module B147 Throttle position (TP) sensor A57 Transmission control module (TCM)	B72-II	Heated oxygen sensor (HO2S) 2			
T1 Ignition coil  15 Ignition switch - ignition ON  A162 Immobilizer control module  S39 Inertia fuel shut-off (IFS) switch  Y3 Injector  A5 Instrument panel  A75 Instrumentation control module  B25 Intake air temperature (IAT) sensor  B69 Knock sensor (KS)  B83 Manifold absolute pressure (MAP) sensor  A11 Multifunction control module  S231 Power steering pressure (PSP) switch  A171 Relay module  B147 Throttle position (TP) sensor  A57 Transmission control module (TCM)	Y99	Idle air control (IAC) valve			
Ignition switch - ignition ON  A162 Immobilizer control module  S39 Inertia fuel shut-off (IFS) switch  Y3 Injector  A5 Instrument panel  A75 Instrumentation control module  B25 Intake air temperature (IAT) sensor  B69 Knock sensor (KS)  B83 Manifold absolute pressure (MAP) sensor  A11 Multifunction control module  S231 Power steering pressure (PSP) switch  A171 Relay module  B147 Throttle position (TP) sensor  A57 Transmission control module (TCM)	A52	Ignition amplifier			
A162 Immobilizer control module S39 Inertia fuel shut-off (IFS) switch Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11 Multifunction control module S231 Power steering pressure (PSP) switch A171 Relay module B147 Throttle position (TP) sensor A57 Transmission control module (TCM)	T1	Ignition coil			
S39 Inertia fuel shut-off (IFS) switch Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11 Multifunction control module S231 Power steering pressure (PSP) switch A171 Relay module B147 Throttle position (TP) sensor A57 Transmission control module (TCM)	15	Ignition switch - ignition ON			
Y3 Injector A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11 Multifunction control module S231 Power steering pressure (PSP) switch A171 Relay module B147 Throttle position (TP) sensor A57 Transmission control module (TCM)	A162	Immobilizer control module			
A5 Instrument panel A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11 Multifunction control module S231 Power steering pressure (PSP) switch A171 Relay module B147 Throttle position (TP) sensor A57 Transmission control module (TCM)	S39	Inertia fuel shut-off (IFS) switch			
A75 Instrumentation control module B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11 Multifunction control module S231 Power steering pressure (PSP) switch A171 Relay module B147 Throttle position (TP) sensor A57 Transmission control module (TCM)	Y3	Injector			
B25 Intake air temperature (IAT) sensor B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11 Multifunction control module S231 Power steering pressure (PSP) switch A171 Relay module B147 Throttle position (TP) sensor A57 Transmission control module (TCM)	A5	Instrument panel			
B69 Knock sensor (KS) B83 Manifold absolute pressure (MAP) sensor A11 Multifunction control module S231 Power steering pressure (PSP) switch A171 Relay module B147 Throttle position (TP) sensor A57 Transmission control module (TCM)	A75	Instrumentation control module			
B83 Manifold absolute pressure (MAP) sensor A11 Multifunction control module S231 Power steering pressure (PSP) switch A171 Relay module B147 Throttle position (TP) sensor A57 Transmission control module (TCM)	B25	Intake air temperature (IAT) sensor			
A11 Multifunction control module S231 Power steering pressure (PSP) switch A171 Relay module B147 Throttle position (TP) sensor A57 Transmission control module (TCM)	B69	Knock sensor (KS)			
S231 Power steering pressure (PSP) switch A171 Relay module B147 Throttle position (TP) sensor A57 Transmission control module (TCM)	B83	Manifold absolute pressure (MAP) sensor			
A171 Relay module B147 Throttle position (TP) sensor A57 Transmission control module (TCM)	A11	Multifunction control module			
B147 Throttle position (TP) sensor A57 Transmission control module (TCM)	S231	Power steering pressure (PSP) switch			
A57 Transmission control module (TCM)	A171	Relay module			
	B147	Throttle position (TP) sensor			
B33 Vehicle speed sensor (VSS)	A57	Transmission control module (TCM)			
	B33	Vehicle speed sensor (VSS)			

V8 500- /Autodata

```
□19 □18 □17 □16 □15 □14 □13 □12 □11 □10 □9 □8 □7 □6 □5 □4 □3 □2 □1 □37 □36 □35 □34 □33 □32 □31 □30 □29 □28 □27 □26 □25 □24 □23 □22 □21 □20 □55 □54 □53 □52 □51 □50 □49 □48 □47 □46 □45 □44 □43 □42 □41 □40 □39 □38 □40 □40 □39 □38
```

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

Manufacturer: Peugeot
Engine code: TU5JP (NFT)
Tuned for: R-Cat

Model: 306 (97-03) 1,6 Output: 72 (98) 5700 Year: 2000-03 © Autodata Limited 2010

Valid forever. 07.10.2020



