



A16 ABS control module K143 AC compressor clutch relay B161 AC refrigerant pressure sensor B133 Accelerator pedal position (APP) sensor B121 Barometric pressure (BARO) sensor 31 Battery + 30 Battery + S13 Brake pedal position (BPP) switch B132 Camshaft position (CMP) sensor S258 Clutch pedal position pedal	
B161 AC refrigerant pressure sensor B133 Accelerator pedal position (APP) sensor B121 Barometric pressure (BARO) sensor 31 Battery + 31 Battery + 31 Battery + 31 Battery + 31 Brake pedal position (BPP) switch B132 Camshaft position (CMP) sensor S258 Clutch pedal position (CMP) sensor S258 Clutch pedal position (CMP) sensor D358 Crankshaft position (CMP) sensor X1 Data link connector (DLC) A161 Digital multifunction display A35 Engine control (EC) relay A35 Engine control module (ECM) K12-II Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 K12-III Engine coolant blower motor relay 3 K12-IV Engine coolant blower motor relay 4 B24 Engine coolant themperature (ECT) sensor H63 Engine malfunction indicator lamp (MIL) B86 Engine oil level sensor S389 Engine oil level sensor S389 Engine oil ressure switch Y28 Exhaust gas recirculation (EGR) solenoid B149 Exhaust gas recirculation (EGR) valve position sensor F64 Fuel filter heater Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module If y3 linjector A5 Instrument panel	
B138 Accelerator pedal position (APP) sensor B121 Barometric pressure (BARO) sensor 31 Battery - 33 Battery - \$13 Brake pedal position (BPP) switch B132 Camshaft position (CPP) switch B132 Camshaft position (CPP) switch CAN Controller area network (data bus) B54 Crankshaft position (CKP) sensor X1 Data link connector (DLC) A161 Digital multifunction display K46 Engine control (EC) relay A35 Engine control module (ECM) K12-II Engine coolant blower motor relay 1 K12-III Engine coolant blower motor relay 2 K12-III Engine coolant blower motor relay 3 K12-IV Engine coolant blower motor relay 4 B24 Engine coolant blower motor relay 4 B25 Engine oil reversor motor indicator lamp (MIL) B86 Engine oil level sensor S389 Engine oil ressure switch Y28 Exhaust gas recirculation (EGR) solenoid B149 Exhaust gas recirculation (EGR) valve position sensor F Fuse X28-II Fuse box/relay plate, fascia 1 R5 Glow plug A104 Instrument panel	
Battery - 31 Battery - 32 Battery - 33 Battery + 34 Brake pedal position (CMP) switch 35 Brake pedal position (CMP) sensor 35 Camshaft position (CMP) sensor 35 Clutch pedal position (CMP) sensor 36 Cantroller area network (data bus) 36 Crankshaft position (CKP) sensor 37 Data link connector (DLC) 38 And Digital multifunction display 39 Engine control (EC) relay 30 Engine control module (ECM) 30 Engine coolant blower motor relay 1 31 Engine coolant blower motor relay 2 32 Engine coolant blower motor relay 2 33 Engine coolant blower motor relay 3 34 Engine coolant blower motor relay 4 39 Engine coolant blower motor relay 4 30 Engine coolant temperature (ECT) sensor 30 Engine malfunction indicator lamp (MIL) 30 Engine oil level sensor 30 Engine oil pressure switch 30 Exhaust gas recirculation (EGR) solenoid 31 Exhaust gas recirculation (EGR) valve position sensor 31 Fuel temperature sensor 32 Fuel filter heater 33 Fuel temperature sensor 44 Fuel flow control valve 45 Engine box/relay plate, engine bay 1 34 Evaluation auxiliary circuits relay 35 Ignition switch - start signal 36 Instrument panel	
31 Battery + 30 Battery + 313 Brake pedal position (BPP) switch B132 Camshaft position (CMP) sensor S258 Clutch pedal position (CPP) switch CAN Controller area network (data bus) B54 Crankshaft position (CKP) sensor X1 Data link connector (DLC) A161 Digital multifunction display K46 Engine control (EC) relay A35 Engine control (EC) relay A35 Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 K12-III Engine coolant blower motor relay 3 K12-IV Engine coolant blower motor relay 3 K12-IV Engine coolant blower motor relay 3 B24 Engine coolant blower motor relay 4 B24 Engine coolant temperature (ECT) sensor H63 Engine oil level sensor S389 Engine oil level sensor S389 Engine oil level sensor Y28 Exhaust gas recirculation (EGR) solenoid B149 Exhaust gas recirculation (EGR) valve position sensor R64 Fuel filter heater Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module K76 Ignition auxiliary circuits relay Injector A5 Instrument panel	
30 Battery + S13 Brake pedal position (BPP) switch B132 Camshaft position (CPP) sensor S258 Clutch pedal position (CPP) switch CAN Controller area network (data bus) B54 Crankshaft position (CKP) sensor X1 Data link connector (DLC) A161 Digital multifunction display K46 Engine control (EC) relay A35 Engine control (EC) relay A35 Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 K12-III Engine coolant blower motor relay 3 K12-IV Engine coolant blower motor relay 3 K12-IV Engine coolant blower motor relay 4 B24 Engine coolant blower motor relay 4 B24 Engine colant temperature (ECT) sensor H63 Engine oil revel sensor S389 Engine oil level sensor S389 Engine oil level sensor S484 Exhaust gas recirculation (EGR) solenoid B149 Exhaust gas recirculation (EGR) valve position sensor F64 Fuel filter heater Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F F use X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, engine bay 1 S28-I Glow plug A104 Glow plug control module K76 Ignition auxiliary circuits relay Injector Instrument panel	
S13 Brake pedal position (BPP) switch B132 Camshaft position (CMP) sensor S258 Clutch pedal position (CPP) switch CAN Controller area network (data bus) B54 Crankshaft position (CKP) sensor X1 Data link connector (DLC) A161 Digital multifunction display K46 Engine control (EC) relay A35 Engine control module (ECM) K12-I Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 K12-III Engine coolant blower motor relay 3 K12-IV Engine coolant blower motor relay 3 K12-IV Engine coolant blower motor relay 4 B24 Engine coolant blower motor relay 4 B24 Engine coolant blower motor relay 4 B26 Engine oil level sensor B389 Engine oil revel sensor S389 Engine oil revel sensor S389 Engine oil revel sensor B149 Exhaust gas recirculation (EGR) solenoid B149 Exhaust gas recirculation (EGR) valve position sensor R64 Fuel filter heater Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 R5 Glow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - start signal A162 Immobilizer control module Y3 Injector Instrument panel	
B132 Camshaft position (CMP) sensor S258 Clutch pedal position (CPP) switch CAN Controller area network (data bus) B54 Crankshaft position (CKP) sensor X1 Data link connector (DLC) A161 Digital multifunction display K46 Engine control (EC) relay A35 Engine control module (ECM) K12-I Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 K12-III Engine coolant blower motor relay 3 K12-IV Engine coolant blower motor relay 4 B24 Engine coolant blower motor relay 4 B24 Engine coolant blower motor relay 4 B26 Engine in Internation indicator lamp (MIL) B86 Engine oil level sensor S389 Engine oil pressure switch Y28 Exhaust gas recirculation (EGR) solenoid B149 Exhaust gas recirculation (EGR) valve position sensor R64 Fuel filter heater Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 Glow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - start signal A162 Immobilizer control module Y3 Injector Instrument panel	
S258 Clutch pedal position (CPP) switch CAN Controller area network (data bus) B54 Crankshaft position (CKP) sensor X1 Data link connector (DLC) A161 Digital multifunction display K46 Engine control (EC) relay A35 Engine control module (ECM) K12-I Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 K12-III Engine coolant blower motor relay 3 K12-IV Engine coolant blower motor relay 4 B24 Engine coolant blower motor relay 4 B25 Engine coolant themperature (ECT) sensor H63 Engine malfunction indicator lamp (MIL) B86 Engine oil level sensor S389 Engine oil pressure switch Y28 Exhaust gas recirculation (EGR) solenoid B149 Exhaust gas recirculation (EGR) valve position sensor R64 Fuel filter heater Y194 Fuel flow control valve Fuel ali pressure (FRP) sensor B186 Fuel rail pressure (FRP) sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 Glow plug A104 Glow plug control module K76 Ignition switch - start signal A162 Immobilizer control module Ingector Ingector Instrument panel	
CAN Controller area network (data bus) B54 Crankshaft position (CKP) sensor X1 Data link connector (DLC) A161 Digital multifunction display K46 Engine control (EC) relay A35 Engine control module (ECM) K12-I Engine coolant blower motor relay 1 K12-III Engine coolant blower motor relay 2 K12-III Engine coolant blower motor relay 3 K12-IV Engine coolant blower motor relay 4 B24 Engine coolant blower motor relay 4 B25 Engine coolant temperature (ECT) sensor H63 Engine malfunction indicator lamp (MIL) B86 Engine oil level sensor S389 Engine oil pressure switch Y28 Exhaust gas recirculation (EGR) solenoid B149 Exhaust gas recirculation (EGR) valve position sensor F64 Fuel filter heater Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, engine bay 1 R5 Glow plug A104 Glow plug control module K76 Ignition switch - ignition ON Ignition switch - start signal A162 Immobilizer control module Injector Injector Instrument panel	
B54 Crankshaft position (CKP) sensor X1 Data link connector (DLC) A161 Digital multifunction display K46 Engine control (EC) relay A35 Engine control module (ECM) K12-I Engine coolant blower motor relay 1 K12-III Engine coolant blower motor relay 2 K12-III Engine coolant blower motor relay 3 K12-IV Engine coolant blower motor relay 4 B24 Engine coolant blower motor relay 4 B24 Engine coolant temperature (ECT) sensor H63 Engine malfunction indicator lamp (MIL) B86 Engine oil level sensor S389 Engine oil pressure switch Y28 Exhaust gas recirculation (EGR) solenoid B149 Exhaust gas recirculation (EGR) valve position sensor R64 Fuel filter heater Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 R5 Glow plug A104 Giow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - ignition ON 50 Ignition switch - start signal Inmobilizer control module Y3 Injector A5 Instrument panel	
X1 Data link connector (DLC) A161 Digital multifunction display K46 Engine control (EC) relay A35 Engine control module (ECM) K12-I Engine coolant blower motor relay 1 K12-III Engine coolant blower motor relay 2 K12-III Engine coolant blower motor relay 3 K12-IV Engine coolant blower motor relay 4 B24 Engine coolant blower motor relay 4 B25 Engine coolant blower motor relay 4 B26 Engine adfunction indicator lamp (MIL) B27 Engine malfunction indicator lamp (MIL) B38 Engine oil level sensor B389 Engine oil pressure switch B49 Exhaust gas recirculation (EGR) solenoid B49 Exhaust gas recirculation (EGR) valve position sensor B40 Fuel filter heater B419 Fuel flow control valve B48 Fuel rail pressure (FRP) sensor B48 Fuel rail pressure (FRP) sensor B49 Fuel temperature sensor F Fuse B48 Fuel rail pressure (FRP) sensor B49 Fuse box/relay plate, engine bay 1 B49 Fuse box/relay plate, fascia 1 B40 Glow plug B404 Glow plug control module B405 Ignition auxiliary circuits relay B416 Ignition switch - ignition ON B406 Ignition switch - start signal B416 Immobilizer control module B42 Injector B43 Instrument panel	
A161 Digital multifunction display K46 Engine control (EC) relay A35 Engine control module (ECM) K12-I Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 K12-III Engine coolant blower motor relay 3 K12-IV Engine coolant blower motor relay 4 B24 Engine coolant blower motor relay 4 B25 Engine coolant temperature (ECT) sensor H68 Engine malfunction indicator lamp (MIL) B86 Engine oil level sensor S389 Engine oil level sensor S389 Engine oil pressure switch Y28 Exhaust gas recirculation (EGR) solenoid B149 Exhaust gas recirculation (EGR) valve position sensor R64 Fuel filter heater Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module K76 Ignition awililary circuits relay 15 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
K46 Engine control (EC) relay A35 Engine control module (ECM) K12-I Engine coolant blower motor relay 1 K12-III Engine coolant blower motor relay 2 K12-IIII Engine coolant blower motor relay 3 K12-IIII Engine coolant blower motor relay 4 Engine coolant blower motor relay 4 B24 Engine coolant temperature (ECT) sensor H63 Engine malifunction indicator lamp (MIL) B86 Engine oil level sensor S389 Engine oil pressure switch Y28 Exhaust gas recirculation (EGR) solenoid B149 Exhaust gas recirculation (EGR) valve position sensor R64 Fuel filter heater Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
K46 Engine control (EC) relay A35 Engine control module (ECM) K12-I Engine coolant blower motor relay 1 K12-III Engine coolant blower motor relay 2 K12-IIII Engine coolant blower motor relay 3 K12-IIII Engine coolant blower motor relay 4 Engine coolant blower motor relay 4 B24 Engine coolant temperature (ECT) sensor H63 Engine malifunction indicator lamp (MIL) B86 Engine oil level sensor S389 Engine oil pressure switch Y28 Exhaust gas recirculation (EGR) solenoid B149 Exhaust gas recirculation (EGR) valve position sensor R64 Fuel filter heater Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
A35 Engine control module (ECM) K12-I Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 K12-III Engine coolant blower motor relay 3 K12-IV Engine coolant blower motor relay 3 K12-IV Engine coolant blower motor relay 4 B24 Engine coolant temperature (ECT) sensor H63 Engine malfunction indicator lamp (MIL) B86 Engine oil level sensor S389 Engine oil pressure switch Y28 Exhaust gas recirculation (EGR) solenoid B149 Exhaust gas recirculation (EGR) valve position sensor R64 Fuel filter heater Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module K76 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
K12-II Engine coolant blower motor relay 1 K12-II Engine coolant blower motor relay 2 K12-III Engine coolant blower motor relay 3 K12-IV Engine coolant blower motor relay 4 B24 Engine coolant temperature (ECT) sensor H63 Engine malfunction indicator lamp (MIL) B86 Engine oil level sensor S389 Engine oil pressure switch Y28 Exhaust gas recirculation (EGR) solenoid B149 Exhaust gas recirculation (EGR) valve position sensor R64 Fuel filter heater Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module K76 Ignition switch - ignition ON 50 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
K12-III Engine coolant blower motor relay 2 K12-III Engine coolant blower motor relay 3 K12-IV Engine coolant blower motor relay 4 B24 Engine coolant temperature (ECT) sensor H63 Engine malfunction indicator lamp (MIL) B86 Engine oil level sensor S389 Engine oil pressure switch Y28 Exhaust gas recirculation (EGR) solenoid B149 Exhaust gas recirculation (EGR) valve position sensor R64 Fuel filter heater Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - ignition ON 50 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
K12-III Engine coolant blower motor relay 3 K12-IV Engine coolant blower motor relay 4 B24 Engine coolant temperature (ECT) sensor H63 Engine malfunction indicator lamp (MIL) B86 Engine oil level sensor S389 Engine oil pressure switch Y28 Exhaust gas recirculation (EGR) solenoid B149 Exhaust gas recirculation (EGR) valve position sensor R64 Fuel filter heater Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - ignition ON 50 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
K12-IV Engine coolant blower motor relay 4 B24 Engine coolant temperature (ECT) sensor Engine malfunction indicator lamp (MIL) B86 Engine oil level sensor S389 Engine oil pressure switch Y28 Exhaust gas recirculation (EGR) solenoid B149 Exhaust gas recirculation (EGR) valve position sensor R64 Fuel filter heater Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
B24 Engine coolant temperature (ECT) sensor H63 Engine malfunction indicator lamp (MIL) B86 Engine oil level sensor S389 Engine oil pressure switch Y28 Exhaust gas recirculation (EGR) solenoid B149 Exhaust gas recirculation (EGR) valve position sensor R64 Fuel filter heater Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - ignition ON 50 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
H63 Engine malfunction indicator lamp (MIL) B86 Engine oil level sensor S389 Engine oil pressure switch Y28 Exhaust gas recirculation (EGR) solenoid B149 Exhaust gas recirculation (EGR) valve position sensor R64 Fuel filter heater Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - ignition ON 50 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	r
B86 Engine oil level sensor \$389 Engine oil pressure switch Y28 Exhaust gas recirculation (EGR) solenoid B149 Exhaust gas recirculation (EGR) valve position sensor R64 Fuel filter heater Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - ignition ON 50 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
S389 Engine oil pressure switch Y28 Exhaust gas recirculation (EGR) solenoid B149 Exhaust gas recirculation (EGR) valve position sensor R64 Fuel filter heater Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - ignition ON 50 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
Y28 Exhaust gas recirculation (EGR) solenoid B149 Exhaust gas recirculation (EGR) valve position sensor R64 Fuel filter heater Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - ignition ON 50 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
B149 Exhaust gas recirculation (EGR) valve position sensor R64 Fuel filter heater Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - ignition ON 50 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
Fuel filter heater Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
Y194 Fuel flow control valve B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - ignition ON 50 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	SHOIT SCHOOL
B186 Fuel rail pressure (FRP) sensor B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - ignition ON 50 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
B31 Fuel temperature sensor F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - ignition ON 50 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
F Fuse X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - ignition ON 50 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
X28-II Fuse box/relay plate, engine bay 1 X28-I Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - ignition ON 50 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
X28-I Fuse box/relay plate, fascia 1 R5 Glow plug A104 Glow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - ignition ON 50 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
R5 Glow plug A104 Glow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - ignition ON 50 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
A104 Glow plug control module K76 Ignition auxiliary circuits relay 15 Ignition switch - ignition ON 50 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
K76 Ignition auxiliary circuits relay 15 Ignition switch - ignition ON 50 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
15 Ignition switch - ignition ON 50 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
50 Ignition switch - start signal A162 Immobilizer control module Y3 Injector A5 Instrument panel	
A162 Immobilizer control module Y3 Injector A5 Instrument panel	
Y3 Injector A5 Instrument panel	
A5 Instrument panel	
A75 Instrumentation control module	
VCC Intoke oir flor control actuator	
Y66 Intake air flap control actuator	
B25 Intake air temperature (IAT) sensor	
Y179 Intake manifold air control actuator	
B155 Intake manifold air control actuator position sensor	JII SEIISUI
B30 Mass air flow (MAF) sensor	
A11 Multifunction control module	
A81 Power steering control module	
P7 Tachometer	_
B105 Turbocharger (TC) boost pressure sensor	
Y196 Turbocharger (TC) control solenoid	

A123	Vehicle speed sensor (VSS) signal amplifier
P9	Vehicle speedometer
B19	Wheel speed sensor, left front

