Monitoring and Control

You can check the status of networked projectors and perform various projector operations using these methods.

Method	Details
ESC/VP21 command	When the projector is connected to a computer with an RS-232C cable, you can control the projector with communication commands.
Epson Web Control	By using the Web browser of a computer connected to the projector on a network, you can set the projector's functions and control the projector.
PJLink command	The projector complies with the PJLink Class2 standard established by the JBMIA. From a computer connected to the projector on a network, you can control the projector with PJLink commands. For more details on PJLink, see the following Web site. http://pjlink.jbmia.or.jp/english/
Art-Net command *	Art-Net is an Ethernet communication protocol based on the TCP/IP protocol. You can control the projector by using a DMX controller or an application system.
Epson Projector Management	Allows you to control multiple Epson projectors on a network. You can download Epson Projector Management from the following Web site. epson.sn/
Crestron Connected	If you are using the Crestron Connected network monitoring and control system, you can set up your projector for use on the system. For additional information on Crestron Connected, visit the Crestron Web site. https://www.crestron.com/products/line/crestron-connected

* EB-L265F/EB-L260F

ESC/VP21 Command List

Item	Function	Command	Setting Value/Response Value
Power on/off *1	Power on	PWR ON	-
	Power off	PWR OFF	-
	Get status	PWR?	-
		Return code	00: Standby 01: Normal operation 02: Warming up 03: Cooling down 04: Monitoring/Communication standby 05: Error standby 09: A/V standby
Operation	Key operation	KEY xx	Control panel 01: Power 03: Menu 04: Home 05: Esc 16: Enter 35: Up 36: Down 37: Left 38: Right 48: Source Search
Operation	Key operation	KEY xx	Remote control 3B: Power A1: Power on 6C: Power off 3C: Menu 30: Home 3D: Esc 49: Enter 58: Up 59: Down 5A: Left 5B: Right 4A: Auto 43: Computer 67: Source Search 4D: HDMI 8A: LAN 85: USB 47: Freeze 28: E-Zoom + 29: E-Zoom - 3E: A/V Mute 3F: Color Mode 20: Aspect 56: Volume + 57: Volume - 84: User 88: Default 8F: ID A0: Split
Adjusting projected image	V-Keystone setting/ Get value	VKEYSTONE xxx	-
		VKEYSTONE?	-
		Parameter/ Return code	0-255 INIT/INC/DEC (settings only)
	H-Keystone setting/ Get value	HKEYSTONE xxx	-
		HKEYSTONE?	-
		Parameter/ Return code	0-255 INIT/INC/DEC (settings only)
	Auto Keystone setting/Get value	AUTOKEYSTONE xxx	-
		AUTOKEYSTONE?	-
		Parameter/ Return code	ON/OFF INIT (settings only)
	Quick Corner direction setting/Get value (based on projection area)	QCS x1 x2 x3 x4 x5 x6 x7 x8	-
		Parameter	x1-x8: 0-9999 Specify in the order of upper left (x,y), upper right (x,y), bottom right (x,y), bottom left (x,y)
		QCS?	-
		Return code	0-9999 Position (x,y) for four points separated by line breaks

Item	Function	Command	Setting Value/Response Value
Adjusting projected image	Quick Corner vector setting	QCV x1 x2 x3 x4 x5 x6 x7 x8	-
		Parameter	x1-x8: -99 ~ 99 Specify in the order of upper left (x,y), upper right (x,y), bottom right (x,y), bottom left (x,y)
	Quick Corner direction movement	QCMV control direction movement	-
		Parameter	control: Control location 01: Upper left control 02: Upper right control 03: Bottom right control 04: Bottom left control INIT (settings only) direction: Direction 01: Up direction 02: Down direction 03: Left direction 04: Right direction movement: Amount of movement INC only (settings only)
	Sliding H-Keystone setting/Get value	SLIDEKEYSTONE xxx	-
		SLIDEKEYSTONE?	-
		Parameter/ Return code	00: Off 01: On INIT (settings only)
	Correction method setting/Get value	CORRECTMET x1	-
		CORRECTMET?	-
		Return code	01: H/V-Keystone 02: Quick Corner 03: Point Correction 06: Arc Correction
	Aspect setting/ Get value	ASPECT xx	-
		ASPECT?	-
		Parameter/ Return code	30: Auto 40: Full 50: Zoom (EB-L210W) 50: H-Zoom (EB-L265F/EB-L260F) 60: Native A0: V-Zoom (EB-L265F/EB-L260F) INIT (settings only) <Auto> only (get only) x1: Mode x2: Auto parameter (fixed at 30)

Item	Function	Command	Setting Value/Response Value
Adjusting projected image	Screen Type setting/ Get value	SCFORMAT mode param	-
		SCFORMAT? mode	-
		Parameter/ Return code	mode: Setting mode 01: Screen Type setting 02: Screen Position setting INIT(settings only) param: set value (mode=01) 01: 4:3 02: 16:9 03: 16:10 04: 16:6 (EB-L265F/EB-L260F) 05: 21:9 (EB-L265F/EB-L260F) param: set value (mode=02) C19 - 000 - 3E7
	Brightness and light source setting/ Get value	LUMINANCE xx	-
		LUMINANCE?	-
		Parameter/ Return code	00: Normal 01: Quiet 04: Extended 05: Custom INIT (settings only)
	Brightness level setting/Get value	LUMLEVEL level	-
		LUMLEVEL?	-
		Parameter/ Return code	0-255 INIT/INC/DEC (settings only)
	Maintain brightness setting/Get value	LUMCONST x1 [x2]	-(EB-L265F/EB-L260F)
		LUMCONST?	-(EB-L265F/EB-L260F)
		Parameter/ Return code	x1: Maintain Brightness 00: Off 01: On INIT (settings only) x2: Brightness Level 0-255
	Dimming rate setting/ Get value	DIMMING x1	- (EB-L265F)
		DIMMING?	- (EB-L265F)
		Parameter/ Return code	x1: Dimming rate 0-255
	Zoom setting/ Get value	ZOOM xxx	-
		ZOOM?	-
		Parameter/ Return code	E-Zoom (Zooming in/Zooming out) 0-255 INIT/INC/DEC (settings only)
	Over scan setting/Get value	OVSCAN xx	-
		OVSCAN?	-
		Parameter/ Return code	00: Off 02: 4% 04: 8% A0: Auto INIT (settings only)

Item	Function	Command	Setting Value/Response Value
Source change /Signal setting	Source change/get	SOURCE xx	-
		SOURCE?	-
		Parameter/ Return code	10: Computer1 20: Computer2 30: HDMI1 41: Video 51: USB Display 52: USB 53: LAN 56: Screen Mirroring1 58: Spotlight (EB-L265F/EB-L260F) 59: Screen Mirroring2 A0: HDMI2 F0: Cycle through all sources F1: Switch to Computer1, Computer2, USB Display, USB, LAN, Screen Mirroring1, Screen Mirroring2 F2: Switch to HDMI1, HDMI2, Video
	Resolution setting/Get value	RESOL x1	-
		RESOL?	-
		Parameter/ Return code	00: Auto F0: Wide F1: Normal INIT (settings only)
	Auto source search	AUTOSEARCH x1	-
		AUTOSEARCH?	-
		Parameter/ Return code	00: Off 01: On
Adjusting image quality	Brightness setting/Get value	BRIGHT xxx	-
		BRIGHT?	-
		Parameter/ Return code	0-255 INIT/INC/DEC (settings only)
	Contrast setting/ Get value	CONTRAST xxx	-
		CONTRAST?	-
		Parameter/ Return code	0-255 INIT/INC/DEC (settings only)
	Color saturation setting/Get value	DENSITY xxx	-
		DENSITY?	-
		Parameter/ Return code	0-255 INIT/INC/DEC (settings only)
	Color tint setting/Get value	TINT xxx	-
		TINT?	-
		Parameter/ Return code	0-255 INIT/INC/DEC (settings only)

Item	Function	Command	Setting Value/Response Value
Adjusting image quality	Sharpness setting/Get value	SHARP x1	-
		Parameter	x1: Adjustment value 0-255 INC/DEC/INIT
		SHARP?	-
		Return code	0-255
	Color temperature setting/Get value	CTEMP xxx	-
		CTEMP?	-
		Parameter/ Return code	Color Temp. 0-255 INIT/INC/DEC (settings only)
	GM correction setting/Get value	FCOLOR xxx	-
		FCOLOR?	-
		Parameter/ Return code	0-255 INIT/INC/DEC (settings only)
	Color mode setting/ Get value	CMODE xx	-
		CMODE?	-
		Parameter/ Return code	01: sRGB 04: Presentation 06: Dynamic 0F:DICOM SIM (EB-L265F/EB-L260F) 11: Blackboard 15: Cinema 1A: Multi-Projection (EB-L265F/EB-L260F) INIT (settings only)
	Horizontal display position setting/ Get value	HPOS xxx	-
		HPOS?	-
		Parameter/ Return code	0-255 INIT/INC/DEC (settings only)
	Vertical display position setting/ Get value	VPOS xxx	-
		VPOS?	-
		Parameter/ Return code	0-255 INIT/INC/DEC (settings only)
	Tracking setting/ Get value	TRACKING xxx	-
		TRACKING?	-
		Parameter/ Return code	0-255 INIT/INC/DEC (settings only)
	Sync. setting/ Get value	SYNC xxx	-
		SYNC?	-
		Parameter/ Return code	0-255 INIT/INC/DEC (settings only)

Item	Function	Command	Setting Value/Response Value
Adjusting image quality	Noise reduction setting/Get value	NRS xx	-
		Parameter	0-255 INIT/INC/DEC
		NRS?	-
		Return code	0-255
	MPEG noise reduction	MPEGNRS x1	-
		MPEGNRS?	-
		Parameter/ Return code	00: Off 01: Low 02: Normal 03: High
	Red offset setting/ Get value Green offset setting/ Get value Blue offset setting/Get value	OFFSETR xxx	-
		OFFSETR?	-
		Parameter/ Return code	0-255 INIT/INC/DEC (settings only)
		OFFSETG xxx	-
		OFFSETG?	-
		Parameter/ Return code	0-255 INIT/INC/DEC (settings only)
		OFFSETB xxx	-
		OFFSETB?	-
		Parameter/ Return code	0-255 INIT/INC/DEC (settings only)
	Red gain setting/ Get Value Green gain setting/ Get value Blue gain setting/Get value	GAINR xxx	-
		GAINR?	-
		Parameter/ Return code	0-255 INIT/INC/DEC (settings only)
		GAING xxx	-
		GAING?	-
		Parameter/ Return code	0-255 INIT/INC/DEC (settings only)
		GAINB xxx	-
		GAINB?	-
		Parameter/ Return code	0-255 INIT/INC/DEC (settings only)
	Gamma setting/ Get value	GAMMA xx	-
		GAMMA?	-
		Parameter/ Return code	20: Set 2 21: Set 1 22: Set 0 23: Set -1 24: Set -2 F0: Custom INIT (settings only)

Item	Function	Command	Setting Value/Response Value
Adjusting image quality	Gamma level setting/ Get value	GAMMALV x1 x2	-
		Parameter	x1: Tone 00-08: Tone 1 - Tone 9 x2: Adjustment value 0-255 INC/DEC
		GAMMALV? xx	-
		Parameter	Same as GAMMALV command x1 parameter
		Return code	0-255
	RGBCMY setting/ Get value	AXESADJ x1 x2 x3 x4	-
		Parameter	x1: Color 01: R 02: G 03: B 04: C 05: M 06: Y 90: ALL x2: Hue 0-255 x3: Saturation 0-255 x4: Brightness 0-255 INIT
		AXESADJ?	-
		Return code	0-255 Hue, Saturation, Brightness values for each color in the order of R, G, B, C, M, Y
	Multi screen color matching setting/Get value	MULSCR x1 x2 x3	- (EB-L265F/EB-L260F)
		Parameter	x1: Adjustment type 01: Display pattern 05: Color correction R 06: Color correction G 07: Color correction B 08: Color correction (RGB) INIT
			x2: Level 00: Off (x1=01 only) 01 - 08: Level 1 - Level 8 FF: whole
			x3: Adjustment value (Except for x1=01) 0-255 INIT/INC/DEC [x3]: type (Except for x1=01 & x2=00) 00: Tone pattern 01: Blend pattern
		MULSCR? xx	- (EB-L265F/EB-L260F)
		Parameter	x1: Adjustment type 01: Display pattern 05: Color correction R 06: Color correction G 07: Color correction B
		Return code	Adjustment value of each level or level value for selected adjustment type. Level: 00-08,FF Adjustment value: 000-255

Item	Function	Command	Setting Value/Response Value
Adjusting image quality	Get color adjustment method setting	CSEL?	-
		Return code	07: RGB/RGBCMY
	Image Preset Mode setting/Get value	IMGPRESET x1	-
		IMGPRESET?	-
		Parameter/ Return code	00: Off 01: Preset 1 02: Preset 2 03: Preset 3 04: Preset 4 05: Preset 5 INIT (settings only)
	Super-resolution: fine line adjust setting/ Get value	SHRF x1	-
		SHRF?	-
		Parameter/ Return code	0-255 INC/DEC/INIT
	Super-resolution: soft focus detail setting/Get value	SHRS x1	-
		SHRS?	-
		Parameter/ Return code	0-255 INC/DEC/INIT
	Detail enhancement: range setting/ Get value	DERANGE x1	-
		Parameter	0-255 INC/DEC/INIT
		DERANGE?	-
		Return code	0-255
	Detail enhancement: strength setting/ Get value	DESTRENGTH x1	-
		Parameter	0-255 INC/DEC/INIT
		DESTRENGTH?	-
		Return code	0-255
	Scene Adaptive Gamma Settings/ Acquire settings	SCENEGAMMA x1	-
		SCENEGAMMA?	-
		Parameter/ Return code	0-255 INC/DEC/INIT(settings only)

Item	Function	Command	Setting Value/Response Value
Audio	Volume setting/ Get value	VOL xxx	-
		VOL?	-
		Parameter/ Return code	0-255 INIT/INC/DEC (settings only)
	Audio output signal setting/Get value	AUDIO mode [source]	-
		Parameter/ Return code	Audio Output setting (when [source] is not specied) mode: Switching setting 00: Auto 01: Audio1 02: Audio2 03: Audio(L/R) INIT (settings only)
			HDMI Audio Output setting mode: Switching setting 00: Default (HDMI) 01: Audio1 02: Audio2 03: Audio(L/R) INIT (settings only) source: Target source 30: HDMI1 A0: HDMI2
		AUDIO? [source]	-
		Parameter	Same as source parameter in AUDIO command
		Return code	Same as mode parameter in AUDIO command
	Mic input level setting/Get value	MICLEVEL xxx	- (EB-L260F/EB-L210W)
		MICLEVEL?	- (EB-L260F/EB-L210W)
		Parameter/ Return code	0-255 INIT/INC/DEC (settings only)
	A/V output setting/ Get value	AVOUT x1	-
		AVOUT?	-
		Parameter/ Return code	00: While Projecting (NW Standby) 01: Always On (AV Standby) INIT (settings only)
Additional features	A/V mute ON, OFF/ Get status	MUTE x1	-
		MUTE?	-
		Parameter/ Return code	ON : A/V mute ON OFF: A/V mute OFF INIT (settings only)
	Freeze ON, OFF/ Get status	FREEZE xxx	-
		FREEZE?	-
		Parameter/ Return code	ON : Freeze ON OFF: Freeze OFF INIT (settings only)
	LCD alignment/ Get status	LCDALIGNMENT 00 x y updown leftright LCDALIGNMENT 04 updown leftright LCDALIGNMENT mode param	-(EB-L265F/EB-L260F)

Item	Function	Command	Setting Value/Response Value
Additional features	LCD alignment/ Get status	Parameter/ Return code	mode 00: Adjustment (Coordinate specification) 01: LCD alignment setting 02: Adjustment color setting 03: Pattern colorsetting 04: Adjustment (Whole) INIT x 0000~270F: Get X coordinate y 0000~270F: Get Y coordinate updown 9D~00~63: Adjustment vertical direction leftright 9D~00~63: Adjustment horizontal direction param • LCD alignment setting 00: LCD alignment correction OFF 01: LCD alignment correction ON • adjustment color setting (02:specified) 01: Red 02: Blue • pattern colorsetting (03:specified) 01: R/G/B 02: R/G 03: G/B
		LCDALIGNMENT? mode x y LCDALIGNMENT? mode	- (EB-L265F/EB-L260F)
		Parameter	00: Adjustment (Coordinate specification) 01: LCD alignment setting 02: Adjustment color setting 03: Pattern colorsetting x 0000~270F: Get X coordinate y 0000~270F: Get Y coordinate
		return code	Get adjustment value(00: specified) return vertical and horizontal value. • LCD alignment setting 00: LCD alignment correction OFF 01: LCD alignment correction ON • adjustment color setting(02:specified) 01: Red 02: Blue • pattern colorsetting(03:specified) 01: R/G/B 02: R/G 03: G/B

Item	Function	Command	Setting Value/Response Value
Conguration	Horizontal reverse setting/Get value	HREVERSE xxx	-
		HREVERSE?	-
		Parameter/ Return code	ON : Horizontal reverse OFF: Normal INIT (settings only)
	Upside down setting/ Get value	VREVERSE xxx	-
		VREVERSE?	-
		Parameter/ Return code	ON : Upside down OFF: Normal INIT (settings only)
	Reset all	INITALL2 x1	-
		Parameter/ Return code	x1: Target for reset
	Communication speed setting/ Get value*2	SPEED xx	-
		Parameter	00: 9600bps 01: 19200bps 02: 38400bps 03: 57600bps INIT
		SPEED?	-
		Return code	00: 9600bps 01: 19200bps 02: 38400bps 03: 57600bps
	Projector ID setting/ Get value	PROJID xx	-
		PROJID?	-
		Parameter/ Return code	00: Off 01-09: ID1-ID9 INIT (settings only)
	Illumination/Indicator setting	ILLUM xx	- (EB-L265F/EB-L260F)
		ILLUM?	- (EB-L265F/EB-L260F)
		Parameter/ Return code	00: Off 01: On INIT (settings only)
	Menu rotation setting	OSDROTATE x1	-
		OSDROTATE?	-
		Parameter/ Return code	00: Off 01: Right 90 degree 02: Left 90 degree
	Startup source/ Get value	STSOURCE mode	- (EB-L265F/EB-L260F)
		STSOURCE?	- (EB-L265F/EB-L260F)
		Parameter/ Return code	00: Last source 10: Computer1 30: HDMI1 41: Video 51: USB Display 52: USB 53: LAN 58: Spotlight A0: HDMI2

Item	Function	Command	Setting Value/Response Value
Conguration	Quick startup mode setting/Get	FASTBOOT x1	-
		FASTBOOT?	-
		Parameter/ Return code	00: Off 01: 20 min. 02: 60 min. 03: 90 min.
	Refresh mode setting/Get value	REFRESHTIME x1	-
		REFRESHTIME?	-
		Parameter/ Return code	01: 1 Hour 0D: 13 Hours 02: 2 Hours 0E: 14 Hours 03: 3 Hours 0F: 15 Hours 04: 4 Hours 10: 16 Hours 05: 5 Hours 11: 17 Hours 06: 6 Hours 12: 18 Hours 07: 7 Hours 13: 19 Hours 08: 8 Hours 14: 20 Hours 09: 9 Hours 15: 21 Hours 0A: 10 Hours 16: 22 Hours 0B: 11 Hours 17: 23 Hours 0C: 12 Hours 18: 24 Hours
	Refresh mode start	REFRESH [x1]	-
		Parameter	x1: ON OFF
	Refresh mode running message display setting/Get	REFRESHMSG x1	-
		REFRESHMSG?	-
		Parameter/ Return code	00: Messages off 01: Messages on
	Batch setup range setting/Get	BARANGE x1	-
		BARANGE?	-
		Parameter/ Return code	00: All 01: Limited
	Light source calibration start (run now)	LTCALB	-(EB-L265F/EB-L260F)
	Auto light source calibration setting/Get (run periodically)	AUTOLTCALB x1	-(EB-L265F/EB-L260F)
		AUTOLTCALB?	-(EB-L265F/EB-L260F)
		Parameter/ Return code	00: Off 01: On (Run periodically)
	Get last date and time of the light source calibration	LASTLTCALB?	-(EB-L265F/EB-L260F)
		Return code	yyyyMMddHHmm (Year/Month/Day/Time) 2000 - 2099: yyyy 01 - 12: MM 01 - 31: dd 00 - 23: HH 00 - 59: mm
	USB Power in Standby Settings/Acquire settings USB Power Settings/ Acquire settings	USBSUPPLY x1	-
		USBSUPPLY ?	-
		Parameter/ Return code	00: On when projecting 01: Always On

Item	Function	Command	Setting Value/Response Value
Conguration	Menu color setting/ Get value *3	MENUCOLOR x1	-
		MENUCOLOR?	-
		Parameter/ Return code	00: Black 01: White INIT (settings only)
	Transmitter Connection Guide Display setting/Get value	TRNSGUIDE x1	-
		TRNSGUIDE?	-
		Parameter/ Return code	00: Off (No display) 01: On (display) INIT (settings only)
	Transmitter Auto Power On setting/Get value	TRNSPWRON x1	-
		TRNSPWRON?	-
		Parameter/ Return code	00: Off 01: On INIT (settings only)
Home Screen	Home screen auto display	AUTOHOME x1	-
		AUTOHOME?	-
		Parameter/ Return code	00: Off (No display) 01: On (Display auto)
	Sort sources	HSORT x1	-
		HSORT?	-
		Parameter/ Return code	00: Off 01: On INIT (settings only)
Network	Get AMX DDDP BeaconMessage *2	AMX	-
		Return code	* Follow AMX specication. AMXB<-SDKClass=VideoProjector> <-GUID=EPSON_EMP001><-Revision=1.0.0>
	AMX DDDP IP BeaconMessage status setting/ Get status	AMXDDDP xx	-
		AMXDDDP?	-
		Parameter/ Return code	00: Stop sending BeaconMessage 01: Start sending BeaconMessage INIT (settings only)
	Wireless LAN power	WLPWR x1	-(NW supported)
		WLPWR?	-(NW supported)
		Parameter/ Return code	00: Off 01: Wireless LAN On
Screen Mirroring	Screen Mirroring (power) setting/Get	WDPWR x1	-
		WDPWR?	-
		Parameter/ Return code	00: Off 01: On
	Performance tuning setting/Get value	WDPERF x1	-
		WDPERF?	-
		Parameter/ Return code	01: 1 (Fine) 02: 2 03: 3 04: 4 (Fast)
	Reflect Screen Mirroring setting	WDRESET	-

Item	Function	Command	Setting Value/Response Value
Screen Mirroring	Interrupt Screen Mirroring setting/Get value	WDINTRPT x1	-
		WDINTRPT?	-
		Parameter/ Return code	00: Off 01: On
	Information bar setting/Get value	WDINFOBAR x1	-
		WDINFOBAR?	-
		Parameter/ Return code	00: Off 01: On
Information	Get light source usage hour	LAMP?	-
		Return code	LAMP=x1 x1: Light Source Hours
	Get usage hours	ONTIME?	-
		Return code	ONTIME=x1 x1: Operation Hours
	Get signal status	SIGNAL?	-
		Return code	00: No signal 01: With signal FF: Unsupported signal
	Get input source information	SOURCELIST?	-
		Return code	30 HDMI1 A0 HDMI2 10 Computer1 20 Computer2 41 Video 51 USB Display 52 USB 53 LAN 56 Screen Mirroring1 59 Screen Mirroring2 58 Spotlight (EB-L265F/EB-L260F)
	Get input source information (all source)	SOURCELISTA?	-
		Return code	30 HDMI1 A0 HDMI2 10 Computer1 20 Computer2 41 Video 51 USB Display 52 USB 53 LAN 56 Screen Mirroring1 59 Screen Mirroring2 58 Spotlight (EB-L265F/EB-L260F)
	Log save destination	LOGTO x1	-
		LOGTO?	-
		Parameter/ Return code	00: Internal Memory 01: USB and Internal Memory

*1 Available even when the password protection is activated.
*2 Only available when you transmit commands using the RS-232C cable.