

A320 Family — Maintenance Manual

FlySmart reference document · Revision C · Effectivity: all

ATA 32 Landing Gear

32-11 Main landing gear — wheel and axle

For the A320 main landing gear, the axle-nut torque is 1,200–1,350 N·m, tightened in the documented sequence using the approved torque adapter. Confirm the locking device is correctly engaged after torquing.

Tyre servicing: inflate to the placard pressure for the wheel. The AMM gives the acceptable in-service range and the limits below which the tyre must be re-inflated or removed from service.

Item	Value
Axle-nut torque	1,200–1,350 N·m
Tyre pressure (in-service range)	per placard ± tolerance

ATA 29 Hydraulic Power

29-31 Accumulator

With the system depressurised, read the accumulator gauge. The nitrogen pre-charge should sit within the band on the placard for the recorded temperature; recharge if it is below limits. Do not exceed the maximum charging pressure.

Caution: relieve all residual pressure before disconnecting any hydraulic line.

ATA 24 Electrical Power

24-20 AC generation

On a single generator loss the bus tie contactor closes automatically so the remaining generator feeds both main AC buses; non-essential loads may shed depending on available capacity.

24-23 Window heat

A failed window heat controller or sensor trips the WINDSHIELD HEAT fault. Reset the related circuit breaker per the AMM and, if the fault recurs, replace the controller.

ATA 27 Flight Controls

27-51 Flaps

The flap control logic detects asymmetry between the two sides and locks the surfaces in place, annunciating a FLAPS fault. Reset is per the QRH; do not attempt to drive the flaps with the fault latched.

ATA 30 Ice and Rain Protection

30-31 Probe heat

With PROBE HEAT selected ON, confirm the probes warm and no PITOT HEAT fault is annunciated; check the heating current on the maintenance page before release to service.

A320 Family — Maintenance Manual (MOCK). For training/demonstration only. Not for operational use.