

A350 — Systems Manual

FlySmart reference document · Revision B

ATA 49 Auxiliary Power Unit

49-10 APU start procedure

Confirm the APU fire test is satisfactory. Then:

1. Move the APU MASTER SW to ON.
2. After the AVAIL light, press APU START.
3. The ECB runs the automatic start sequence and stabilises the APU.

Note: do not select the bleed until the APU is at governed speed.

ATA 32 Landing Gear — Inspection

32-42 Brake unit wear check

With the brakes applied, the wear indicator pin protrusion is measured. If the pin is flush with or below the housing limit, the brake unit must be replaced before further flight.

A350 — Systems Manual (MOCK). For training/demonstration only.