

AIRCRAFT MAINTENANCE MANUAL — MOCK / TRAINING

B777 — Maintenance Manual

FlySmart reference document · Revision E

ATA 28 Fuel

28-22 Crossfeed

The crossfeed valve allows fuel to flow between the left and right manifolds. It is commanded from the fuel panel; when open, either engine can be fed from any tank. Verify torque values against the current AMM revision before any line work.

ATA 79 Engine Oil

79-00 Oil consumption monitoring

Consumption is tracked per engine over flight hours. The AMM specifies the maximum quarts/hour before maintenance action is required; trend the values and investigate any step change.

ATA 31 Indicating / Recording

31-60 Display system

The display units present systems synoptics and maintenance pages. Confirm no maintenance messages remain latched before returning the aircraft to service.

B777 — Maintenance Manual (MOCK). For training/demonstration only.