

Filename: cisco-ccna200301-1-8-1-ip_addressing_ipv6_configuration

ShowName: Cisco CCNA (200-301)

Topic: 1.0 Networking Fundamentals

EpisodeName: IP Addressing: IPv6 configuration

Description: In this episode, Aubri and Ronnie show how to configure IPv6 addresses on Cisco devices as well as a Windows OS.

IP Addressing: IPv6 Configuration

1.8 Configure and verify IPv6 addressing and prefix

```
Code starts
NYEDGE1
NYEDGE1>enable
NYEDGE1#
NYEDGE1#show ip interface brief
NYEDGE1#configure terminal
NYEDGE1#ipv6 unicast-routing
NYEDGE1(config)#interface gigabitethernet 0/0
NYEDGE1(config-if)#ipv6 address 2001:C0A8:10::1/64
NYEDGE1(config-if)#shutdown
NYEDGE1(config-if)#no shutdown
NYEDGE1(config-if)#end
NYEDGE1#show ip interface brief [note the the result]
NYEDGE1#show ipv6 interface brief [note the result--two addresses]
NYEDGE1#show ipv6 int gigabitethernet 0/0 [note the result--group addresses
too]
NYEDGE1#configure terminal
NYEDGE1(config)#interface gigabitethernet 0/1
NYEDGE1(config-if)#ipv6 address 2001:AC:E:0::/64 eui-64
NYEDGE1(config-if)#do show ipv6 interface brief
NYEDGE1(config-if)#do show ip interface gigabitethernet 0/1
NYEDGE1(config-if)#ipv6 address autoconfig
Code ends
```

Windows OS

- Control Panel > Network and Sharing Center > Network Connection > Lab_Nic > Properties >
- note that `Internet Protocol Version 6 (TCP/IPv6)` is not enabled, check mark to enable
- Click properties to see configuration.