Acme Bulk Systems

Emulsion Pump EP-40

Service Manual

Revision C, March 2026

CONFIDENTIAL. For authorised service staff only.

Contents

1 Safety notes 3

2 Calibration 3

3 Maintenance 4

Legal notice

Copyright 2026 Acme Bulk Systems. All rights reserved. No part of this manual may be reproduced without written permission. Acme accepts no liability for damage caused by service work that does not follow this manual.

1 Safety notes

Isolate the pump at the MMU control panel and bleed the line pressure before any service work.

2 Calibration

Calibrate the flow meter every 250 operating hours, and always after replacing the stator.

1. Flush the line with water until no emulsion comes out.
2. Run water at 120 kg/min for 2 minutes into the calibration tank.
3. Weigh the tank. The weighed amount must be within 2% of the meter reading.
4. If it is not, enter the new K-factor in the MMU controller under Settings > Flow.
   The factory K-factor is 0.982.

WARNING: Never calibrate with emulsion in the line. Emulsion in the calibration tank must be disposed of as explosive waste.

3 Maintenance

The auger slew bearing and the pump need regular service:

Part	Interval	Note
Auger slew bearing	weekly	6 strokes of EP2 grease
Pump stator	1,500 hours	replace; then calibrate
Inlet strainer	daily	clean at the end of shift

Torque the pump mounting bolts to 210 Nm after every stator change.

Record every service in the MMU logbook.