

TRIDENT R1 Pro

All yellow rectangle positions indicate where jumper caps need to be inserted. The position of jumper caps need to be adjusted if you change to use other type stepper drivers.



FORMBOT

