SPIKE Prime hub lights

Check which button, which color and whether the light flashes. A letter on the display is separate program output.

Center button — Green, steady

Hub is on, its OS is compatible with SPIKE, and battery is at least 20%. Still check the correct hub connection, program and clear lane before running.

Center button — White, steady

Hub OS needs an update to work with SPIKE. Ask the mentor to follow the app's update instructions.

Center button — Orange, flashing

Battery is below 20%. Tell the mentor and connect the USB cable to charge.

Center button — Red, flashing

Extended load. Stop, tell the mentor, switch the hub off and let it cool for 15 minutes.

Center button — Purple, flashing

Firmware update is in progress. Let the update finish and follow the app instructions.

Connection button — Blue, flashing

Waiting for a Bluetooth connection. Check the intended hub name with the mentor.

Connection button — Blue, steady

Connected by Bluetooth. This is not a battery-level indication.

LEGO Education reference supplied October 25, 2026. Full source and original image: 06_References/SPIKE_Hub_Color_Guide.md.