



DPUMERedlabLS

Interface for external measurement instruments of type Meilhaus Redlab 1208 LS. For other measurement instruments of the Redlab family the use of DPUMERedlab is recommended.

1. Static parameters:

<i>BoardNumber</i>	Number of the measurement instrument as shown by InstaCAL. (default: 0 = first connected instrument)
<i>Voltage</i>	Specific value for the measurement range of the analog inputs. Possible values are: 0 -5V .. +5V 1 (default) -10V .. +10V 4 -1V .. +1V
<i>Channel</i>	Number of the analog input to poll. (default: 0 = port CH0 of the card)

2. Outputs:

<i>Out</i>	Voltage (V) of the selected analog input at the measurement instrument.
------------	---

3. Functional principle:

DPUMERedlabLS supplies an interface for the USB measurement instrument RedLab 1208 LS from Meilhaus.

Several Redlab devices may be connected to a PC at the same time. Before use the device has to be configured and calibrated by the enclosed software InstaCAL. During this process every device gets a unique number (0,1,2,...). This number has to be set as parameter *BoardNumber* (default: 0) for the DPU.

Only one analog input of the device will be polled, but which one can be chosen by setting the parameter *Channel*.

Analog inputs are polled with the same frequency as is DPUMERedlabLS running. However one reading cycle takes at least 16 ms, meaning the maximum frequency of DPUMERedlabLS is 60 Hz.

For faster devices (for example RedLab 1208 FS) DPUMERedlab is an alternative which supports more channels and higher frequencies.