



DPUMOVClient

Moves pedestrians synchronously with the simulation on the corresponding server, which is implemented in DPUMOV. The DPUs are connected via a local area network.

1. Inputs:

SimTime Current simulation time from the server

2. Static parameters:

NumPersons Maximum number of simulated pedestrians in the “normal” category. Even if a module requests more than *NumPersons* pedestrians, they are not simulated. The same value as for DPUMOV should be set.

NumSpecialPersons Maximum number of simulated pedestrians in the “special” category. Even if a module requests more than *NumSpecialPersons* pedestrians, they are not simulated. The same value as for DPUMOV should be set.

ServerIP Computer name, alias name, or IP address of the server on which DPUMOV is running. It provides the simulation data.

ReadyToStartDelay Waiting time (in milliseconds) in *ReadyToStart*. Normally, it is chosen randomly; however, if a lot of clients (more than 10) are present, a unique time should be set each of them.

InformTRF Try to submit information on pedestrians to TRFX?
Default value = *true*, but this will only work on the computer where DPUTRFX is running.

ODB Boolean value: Insert pedestrians into the object database ODB?
Default: *false*

3. Dependencies to other DPUs:

DPUMOVClient must be run together with DPUSCNX. A server computer on which DPUMOV is running is also required.

The complete setup is described in DPUMOV's documentation.