



DPUSGEDistortionBezier5ExtSaveParams

Saves the distortion parameters of the currently running DPUSGEDistortionBezier5Ext to a configuration file that can be loaded by SILAB.

1. Dynamic parameters:

Par Changes to this parameter are immediately applied, even while the simulation is running.

2. Static parameters:

Server Computer name of the machine where the associated DPUSGEDistortionBezier5Ext is running. Default: "localhost".

Port TCP port number of the DPUSGEDistortionBezier5Ext instance that this DPU is connected to. The default value normally doesn't need to be changed, unless two in-stances of DPUSGEDistortionBezier5Ext are running on the same computer.

FilePath Path where the configuration file is saved, below the SILAB installation folder.
Default: "lib\configurations\system\"

FileName Name of the saved configuration file, without extension. The extension ".inc" is automatically appended to the file name.
Default: "SYSSGEDistortion"

DistInstanceName Instance name of the DPU (possibly including the computer name) that is configured by this file. Must include a trailing dot.
Example: "M2VISF1.SGEDist." configures the DPU called SGEDist on the machine M2VISF1.

SaveDataTime Time interval in milliseconds. While the simulation is running, the configuration file is saved repeatedly after this interval has passed.

3. Outputs:

LastSaveTime Simulation time (in milliseconds) when the configuration was last saved.

4. Dependencies to other DPUs:

Connects to an instance of **DPUSGEDistortionBezier5Ext** that is running on an-other machine.



5. Functional principle:

While the simulation is running, repeatedly saves the configuration of an instance of DPUSGEDistortionBezier5Ext that is running on a remote computer. The configuration is saved in SILAB configuration format, so that it can be reloaded when the simulation is started again. Because the configuration is read on the operator, this DPU should always be configured to run on the OPERATOR machine.

To do so, the created configuration file must be included in the SILAB base configuration, for example, within SYSSGEPARAMS.inc.

6. Example:

This DPU works well using the following script:

```
# Window to configure distortion, displayed on the operator
DPUSGEDistortionBezierParamsExt SGEdistParams
{
    Computer = {OPERATOR};
    Index = 0;
    ViewServer01 = "M2VISF1";

    ViewW01 = 1920;
    ViewH01 = 1200;

    ViewX01 = -960;
    ViewY01 = 0;

    WindowX = 0;
    WindowW = 1920;
    WindowH = 1024;
    Views = 1;
};

# DPU saving distortion parameters, running on the operator
DPUSGEDistortionBezier5ExtSaveParams SaveParamsFront
{
    Computer = {OPERATOR};
    Index = 20;
    Server = "M2VISF1";
    DistInstanceName = "M2VISF1.SGEDist.";
    FileName = "DistFront";
    SaveDataTime = 5000;
};

# DPU for actual distortion, running on the visualization machines
DPUSGEDistortionBezier5Ext SGEdist
```



SILAB DRIVING SIMULATION

version Version 7.1 documentation

```
{
    Computer = {VISF};
    Index = 40;
    ResolutionX = 1920;
    ResolutionY = 1200;
    SubdivX = 21;
    SubdivY = 21;
    # Use an equal distribution of control points initially
    Points = (
        0, 0,      480, 0,      960, 0,      1440, 0,      1920, 0,
        0, 300,    480, 300,    960, 300,    1440, 300,    1920, 300,
        0, 600,    480, 600,    960, 600,    1440, 600,    1920, 600,
        0, 900,    480, 900,    960, 900,    1440, 900,    1920, 900,
        0, 1200,   480, 1200,   960, 1200,   1440, 1200,   1920, 1200
    );
};

# Load the configuration files saved by the SaveParamsFront instance above
#includeif system/DistFront.inc
```