



DPUSNDXListener

Sets the position of the listener (that is the test operator) for the sound simulation SNDX.

1. Inputs:

<i>X, Y, Z</i>	Position of the listener in SILAB world coordinates. Normally connected with the outputs X, Y, Z of the vehicle dynamics.
<i>vX, vY, vZ</i>	Velocity of the listener along every axis of the SILAB world coordinate system.
<i>yaw</i>	Yaw angle of the listener
<i>pitch</i>	Pitch angle of the listener
<i>roll</i>	Roll angle of the listener
<i>DopplerEffectFactor</i>	Intensity of the Doppler effect. 1 (default) equals to the effect in air.

2. Dependencies to other DPUs:

Other DPUs of the sound simulation SNDX (for example DPUSNDXWavPlayer or DPUTRFSNDX) need the position, direction of travel and speed of the listener to position sound sources correctly. These are made available for other DPUs of the sound simulation by the DPUSNDXListener.

3. Example:

This DPU works well using the following script:

```
DPUSNDXListener SNDXListener
{
    Computer= {SNDX};
    Index=123;
};
Connections=
{
    VDyn.v<->SNDXListener.v,
    VDyn.yaw<->SNDXListener.yaw,
    VDyn.pitch<->SNDXListener.pitch,
    VDyn.roll<->SNDXListener.roll,
    VDyn.X<->SNDXListener.X,
    VDyn.Y<->SNDXListener.Y,
    SCNX.ZOut<->SNDXListener.Z
};
```



SILAB DRIVING SIMULATION

version Version 7.1 documentation

Note: `DESIRED_SOUND_COMPUTER` should be changed into the alias or address of the computer responsible for the sound simulation.

As always, make sure that the Index is set appropriately.

Most of our connections stem from *VDyn*, our vehicle dynamics DPU.