



## DPUTRFClient

Moves road users synchronously with the simulation on the corresponding server, which is implemented in DPUTRFX. The DPUs are connected via a local area network.

### 1. Inputs:

*Trafficdata*

Current simulation time from the server

*ThreePointHeight*

The variable *ThreePointHeight* specifies the method for calculating the orientation of simulated vehicles due to different heights of tire contact points.

*ThreePointHeight* = 0:

The orientation of a vehicle is defined by the height of the center of gravity of the vehicle. The height of the center of gravity is defined by the height of the nearest point to the road .

*ThreePointHeight* = 1 (the default value):

The orientation of a vehicle is defined by two points of the front axle and one point of the rear axle.

The height of the road shoulder and the landscape is also taken into account.

This results in much more realistic driving over sidewalks and on the shoulder of a road.

The parameter has to be specified for the *DPUTRF* as well as for the *DPUTRFClient*. In both DPUs the same value has to be set.

### 2. Dependencies to other DPUs:

SILAB's traffic simulation consists of the DPUs DPUTRFX, DPUTRFClient and DPUTRFSGE.

These DPUs depend on other DPUs as follows:

| DPU          | Depends on                           |
|--------------|--------------------------------------|
| DPUTRFX      | DPUSCN                               |
| DPUTRFClient | DPUSCN + Connected to DPUTRFX        |
| DPUTRFSGE    | DPUTRFX / DPUTRFClient + DPUSGEWorld |

For each dependency, please make sure that a higher Index is assigned to the dependent DPU than to its dependencies.



# SILAB DRIVING SIMULATION

version Version 7.1 documentation

Usually, DPUTRFX is started on the main simulation computer. The graphics computers run DPUTRF-Client and DPUTRFSGE each.

For single-computer setups, only DPUTRFX and DPUTRFSGE are required.