



DPUTRFFlowpoint

The **DPUTRFFlowpoint** sends commands to vehicles during simulation.

The commands are specified by strings and can be generated while the simulation is running. The commands can be triggered by the operator or any simulation variable.

1. Dynamic parameters:

<i>UserID</i>	Only vehicles with the specified UserID (Index) is addressed
<i>ID</i>	Only vehicles with the specified ID (Index) is addressed
<i>Flowpoint[1..NFlowpoints]</i>	Flowpoint string with different commands.
<i>Send</i>	If $Send \neq 0$: The command <i>Flowpoint[Send]</i> is send to the vehicle with the corresponding <i>ID</i> or (in case $ID = 0$) to the vehicle with the corresponding <i>UserID</i> .

2. Static parameters:

<i>NFlowpoints</i>	Number of input and output variables that will be created (see below).
--------------------	--

3. Functional principle:

The DPU can be used in order to send commands to simulated vehicles during a simulation. Simulated vehicles can be addressed by their UserID as well as their IDs. In combination with java script files and iTRF this powerful tool can be used to control simulated vehicles depending on the whole situation at runtime.

4. Dependencies on other DPUs:

DPUTRFFlowpoint must run on a computer together with **DPUTRF(X)**. The DPU *Index* entry for **DPUTRFFlowpoint** must be higher than the *Index* entry for **DPUTRF(X)**.