



DPUTRFTarget

1. Dynamic parameters:

<i>Radius</i>	Radius around the EGO-vehicle
<i>FilterUserDataIDX</i>	Only vehicles with the specified UserData (Index)
<i>FilterUserDataValue</i>	Only vehicles with the specified UserData (Index)

2. Outputs:

<i>v[01...10]</i>	Speed [m/s]
<i>ax[01...10]</i>	Acceleration [m/s ²]
<i>X[01...10]</i>	X-world coordinate reference point [m]
<i>Y[01...10]</i>	Y-world coordinate reference point [m]
<i>Z[01...10]</i>	Z-world coordinate reference point [m]
<i>dX[01...10]</i>	Distance X direction EGO-vehicle / vehicle [m]
<i>dY[01...10]</i>	Distance Y direction EGO-vehicle / vehicle [m]
<i>dEX[01...10]</i>	Distance in X-direction between EGO vehicle and vehicle in the relative coordinate system with respect to the EGO vehicle [m]
<i>dEY[01...10]</i>	Distance in Y-direction between EGO vehicle and vehicle in the relative coordinate system with respect to the EGO vehicle.
<i>yaw[01...10]</i>	Yaw angle [rad]
<i>psi[01...10]</i>	Difference of yaw angle – tangential angle [rad]
<i>roll[01...10]</i>	Roll angle [rad]
<i>pitch[01...10]</i>	Pitch angle [rad]
<i>ID[01...10]</i>	ID of vehicle
<i>UserID[01...10]</i>	UserID of vehicle
<i>Type[01...10]</i>	Type if vehicle (see ODB type 2)
<i>Privilege[01...10]</i>	Special signal status
<i>LaneInfo[01...10]</i>	Lane information (lane number)
<i>NodeInfo[01...10]</i>	Template information about the node
<i>NodeInstanceInfo[01...10]</i>	Instance counter for the node
<i>ModuleInfo[01...10]</i>	Template information for the module
<i>ModuleInstanceInfo[01...10]</i>	Instance counter for the module
<i>SInfo[01...10]</i>	Propagated S info for the lane (only in Courses) [m]
<i>SLaneInfo[01...10]</i>	S info for the lane (Areas + Course) [m]
<i>TInfo[01...10]</i>	Lane shift of the vehicle
<i>FrontLight[01...10]</i>	Front light status
<i>FrontLightU[1...10]</i>	???
<i>RearLight[01...10]</i>	Rear light status
<i>RightIndicator[01...10]</i>	Right indicator on
<i>LeftIndicator[01...10]</i>	Left indicator on
<i>BrakeLight[01...10]</i>	Brake light status
<i>BlueLight[01...10]</i>	Blue light status



SILAB DRIVING SIMULATION

version Version 7.1 documentation

<i>DimensionFront[01...10]</i>	Distance reference point to the front vehicle edge [m]
<i>DimensionRear[01...10]</i>	Distance reference point to the rear vehicle edge [m]
<i>DimensionWidth[01...10]</i>	Width of the vehicle [m]
<i>DimensionLeft[01...10]</i>	Distance reference point to left vehicle edge [m]
<i>DimensionRight[01...10]</i>	Distance reference point to right vehicle edge [m]

3. Dependencies on other DPUs:

DPUTRFTarget must run on a computer together with **DPUTRF(X)**. The *DPU Index* entry for **DPUTRF-Target** must be higher than the *Index* entry for **DPUTRF(X)**.