



DPUTTSSCNX

Processes events from the databasis SCNX and creates speech output with the use of DPUTTSCClient or DPUTTSCClientSCNX.

1. Dynamic parameters:

<i>EnableTTS</i>	Should TTS events be processed at the moment? (0/1) default: 1
<i>EnableNav</i>	Should navigation events be processed at the moment? (0/1) default: 0
<i>NavText[1..10]</i>	Text for speech output when a navigation event with the corresponding value is found. For example: <i>NavText2</i> will be triggered by the event (<i>Nav</i> , <i>Image</i> , 2).

2. Static parameters:

<i>TTSTFamily</i>	family name for events for direct speech output („text-to-speech“, TTS). default: <i>TTS</i>
<i>NavFamily</i>	family name for events for navigation advices. default: <i>Nav</i>
<i>NavSound</i>	Filename of the sound file that will be played before the navigation advice. The file must exist on the TTSServer computer and will be searched below the directory <code>\SILAB\lib\sounds</code> as well as in the project folder.
<i>ManagedCursorID</i>	ID of the SCNX databasis cursor that is used to „pick up“ events. default: 0 that is the primary cursor which position is defined by the variables X, Y and Z of DPUSCNX.

3. Dependencies:

DPUSCNX must be running on the same computer. The parameter *Index* of **DPUSCNX** must be lower than the parameter *Index* of **DPUTTSSCNX**.

Additionally either **DPUTTSCClient** or **DPUTTSCClientSNDX** must be running on the same computer and have a lower *Index* value than **DPUTTSSCNX**.

```
DPUTTSCClientSNDX TTSCClient
{
    Computer = {TTSC};
    Index = 50;
};
```



SILAB DRIVING SIMULATION

version Version 7.1 documentation

DPUSCNX SCNX

```
{  
    Computer = {TTSC};  
    Index = 20;  
};
```

DPUTTSSCNX TTSSCNX

```
{  
    Computer = {TTSC};  
    Index = 51;  
};
```