

深度学习模型部署流程

汇报人: 张文剑






模型部署

简单来说,深度学习模型的部署就是指训练好的模型在特定环境中运行的过程。相比于软件工 程定义中应用软件的部署,深度学习模型的部署会有以下一些难点:

- 模型运行所需的环境难以配置。深度学习模型通常是由PyTorch、TensorFlow框架编写,由于框 架规模和依赖环境的限制,这些**框架本身并不适合在手机、开发板等边缘计算环境中**安装;
- 深度学习模型的网络**结构一般较为庞大**,需要大量的算力才能满足一些实时运行的需求,模型 的运行效率要求较高:

在工业界中模型部署有了一条流行的流水线:





ONNX计算图


ONNX(**Open Neural Network Exchange**) 2017年由**微软和Facebook**联合推出的开源项目,旨在 为深度学习模型提供一个**跨平台、跨框架的标准化表示**。它能够标准地描述深度学习**模型的计算图**, 允许AI开发人员将训练好的模型从一个深度学习框架迁移到另一个框架,保证模型的跨框架互操作 性。

因此, ONNX 被当成了深度学习框架到推理引擎的桥梁, 为高效地进行跨框架的模型迁移与部 署提供了一个解决方案。

```
torch.onnx.export(
  model,
                  #模型实例
  img, #模型输入数据,可以是一个元组或列表
   "/data/zhangwj/lmf-output/onnx/model.onnx", # 输出文件路径
  input names=["image"], # 输入节点名称,
  output_names=["output"], # 输出节点名称
  opset_version=11, # 使用 ONNX opset 11
  verbose=True, # 打印详细的转换信息
  # export params=True
```







Netron工具可视化计算图:


```
| Conv | Sigmoid | Mul | values | 5×3×640×640 | B ⟨32⟩ | 5×32×640×640 |
```


```
# Create the input tensor
input_tensor = helper.make_tensor_value_info('input', TensorProto.FLOAT, [5, 3, 640, 640])
# Create the weight and bias tensors for the convolution layer
weights_data = np.random.randn(*conv_weight_shape).astype(np.float32)
bias_data = np.random.randn(*conv_bias_shape).astype(np.float32)
weights_tensor = helper.make_tensor('weights', input_dtype, [32, 3, 3, 3], weights_data)
bias_tensor = helper.make_tensor('bias', input_dtype, [32], bias_data)
# Create the convolution node
conv_node = helper.make_node(
    'Conv', # onnx算子
   inputs=['input', 'weights', 'bias'], # 输入向量名称
   outputs=['conv_output'], # 输出向量名称
   kernel_shape=[3, 3],
   pads=[1, 1, 1, 1],
   strides=[1, 1]
# Create the sigmoid node
sigmoid_node = helper.make_node(
    'Sigmoid',
   inputs=['conv_output'],
   outputs=['sigmoid_output']
# Create the multiplication node
mul_node = helper.make_node(
    'Mul',
   inputs=['conv_output', 'sigmoid_output'],
   outputs=['values']
# Create the graph
graph_def = helper.make_graph(
   [conv_node, sigmoid_node, mul_node], # 节点名称
    'example_model', # 计算图名称
   [input_tensor], # 输入向量
   ['values'],
   initializer=[weights_tensor, bias_tensor]
model_onnx = helper.make_model(graph_def, producer_name='onnx-example')
onnx.checker.check_model(model_onnx) # 检测模型的准确性
# Save the model to a file
onnx.save(model_onnx, 'example.onnx')
```



ONNX计算图-yolov5s

模型结构图







转换ONNX文件

```
Upsample 1r feat to hr feat
inp = F.grid sample(
    feat, coords.flip(-1).unsqueeze(1),
    mode='nearest', align corners=False)[:, :, 0, :] \
    .permute(0, 2, 1)
```

```
torch.onnx.export(
 File "/home/zhangwenjian/miniconda3/envs/test/lib/python3.8/site-packages/torch/onnx/utils.py", line 506, in export
 File "/home/zhangwenjian/miniconda3/envs/test/lib/python3.8/site-packages/torch/onnx/utils.py", line 1548, in export
    graph, params dict, torch out = model to graph(
 File "/home/zhangwenjian/miniconda3/envs/test/lib/python3.8/site-packages/torch/onnx/utils.py", line 1117, in _model_to_graph
    graph = optimize graph(
 File "/home/zhangwenjian/miniconda3/envs/test/lib/python3.8/site-packages/torch/onnx/utils.py", line 665, in optimize graph
    graph = C. jit pass onnx(graph, operator export type)
 File "/home/zhangwenjian/miniconda3/envs/test/lib/python3.8/site-packages/torch/onnx/utils.py", line 1901, in run symbolic function
    raise errors.UnsupportedOperatorError(
torch.onnx.errors.UnsupportedOperatorError: Exporting the operator 'aten::grid sampler' to ONNX opset version 11 is not supported. Support for this operator was added in version 16, try exporting with this ve
```

调用export()方法时转 ONNX 时最容易出现的问题就是**算子不兼容**了,转换普通的 torch.nn.Module 模型时,PyTorch 会用跟踪法执行前向推理,把遇到的算子整合成计算图,同时会把遇到的每个算子翻译成 ONNX 中定义的算子。

- 该算子可以一对一地翻译成一个 ONNX 算子;
- 该算子在 ONNX 中没有直接对应的算子,会翻译成一至多个 ONNX 算子;
- 该算子没有定义翻译成 ONNX 的规则,报错。



主要特点

处理器内核 8G

- 四核 ARM Cortex A55@1.4GHz
 - 32KB I-Cache, 32KB D-Cache /512KB L3 cache
 - 支持Neon加速, 集成FPU处理单元
- 内置 32bit MCU@500MHz
 - 32KB I-Cache, 32KB D-Cache /64KB TCM
- 图像分析加速引擎, 高达 10.4Tops@INT8 算力
 - 双内核异构引擎
 - 引擎 1 支持 4.8Tops 算力,支持 INT4/INT8/FP16
 - 引擎 2 支持 5.6Tops 算力, 支持 INT8/INT16

数字图像处理 (ISP)

- ISP 支持分时复用处理多路 sensor 输入视频
- 支持 3A (AE/AWB/AF) 功能, 3A 的控制用 户可调节
- 支持去固定模式噪声 (FPN)
- 支持坏点校正、镜头阴影校正;
- 最高支持三帧 WDR 及 Advanced Local Tone Mapping
- 支持多级 3D 去噪、图像边缘增强、去雾、动态对比度增强等处理功能
- 支持 3D-LUT 色彩调节
- 支持镜头畸变校正,支持鱼眼矫正
- 支持 6-DoF 数字防抖及 Rolling-Shutter 校正
- 支持图像 Mirror、Flip、90 度/270 度旋转
- 提供 PC 端 ISP 调节工具

内置AI ISP功能





AI ISP卓越的全天候图像效果


- 超感光降噪,12dB信噪比提升
- 超级宽动态,基于场景感知的极限收光;快速 准确跟踪复杂光线下的成像效果

- Hi3403V100是一颗面向监控市场推出的专业 Ultra-HD Smart IP Camera SOC,该芯片最高支持四路 sensor输入,支持最高4K60的ISP图像处理能力;
- Hi3403V100集成了高效的神经网络推理单元,最高10TOPS INT8,并支持业界主流的神经网络框架。









SoC激活的主要步骤

1.安装交叉编译工具

2.编译SDK


3.烧录固件

SoC主体

目前Hi3403V100网上经销商售价大概是4000









om文件

".om"文件是Huawei Ascend AI 处理器 (hisilicon) 的模型文件格式,全称为"offline model"。Huawei Ascend AI是一种专门用于人工智能计算的芯片,旨在提高 AI 计算效率和性能。因此, om文件用于在 Ascend AI 推理引擎上部署和运行的模型文件。

为了适配这种芯片, Huawei 开发了一种名为 MindSpore 的 AI 框架,可以将训练好的模型转换为 ".om"格式的模型文件,并在 Ascend AI 处理器上进行高效的推理计算。

转换方式: SoC开发板中SDK文档中带的ATC模型转换工具

名称	修改日期
Ascend-cann-toolkit_5.20.t6.2.b060_linux-x86_64.run	2022/12/26 11:43
CANN-amct-5.20.t6.2.b060-ubuntu18.04.x86_64.tar.gz	2022/12/26 11:43


每一种型号的开发板自带的ATC转换工具不同,适应不同开发板的特点。





Caffe模型转换om文件

Profiling 性能分析 工具用于采集和分析运 行在 SOC 上的推理业 务(应用或算子) 各个 运行阶段的关键性能指 标,用户可根据输出的 性能数据针对关键性能 瓶颈做出优化以实现产 品的极致性能。





om模型转换

atc --model=lmliif.onnx --framework=5 --output=lmliif --soc_version="OPTG" --output type=FP32 --insert op conf=./op.cfg

▼ 5 算子规格说明	82
▶ □ 5.1 Caffe框架算子规格	82
▶ □ 5.2 Onnx框架算子规格	102

(atc) wenjian@qihaoran-server:~/Ascend/ascend-toolkit/svp latest/x86 64-linux\$ atc --model=/data/zhangwi/lmf-output/LMF0113-v11.onnx --framework=5 --output=LMF0113-v11 --soc version="SS928V100" --output type=FP32 Mapper Version 1.0.0.0 B010 (PICO 1.0) 221230032147ce09523(CPU) (INST 2.0.9) framework:5 model:/data/zhangwj/lmf-output/LMF0113-v11.onnx output:LMF0113-v11 output type:FP32 soc version:SS928V100 begin net parsing... ERROR][LoadLibrary][46] ERROR: dlopen libpath[libsvp custom.so] failed [ERROR][ParseLayer][179] Unknown Op[ScatterND]. Known Ops[Abs, AbsVal, Acos, Acosh, Add, And, ArgMax, ArgMin, Asin, Atanh, AveragePool, BILSTM, BIRNN, BNLL, BatchNorm, BatchNorm, BatchNormalization, Bias, BinaryMath, Bit hift, CReLU, Ceil, Celu, Clip, Cmp, Compress, Concat, CondEnd, ConstantOfShape, Convolution, Cos, Cosh, Crop, CumSum, Custom, DecBBox, Deconvolution, DepthToSpace, DepthwiseConv, Det, DetectionOutput, Div, Deconvolution, Cos, Cosh, Crop, CumSum, Custom, Deconvolution, DepthToSpace, DepthwiseConv, Det, DetectionOutput, Div, Deconvolution, Cos, Cosh, Crop, CumSum, Custom, Deconvolution, DepthToSpace, DepthwiseConv, Det, DetectionOutput, Div, Deconvolution, Cos, Cosh, Crop, CumSum, Custom, Deconvolution, DepthToSpace, DepthwiseConv, Det, DetectionOutput, Div, Deconvolution, DepthToSpace, DepthwiseConv, Det, DetectionOutput, Div, Deconvolution, Cos, Cosh, Crop, CumSum, Custom, Deconvolution, DepthToSpace, DepthwiseConv, Det, DetectionOutput, Div, Deconvolution, Deconvolution, DepthToSpace, DepthwiseConv, Det, DetectionOutput, Div, Deconvolution, Deconvo lopout, ELU, Einsum, ElseBegin, Eltwise, Equal, Exp, Expand, Extract, ExtractSlice, EyeLike, Filter, Floor, GRU, Gather, GatherElements, Gemm, GlobalAveragePool, GlobalLpPool, GlobalMaxPool, Greater, GreaterOrEqual HardSigmoid, Hardmax, Hswish, Identity, If, InnerProduct, Input, InstanceNormalization, Interp, LRN, LSTM, LeakyRelu, Less, LessOrEqual, Log, Logical, Loop, LpNorm, LpPool, MVN, MatMul, Max, MaxPool, MaxRoiPool, MaxUnpool Mean, MeanVarianceNormalization, Min, Mish, Mod, Mul, NMS, Neg, NonMaxSuppression, NonZero, Nop, Normalize, Not, OneHot, Or, PReLU, PSROI, PSROI, PSROIPooling, Pad, Parameter, PassThrough, Passthrough, Permute, Pooling, Pb olingMask, Power, QLinearMatMul, RNN, ROIPooling, RReLU, Range, ReLU, ReduceSumSquare, ReduceL1, ReduceL2, ReduceL2, ReduceLogSumExp, ReduceMax, ReduceMan, ReduceMin, ReduceProd, ReduceSum, ReduceSumSquare, Reduction , Reorg, Reshape, Resize, Reverse, Round, SPP, Scale, Scan, Scatter, ScatterElements, Selu, Shape, Shrink, ShuffleChannel, Sigmoid, Sign, Silence, Sin, Sinh, Size, Slice, Softmax, Softplus, Softsign, Sort, SpaceToDepth, Sp 🗽 Sqrt, Squeeze, Sub, Sum, Tan, TanH, Tanh, ThenEnd, Threshold, ThresholdedRelu, Tile, TopK, Transpose, Unique, Unsqueeze, Upsample, Where, Xor], ExtendedOps[].

难点: 涉及未知算子的问题, 开发文档中提供了算子自定义流程, 过程复杂且耗时。




```
npu
   Makefile
   sample_npu_main.c
   sample svp npu
      sample npu model.c
     - sample npu process.c
   - include
     - sample_npu_model.h
     - sample npu process.h
   data
     model
       - mobilenet v3 dynamic batch.om
      - resnet50.om
     ımage
     └─ yuv sp420 224 224.sp420
     caffe_model
     - resnet50.prototxt
```

```
/* function : show the sample of npu resnet50 */
hi void sample svp npu acl resnet50(hi void)
   hi void *data buf = HI NULL;
   size t buf size;
   hi_s32 ret;
   const char *om_model_path = "./data/model/resnet50.om";
   ret = sample svp npu acl prepare init(om model path);
   if (ret != HI_SUCCESS) {
       return;
   ret = sample_svp_npu_load_model(om_model_path, 0, HI_FALSE);
   if (ret != HI SUCCESS) {
       goto acl_process_end0;
   ret = sample svp npu dataset prepare init(0);
   if (ret != HI SUCCESS) {
       goto acl process end0;
   ret = sample_svp_npu_get_input_data(&data_buf, &buf_size, 0);
   if (ret != HI SUCCESS) {
       sample_svp_trace_err("execute create input fail.\n");
       goto acl process end1;
   ret = sample svp npu create input databuf(data buf, buf size, 0);
   if (ret != HI SUCCESS) {
       sample_svp_trace_err("memcpy_s device buffer fail.\n");
       goto acl process end2;
   ret = sample npu model execute(0);
   if (ret != HI SUCCESS) {
       sample_svp_trace_err("execute inference fail.\n");
        goto acl process end3;
   sample npu output model result(0);
acl process end3:
   sample svp npu destroy input databuf(1);
   sample svp npu release input data(&data buf, &buf size, 1);
acl process end1:
   sample svp npu dataset prepare exit(1);
acl process end0:
   sample svp npu acl prepare exit(1);
```

板端Resnet50 Sample模型推理

- 模型初始化
- 模型加载
- 数据初始化
- 数据加载
- 模型推理
- 推理结果后处理





主要特点

Rk3588系列是瑞芯微电子22年发布的一款旗舰芯片,该系列主要包括两款型号:

RK3588 EVB及RK3588S EVB。

- RK3588 EVB:面向ARM PC、NVR、服务器、IPC、大屏显示设备等AloT**行业类应用产品**;
- RK3588S EVB: 面向高端平板、AR/VR、个人移动互联网设备等消费类电子产品;
- 8nm先进制程, 8核64位架构, 高性能, 低功耗
- ARM Mali-G610 MC4 GPU, 专用2D图形加速模块
- 6TOPs NPU,赋能各类AI场景
- 8K 视频编解码,8K显示输出
- 内置多种显示接口,支持多屏异显
- 超强影像处理能力, 48MP ISP, 支持多摄像头输入
- 丰富的高速接口(PCIe, TYPE-C, SATA, 千兆以太网), 易于扩展
- Android 和Linux OS









RKNN 是 Rockchip npu 平台使用的模型类型,以.rknn后缀结尾的模型文件。Rockchip 提供了完 整了模型转换 Python工具——RKNN-Toolkit2工具包 ,方便用户将自主研发的算法模型转换成 RKNN 模型,同时 Rockchip 也提供了C/C++和Python API 接口。

RKNN-Toolkit 是为用户提供在 PC、 Rockchip NPU 平台上进行模型转换、推理和性能评估的开发 套件(相当于海思SDK文档),用户通过该工具提供的 Python 接口可以完成模型转换、量化功能、 自定义算子和可视化功能等。




虚拟机安装Ubuntu系统

安装依赖的虚拟环境 (python、依赖库)

安装RKNN-Toolkit2工具

执行模型转换流程





将yolov5_onnx模型转为yolov5.rknn模型

(atc) zhwj@ubuntu:~\$ atc --model=./Downloads/LMF_0102_epoch-best_3.onnx --framework=5 --output=./Downloads/LMF 0102 epoch-best 3 --soc version="OPTG" --input fp16 nodes="image"

ATC start working now, please wait for a moment.

ATC run failed, Please check the detail log, Try 'atc --help' for more information

E19022: Model featuremap requires [27977189376] memory, which exceeds system limit [27917287424].

build graph failed, graph id:0, ret:245000[FUNC:BuildModel][FILE:ge_generator.cc][LINE:1327]

ONNX模型转RKNN模型


导出RKNN模型

```
name == ' main ':
model_path, platform, do_quant, output_path = parse_arg()
rknn = RKNN(verbose=False)
print('--> Config model')
rknn.config(mean_values=[[0, 0, 0]], std_values=[[255, 255, 255]], target_platform=platform)
print('done')
print('--> Loading model')
ret = rknn.load onnx(model=model_path)
    print('Load model failed!')
    exit(ret)
print('--> Building model')
ret = rknn.build(do_quantization=do_quant, dataset=DATASET_PATH)
    print('Build model failed!')
    exit(ret)
print('done')
print('--> Export rknn model')
ret = rknn.export rknn(output path)
if ret != 0:
    print('Export rknn model failed!')
    exit(ret)
print('done')
```



板端NPU进行推理

PC端通过运行build-linux_RK356X.sh,将调用模型的C程序、转换得到的.rknn模型参数编译生成一个install和build文件,**得到可执行文件**



CSDN @乡万里

RK3588.sh

RK356X.sh



板端NPU进行推理

运行编译生成的可执行文件rknn_yolov5_demo,输入模型权重、图像路径运行程序获取推理结果

```
[root@RK356X:/mnt/rknn yolov5 demo Linux] /# ./rknn yolov5 demo ./model/RK356X/yolov5s-640-640.rknn ./model/bus.jpg
    post process config: box conf threshold = 0.25, nms threshold = 0.45
    Read ./model/bus.jpg ...
    img width = 640, img height = 640
    Loading mode...
    sdk version: 1.4.0 (a10f100eb@2022-09-09T09:07:14) driver version: 0.4.2
    model input num: 1, output num: 3
      index=0, name=images, n dims=4, dims=[1, 640, 640, 3], n elems=1228800, size=1228800, fmt=NHWC, type=INT8, qnt type=AFFINE, zp=-128, scale=0.003922
      index=0, name=334, n dims=4, dims=[1, 255, 80, 80], n elems=1632000, size=1632000, fmt=NCHW, type=INT8, qnt type=AFFINE, zp=77, scale=0.080445
      index=1, name=353, n dims=4, dims=[1, 255, 40, 40], n elems=408000, size=408000, fmt=NCHW, type=INT8, qnt type=AFFINE, zp=56, scale=0.080794
10
      index=2, name=372, n dims=4, dims=[1, 255, 20, 20], n elems=102000, size=102000, fmt=NCHW, type=INT8, qnt type=AFFINE, zp=69, scale=0.081305
    model is NHWC input fmt
    model input height=640, width=640, channel=3
    once run use 62.407000 ms
14
    loadLabelName ./model/coco 80 labels list.txt
    person @ (114 235 212 527) 0.819099
    person @ (210 242 284 509) 0.814970
    person @ (479 235 561 520) 0.790311
    bus @ (99 141 557 445) 0.693320
    person @ (78 338 122 520) 0.404960
    loop count = 10 , average run 77.491700 ms
22
```