

smeg
BCC11BLMEU
Bean To Cup
Coffee Machine



smeg BCC11BLMEU Bean To Cup Coffee Machine User Manual

[Home](#) » [Smeg](#) » smeg BCC11BLMEU Bean To Cup Coffee Machine User Manual 

Contents

- [1 smeg BCC11BLMEU Bean To Cup Coffee Machine](#)
- [2 Specifications:](#)
- [3 Product Usage Instructions](#)
- [4 Important Safeguards](#)
- [5 Description / Controls](#)
- [6 Use](#)
- [7 Cleaning and maintenance](#)
- [8 TROUBLESHOOTING](#)
- [9 FAQ](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)



smeg BCC11BLMEU Bean To Cup Coffee Machine



Specifications:

- **Brand:** SMEG
- **Model:** BCC11BLMEU
- **Type:** Bean-to-Cup Coffee Machine

Product Usage Instructions

Assembly of Components:

Refer to Figure E for assembling the components of the coffee machine

Use:

1. Fill the water tank with water up to the maximum level indicated.
2. Press the power button to turn on the machine.
3. Select your desired coffee options using the control panel.
4. Place a cup under the coffee spout.
5. Press the start button to begin the coffee brewing process.

Cleaning and Maintenance:

1. Regularly clean the coffee machine after each use following the instructions in Figures B, D, E, F, G, and H.
2. Descale the machine as recommended in the user manual to maintain performance.

Troubleshooting:

If the machine does not turn on:

- **Possible Cause:** Power issue.
- **Solution:** Check the power source and ensure the machine is properly plugged in.

We advise you to read this manual carefully, as it contains all the instructions for managing the appliance's aesthetic and functional qualities.

For further information on the product: www.smeg.com

Important information for the user

- **Warnings**

General information on this user manual, on safety, and final disposal.

- **Description**

Appliance description.

- **Use**

Information on using your appliance.

- **Cleaning and Care**

Information for proper cleaning and maintenance of the appliance.

- **Safety Instructions**

Warnings related to safety.

- **Information**

- **Advice**

Scan the QR code for an easy access to “How to” SMEG guide to assist you during product use and installation.




SMEG
ASSISTANT

- The manufacturer and resercturer reserves the right to make any changes deemed usves the right to make any changes deemed useful for the improvement of its products withouteful for improvement of its products without prior priornotice.
- The illustrations and descriptions contained in this mannotice. The illustrations and descriptions contained in this manual are, therefore, not binding and are merely indicative. ual are, therefore, not binding and are merely indicative.

Dear Customer,

- Thank you very much for purchasing the Smeg Line coffee machine.
- By choosing our product, You have opted for a solution in which aesthetics and innovative technical design offer unique objects, which become part of the furnishings.
- In fact, a Smeg household appliance always co-ordinates perfectly with other products in the range and, at the same time, can become a design object for the kitchen.
- We hope You fully appreciate the functionalities of Your appliance. Best regards. SMEG S.p.A.



Model BCC11
Bean to cup Coffee machine

Important Safeguards

SAFETY

- Essential safety recommendations.
- Keep these instructions carefully. Whenever the appliance is transferred to other persons, they must also be given these user instructions.

Danger of Electrocution, since the appliance operates on electric current, it is necessary to comply with the following safety warnings:

- Do not touch the plug with wet hands.
- Make sure that the power outlet used is always freely accessible, because only in this way can it be unplugged when necessary.
- If you want to remove the plug from the socket, grasp the plug directly. Do not remove the plug from the socket by pulling on the cable or with wet hands.
- If the appliance should break down, do not attempt to repair it. Switch the appliance off, remove the plug from the power outlet and contact the Smeg Technical After-sales centre.
- If the plug or power supply cable are damaged, have them replaced exclusively by the Technical After-sales centre, so as to prevent all risks.
- Do not immerse the appliance, the power cord, the plug in water or any other liquid.
- Warning: Danger of injury! Improper use of the appliance can cause injury. Before cleaning, disconnect the plug.
- Do not allow the power supply cable to dangle over the edge of the table or other surface or to come into contact with hot surfaces. Choking hazard due to plastic packaging, keep the packaging material (plastic bags, expanded polystyrene) out of the reach of children.
- Do not position the appliance on or in proximity of electric or gas cookers, or in a heated oven.
- Do not wash the appliance in the dishwasher.

Connecting the appliance

Warning! Make sure that the mains voltage and the frequency correspond with those indicated on the data plate on the bottom of the appliance. Only connect the appliance to a current outlet installed perfectly with minimum capacity of 10A and with an efficient earth.

If the plug and power outlet are incompatible, have the power outlet replaced with a suitable type by qualified staff. In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.

- Do not use an adapter.
- Do not use an extension cord.
- Do not spill liquid on the power plug and on the power base.

Failure to observe these warnings can result in death, fire or electric shock.

- Keep the appliance out of the reach of children under the age of 8.
- Children must not play with the appliance.
- The use of this appliance is allowed to people (including children of at least 8 years) with reduced physical, sensory or mental abilities only if they are under the control of adults or have been instructed on the safe use of the appliance and have understood the dangers associated with its use.
- Cleaning or maintenance work can be carried out by children who are at least 8 years old, only under the supervision of an adult.
- Disconnect the appliance from the power outlet before all assembly, disassembly and cleaning operations.

Danger of burns

- Allow the appliance to cool down before cleaning.

- The coffee machine generates heat and produces hot water when running. Avoid contact with boiling water.

Use compliant with destination

- Only use the appliance indoors and at a maximum altitude of 2000 meters.
- Use the device only to prepare coffee-based drinks from grinding coffee beans or to dispense hot water. Other uses are improper.
- Only insert water into the appropriate tank. Use fresh, clean water.
- Use only original spare parts from the manufacturer. The use of spare parts not recommended by the manufacturer could cause fire, electric shock or personal injury.
- The appliance is intended for household and similar use, such as:
 - in the kitchen area for the staff of shops, offices and other work environments;
 - in bed and breakfast and agritourism accommodation;
 - by guests at hotels and motels, and in residential environments.
- Other uses, in restaurants, bars and cafes for example, are improper.

Moreover:

- Do not fill the water container beyond the maximum limit indicated.
- Do not use without water in the tank or without a tank.
- Use only coffee beans to obtain the powder, do not put already ground coffee in the coffee bean hopper.
- Do not insert the appliance in a closed cabinet (built-in type).

Attention: For cleaning surfaces that come into contact with food, observe the special cleaning indications in the instructions.

Manufacturer's liability

The manufacturer declines all liability for damage undergone by persons and objects due to:


- use of the appliance different from that envisioned;
- user manual has not been read;
- tampering of individual parts of the appliance;
- use of non-original spare parts;
- failure to comply with safety recommendations.

DISPOSAL

Electrical appliances must not be disposed of with household waste. The appliances that have this  symbol are subject to the European Directive 2012/19/EU. All discarded electric and electronic appliances must be disposed of separately from household waste, by taking them to relevant centres envisioned by the Country. By disposing of the discarded appliance correctly, damage to the environment and risks to health will be avoided. For further information regarding disposal of the discarded appliance, contact the Municipal Administration, the Disposal dept. or the shop where the appliance was purchased.

Description / Controls



DESCRIPTION OF THE APPLIANCE (Fig. A)



1. Machine body.
2. Coffee bean container lid.
3. Coffee bean container.
4. Water tank cover.
5. Water tank (1,4 l).
6. Grinding selection knob.
7. Grinders protection.
8. Brewing group access door.
9. ON/OFF button.
10. Control panel.
11. Height adjustable coffee dispenser.
12. Coffee grounds container.
13. Drip tray.
14. External drip tray.
15. Internal drip tray with level indicator.

16. Mug holder.
17. Brewing group.
18. Cleaning brush.
19. Water hardness test strip.

DESCRIPTION OF CONTROLS AND ALARMS (Fig. B-C)



ON/OFF button (9)

Pressing the button switches the machine on or off.

Change dispensing program button (24)

- The product has 8 functions, accessible through two menus, White Menu and Orange Menu.
- By pressing this button it is possible to change the dispensing menu from "White" and "Orange" and vice versa.

White	Keys LED white
 20	Ristretto coffee
 21	Espresso coffee
 22	Coffee
 23	Hot water
Orange	Keys LED orange
 20	Light Ristretto coffee
 21	Light Espresso coffee
 22	Long coffee
 23	Americano

Controls

- **Empty water tank alarm (25)**

The related LED flashes when the tank (5) is absent, or when the water inside it is missing or at an insufficient level. Insert the tank or fill it with water.

- **No coffee alarm (26)**

The relative LED lights up steadily indicating that the coffee beans in the container (3) have reached the minimum level or are absent. Fill the container with coffee beans.

- **Coffee grounds container alarm (27)**

- **Steady lit LED:**

Coffee grounds container full (12); empty the container.

- **Flashing LED:**

Coffee grounds container (12) or internal drip tray (13) missing or incorrectly assembled; the machine is blocked until the components are correctly reassembled.

- **Brewing group alarm (28)**

- **Flashing LED:**

Door open or brewing group missing or incorrectly assembled; the machine is blocked until the brewing group is correct assembled or door closed.

- **Stead lit LED:**

Indicates that it is advised to clean the area of the infuser group to remove coffee residues which may damage machine operation. Remove the infuser from its seat while the machine is on and reinsert it after cleaning.

- **Descaling alarm (29)**

- **Steady lit LED:**

Indicates that it is highly recommended to carry out a descaling cycle;

- **Flashing LED:**

The machine is blocked in all its functions, a descaling cycle is mandatory to restore machine operation.

- **Grinding adjustment knob (6) (Fig. D)**

The appliance is equipped with a knob (6) that allows you to adjust the grinding grain of the coffee according to its uses:





- Turning the knob (6) clockwise “A” increases the grinding grain; turning the knob (6) anticlockwise “B” decreases the grinding grain and the ground coffee will be finer (Fig.D).
 - Turn the knob (6) and match the indicator (30) with the desired grinding level.

The grinding grain adjustment must be carried out when the grinder is in operation or on first use when the bean container is completely empty; turning the knob (6) with the grinder stopped and the beans inside could damage the grinding unit.

Do not use green, caramelised or candied coffee beans, as they may stick to the coffee machine and ruin it.

Use

BEFORE FIRST USE (Fig. D-E-F)



- Unpack the appliance carefully and remove all packaging materials.
- Rinse the following removable components with warm water: water tank (5) lids (2,4), door (8) grounds container (12), drip tray (13), drip trays (14,15), cup holder (16) and infuser unit (17).

Before use, check that all components are integral and have no cracks.

ASSEMBLY OF COMPONENTS (Fig. E)

- Place the machine on a flat surface and fix the drip tray (14).
- Connect the power supply cable to the socket on the rear of the machine and the other end to a power socket.

USE (Fig. E-F-G)

- Lift the tank cover (4) and pour fresh water in the tank (5) being sure not to exceed the indicated 'Max' level. Replace the water tank cover when full (4).
- Lift the coffee bean container lid (2) and introduce the coffee beans into the container (3).
- Check that the drip tray (14) is correctly positioned. Make sure that the tray which can be washed in the dishwasher (15) is correctly inserted inside it and mount the mug holder (16).
- Press the button (9), the machine starts the heating phase and the keys light up flashing in sequence. At the end of the heating, a self-cleaning cycle of the internal circuits is carried out and, once the cycle is finished, the machine is ready to be used.
- At the first use it is recommended to make at least one coffee to make a complete break-in of all the circuits.
- We recommend setting the water hardness upon first use. Please see the "Water hardness settings" paragraph for this reason.
- Remember to reassemble the tray (14) at the end of any dispensing.
- After 30 minutes of non-use, the machine switches off. If it has made at least one coffee, it performs a self-cleaning cycle. Press the button (9) to switch on the machine.

Change of dispensing program

- The machine has two dispensing menus in its memory: White and Orange. To switch from one program to another, press the key (24). In the White menu all the keys are illuminated in white, in the Orange menu, all the keys are illuminated in orange.
- For the specific functions of each menu, refer to the paragraph "Description of controls and alarms"

Turning off the machine the setting of the White or Orange dispensing menu remains in the memory at the next restart.

Dispensing a drink

- It is possible to adjust the position of the dispenser (11) according to the cup used. For very high cups it is possible to remove the drip tray (14).
- Place a cup or large cup under the dispenser.
- Press the key for the desired function. For each selected function, preparation stops automatically. For specific functions, refer to the paragraph "Description of controls and alarms".
- At the end of dispensing, all the keys light up fixed.
- Remember to reassemble the tray (14) at the end of any dispensing.
- It is completely normal that after a prolonged inactivity of the machine (breaks longer than 20 min) the first coffees are not at the right temperature. The tips to obtain a hot coffee immediately are given in the section "What to do if..."
- Dispensing can be stopped at any time by pressing the dispensing key again.

Customization of the quantity

It is possible to customize, for each type of dispensing, the quantity of coffee or water dispensed.

- Place a cup or large cup under the dispenser.
- Press for at least 3 seconds one of the keys relative to the drink to be dispensed. The selected key lights up flashing; the machine emits a double sound to signal the modification of the preset program.

- On reaching the desired quantity, stop dispensing by pressing the key again; an acoustic signal indicates the memorization of the quantity.
- Any customization of the drinks remains saved for future dispensing.
- To restore the manufacturer's settings, press the keys (9) and (24) simultaneously for at least 3 seconds.
- The machine emits a single sound to signal the restoration of the factory settings.

Turning off the machine

- Check that the drip tray (14) is positioned correctly.
- If there is no water, the machine remains in the rinse position until the tank is filled.
- Press the button (9), the keys (20), (21), (22), (23) light up flashing in sequence and the machine, if it has dispensed at least one coffee, performs a self-cleaning cycle.
- At the end of the self-cleaning cycle, the machine switches off.

MACHINE SETTINGS (Fig. B)

Through a programming menu it is possible to set the water hardness and the acoustic signals.

Activation/deactivation of acoustic signals.

The acoustic signals can be disabled / enabled by keeping the keys (21) and (24) pressed for three seconds; the key (21) flashes three times indicating the memorization of the setting.

Setting the water hardness.

The machine is factory set to "Hard Water Level". The machine can also be set according to the actual water hardness in the various regions for less frequent descaling.

If you don't know the water hardness, use the supplied test strip (19) and follow the instructions below.

- Remove the supplied reactive strip from its packaging.
- Fully submerge the strip in a glass of water for about one second.
- Remove the strip from the water and slightly shake it. Read the results after about one minute. If 5 blue stripes appear on the strip, select "Soft water" settings. If 1 or 2 pink stripes appear on the strip, select "average water" setting. If 3, 4 or 5 pink stripes appear on the strip, select "hard water" settings.
- To open the water hardness settings, simultaneously press and hold down keys (20) and (24) for at least 3 seconds, LEDs (25), (26), (27) will flash simultaneously.
- Choose the water hardness, referring to the following table, pressing the key (20), the LED relating to the selected hardness lights up steadily, the others go off.


Led	Hardness
 25	Soft
 26	Medium
 27	Hard

- To memorize the selected hardness, press keys (20) and (24) simultaneously for at least 3 seconds or do not press any key for 15 seconds.

To prolong the machine operation and preserve the aroma and taste of the coffee, it is recommended to use the Smeg Softener Filter (optional, not supplied). For installation and operation, follow the instructions that accompany the accessory. Once installed, set the water hardness level to 'Soft' following the instructions in the previous paragraph.

Cleaning and maintenance

CLEANING AND MAINTENANCE (Fig. B-D-E-F-G-H)



Incorrect use Risk of damage to surfaces.

- Do not use steam jets to clean the coffee machine.
- Do not use cleaning products containing chlorine, ammonia or bleach on parts with metal surface finishes (e.g.

anodised, nickel- or chrome-plated).

- Do not use abrasive or corrosive detergents (e.g. powder products, stain removers and metallic scourers).
- Do not use rough or abrasive materials or sharp metal scrapers.

Automatic rinse

- After dispensing a coffee beverage or beverage with milk, the machine automatically rinses the dispenser nozzle (11) before turning off.
- To ease cleaning operations, it is possible to scan the QR code located inside the service door, which opens a specific web section dedicated to Cleaning and Installation (fig. H).

Manual rinse

- Make sure that the White program is selected with keys (20), (21), (22), (23) illuminated in white.
- With the machine ready to dispense and the drip tray mounted, press the keys (24) and (23) simultaneously for at least 3 seconds: the machine will rinse the coffee circuit (coffee dispenser 11).
- At the end of the washing cycle, the keys light up steadily.

Cleaning of the machine body

- For a good preservation of the external surfaces it is necessary to clean them regularly at the end of each use, after letting them cool.
- Clean with a soft cloth dampened with water.
- Never immerse the machine body (1) in water or other liquids.
- Allow the machine to cool down before cleaning.
- Use the supplied brush to clean the empty coffee bean container (3), removing any beans or residue. Always clean when the machine is off.

General cleaning

To ensure good operation of the machine, beyond the optimal quality of the drinks, some daily operations of simple cleaning are advised, such as tray (13), drip trays (14, 15) and grounds container (12) cleaning. We also recommend you routinely clean some specific machine components such as the brewing group (17) or water tank (5). Please see the specific paragraphs for cleaning instructions.

Cleaning the drip tray (14, 15)

The drip tray (14) envisages an internal tray (15) inside it which is equipped with a red float (31) which protrudes from the mug holder (16) as soon as the maximum level of liquid is exceeded.

- • The internal tray (15) can be washed in the dishwasher.
- • Clean the tray (14) and the grid (16) in running water with neutral dish detergent.
- • Dry the components and reassemble them in the machine.
- Do not wash the components in the dishwasher, except for the internal tray (15).
- We recommend you clean the external drip tray daily.

Coffee grounds container cleaning (12) and drip tray (13) Always empty the coffee grounds container with the appliance switched on. This is the only way of resetting the coffee grounds counter. The counter resets at least 15 seconds after opening the various components and LED (27) flashes.

- Remove the trays (14, 15).
- Remove the grounds container (12) with its tray (13) by pulling it outwards.
- Empty the coffee grounds from the container (12).
- Clean the container (12) and the tray (13) in running water with neutral dish detergent.
- Thoroughly dry components and reassemble on the machine.
- When the grounds container is emptied, take care to also empty the drip tray (13) from possible residues.
- It is advised to daily clean the coffee grounds container (12) and the drip tray (13).
- It is totally normal to find water residues in the tray. Clean and dry.

Cleaning the water tank (5)

- Remove the lid (4) and remove the tank (5) from the machine using the appropriate handle.
- Clean the tank (5) in running water with neutral dish detergent and reassemble it in the machine.

The presence of lime scale inside the tank could cause the appliance to malfunction. Make sure the tank is always clean and without lime scale stains.

Cleaning the brewing group (17)

We recommend cleaning the brewing group at least once a week.

- The coffee machine indicates when brewing group cleaning is recommended (steady lit LED 28).
- With the machine on, press the lower part of the door (8) until it is released and slide it out from the top.
- Press the two release clips (32) located on the sides of the infuser (17) and remove it from the machine (Fig.H).
- Wash the brewing group (17) with running water and dry it.
- Thoroughly clean its housing and the duct as well, using the cleaning brush (18) supplied, as in Figure H.
- Dry thoroughly before re-mounting the various components.
- Refit the service door (8) making sure it is correctly positioned.
- Open the door and clean the brewing unit while the machine is on. This is the only way of resetting the counter.
- The counter resets at least 10 seconds after opening the various components and LED 28 turns off.
- We recommend running a manual circuit cleaning cycle whenever this operation is performed. Please see paragraph "Manual rinse" for this reason.
- Do not wash the brewing group in the dishwasher in order not to damage it permanently.
- Coffee powder residue can be found in the brewing group compartment. We recommend thorough cleaning whenever cleaning the brewing group. Use the supplied brush to remove any residue from the brewing group compartment.
- Dry all components and internal parts using a dry cloth before closing the side door.

Descaling

- Before performing the descaling cycle, remove possible softener filters inside the tank.
- The coffee machine signals when it is necessary to carry out a descaling cycle based on the set water hardness (For the setting of the water hardness, see the "Setting the water hardness" paragraph).
- If the LED (29) lights up steadily, it means that a descaling cycle is necessary, so as not to alter the taste of the coffee and damage the machine. However, coffee and further drinks may continue to be dispensed for a limited number of cycles.

- If the LED (29) flashes, it means that a descaling cycle is mandatory to proceed with further dispensing of drinks.

To carry out a descaling cycle, proceed as follows:

- Place a container with a capacity of at least 1.4 L under the dispenser (11).
- Make sure that the White program with white illuminated keys is selected.
- Fill the tank (5), up to the “MAX” level, with a solution of water and descaler in the doses recommended by the manufacturer.
- With the machine ready for use, press the keys (24) and (22) simultaneously for at least 3 seconds. The key (22) flashes with an orange light and the LED (29) has a fixed light for the entire duration of the descaling cycle.
- Stay near the machine for the entire duration of the descaling cycle since you may be required, for example, to fill the tank (5). The entire cycle lasts approximately 30 minutes.
- During the descaling cycle, the machine will take a few breaks to allow the descaler to act effectively. Wait for the end of the cycle.
- The descaling cycle ends when there is no more solution in the tank (5), the key (22) turns white and the LEDs (25) and (29) remain lit.
- Pour clean water into the tank (5) up to the “MAX” level to carry out the rinse cycle, then press the button (22) to start the rinse cycle, the button (22) flashes and the LED (29) lights up steadily for the entire duration of the washing cycle.
- The rinse cycle ends when the keys light up white.
- If at the end of descaling the key (24) blinks in white and the led (29) lights up steady, that means that it is necessary to carry out a new descaling cycle since the quantity of descaling solution that has been used was insufficient for a complete cleaning.
- If, at the end of the descaling process, the LED (29) remains permanently lit, it indicates that a new descaling cycle must be carried out since the quantity of descaling solution that was used was insufficient for complete cleaning.

Personal injury hazard.

- The descaler contains acids that can irritate the skin and eyes.
- Follow the manufacturer’s instructions and safety warnings on the packet scrupulously in the event of contact with skin or eyes.
- Use descaler products recommended by Smeg to prevent damage to the coffee machine.

Any other servicing should be performed by an authorized service representative.

“Empty system” procedure

The ‘Empty system’ procedure is recommended before long periods of non-use and before consulting a maintenance manager.

- Activate the procedure by holding down the key (20) and the key (23) simultaneously for three seconds, the key (21) and the key (23) flash simultaneously.
- The entire quantity of water in the tank is drained through the coffee circuit.

- The pump continues to operate, even intermittently, to also empty the internal water circuits.
- At the end of the procedure the machine switches off.

The empty system procedure takes several minutes and on-off cycles. Do not turn off the machine until the complete procedure is complete.

TROUBLESHOOTING

What To Do If....

Problem	Possible cause	uses	Solution
Plug not connected.		d.	Connect the plug.
The machine doesn't turn on.	Plug not fully connected.	nected.	Fully connect the plug to the machine.
	ON-OFF (9) button pressed.	n not	Press the button to start the machine.
	ON-OFF (9) button working.	n not	Contact an authorised service centre.
	Empty tank alarm or missing (LED 25 on).		Make sure the tank is correctly assembled or fill with water, or rinse to remove any scale residues.
	No coffee alarm on).	(LED 26	Pour coffee beans in the relevant container.
Grounds contain (LED 27 on).		er alarm	Empty the grounds container. Note: empty by removing the drawer for at least 15 seconds with the machine on. Alarm 27 flashes to indicate the counter was correctly reset.
The machine is on but does not work.	Grounds container (LED 27 flashing).	r alarm	Grounds container not correctly assembled or internal drip tray missing. Reassemble the components.
Generic alarm (LED flashing).		ED 28 or closed.	Make sure the brewing group is correctly assembled and the door is closed.
	Generic alarm (LED 28 on).		Open the access door, remove the brewing unit, check and clean the movement area. If the problem persists, contact an authorised service centre.
Mandatory descaling (LED 29 flashing).		ling alarm	Run a descaling cycle.

Problem	Possible Causes	Solution
Machine stops when dispensing.	Tank removed during dispensing or water below minimum level.	Ensure the tank is correctly assembled or fill it with water.
	Side door was opened during dispensing.	Close the side door again.
Incorrect water reading in tank.	Lime scale inside the tank.	Clean and reassemble the tank. Run a descaling cycle if needed.
Alarm 25 not on but water missing.	Water mistakenly poured into the tank gap.	Remove the tank and dry the compartment thoroughly.
Coffee is not hot.	Cups were not preheated.	Preheat cups by rinsing them with hot water (use hot water function).
Coffee is weak or lacks crema.	Coffee too roughly ground.	Turn the knob counterclockwise to tighten the grinders (adjust during grinding).
	No more beans in the container.	Fill the bean container and dispense coffee again.

Problem	Possible Causes	Solution
Coffee dispensed slowly or in drips.	Coffee too finely ground.	Turn the knob clockwise to loosen the coffee grinders. Adjust while running.
	Dispenser clogged.	Manually clean as indicated in "Cleaning and Maintenance".
Machine does not work after descaling.	The cycle was not completed.	Ensure the cycle and rinse are completed. Follow "Cleaning and Maintenance".
	Tank not filled to max level.	Fill the tank properly and empty the container under the dispenser.
Machine does not turn off.	LED 25 is on, no water in tank.	Fill the tank to allow the machine to complete the final rinse cycle.
Machine emitted two beeps, LEDs turned off.	General machine problem.	Contact an authorized service center.
Drawer blocked.	Incorrect machine use.	Turn the machine off and on to reset internal parts.
All buttons flash simultaneously.	Hydraulic circuit error.	Ensure water is in the tank and wait for the circuit to reset. The machine will return to its initial position. If the problem persists, contact an authorized service center.

Contact local technical support if the problem is not solved or in case of other types of faults.

FAQ

Q: How often should I descale the coffee machine?

A: It is recommended to descale the machine every 2-3 months depending on usage frequency and water hardness.

Q: Can I use ground coffee instead of beans in this machine?

A: No, this machine is designed for use with coffee beans only.

Documents / Resources

	smeg BCC11BLMEU Bean To Cup Coffee Machine [pdf] User Manual BCC11BLMEU, BCC11BLMEU Bean To Cup Coffee Machine, Bean To Cup Coffee Machine, Cup Coffee Machine, Coffee Machine
---	---

References

- [Smeg - Technology with style | Smeg.com](#)
- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.