

10 Troubleshooting

10.1 Service and Maintenance

Review all safety warnings and cautions in [2.3 General Safety Precautions](#) and [2.4 Electrical Installation Precautions](#) before the service/maintenance begin

Only qualified service personnel can update the Active Power Filter hardware and firmware.

Regularly clean the Active Power Filter, especially the slits, openings, and filters, to ensure that the air freely flows into the Active Power Filter to avoid overheating. If necessary, use an air blower or vacuum cleaner to clean the slits, and openings and replace the filters regularly to avoid any object from blocking or covering these areas.

Check if all fans work properly when the Active Power Filter is running, and ensure that air can move freely around and through the Active Power Filter. Replace the fan if it is not working properly.

Some components like power capacitors and fans become worn out due to long term usage, and increase the risk of failure on the Active Power Filter.

Contact Danfoss for further information regarding maintenance and service.

10.2 Fault Finding and Troubleshooting

Review all safety warnings and cautions in [2.3 General Safety Precautions](#) and [2.4 Electrical Installation Precautions](#) before the fault finding and troubleshooting begin.

If the filter does not work properly, readout the fault name and investigate possible root causes for the fault.

Table 41: Overview of Faults and Troubleshooting Hints

Fault number	Fault name	Possible fault	Troubleshooting
1	SYS 485 comm loss	1 The communication wire is not well connected. 2 The Active Power Filter modules have repeated IDs.	1 Check if the communication wire is firmly connected. 1 Check the DIP switches of the individual modules.
2	Fuse blowout	The input fuse is broken.	Contact service personnel.
3	Ambient OTP	1 The air vents ate blocked. 2 The fans do not work.	Contact service personnel.
4	BUS OVP/UEP	BUS capacitor failure.	Contact service personnel.
5	Fan Fail	Fan failure.	Contact service personnel.
6	No current compensation/Bad current compensation	The CT is not well connected.	Check if the CT wiring is correct.

10.3 Disposal

Danfoss accepts defective filter modules for disposal.