

HP-700 Maintenance Manual

SERIAL: HP7-000042

Hydraulic pressure low

Inspect the main pump and tighten the coupling.