

Cache Size

TAG RAM

Cache RAM (U18-21)

JP17

JP18

JP19

**J**P37

Cache Configuration Size

512K 256K 128K

32KX8

128KX8 64KX8 32KX8

1:2

2.3 2.3 1.2

1-2,3-4 1-2,3-4

32KX8 8KX8 (U22)

2-3 1-2

1.2 2-3

1.2

1-2,3-4

	2-4
1	SHE
	RCON
	NECT
	ORS

Keylock.	J45
Speaker Connector.	J44
Turbo Switch.	J43
Turbo LED.	J42
HDD LED.	J41
Reset.	J40
Description	Connector

E-mail: pcvesti@null.ru http://pcvesti.null.ru Посетите нашу страничку в Интернете

## 2-1.1 CPU Type settings

CPU TYPE	JP22	JP24	JP25	JP26	JP27	JP28
P24T	1.2	nado	1.2	open	1-2	3-4
P24D	1-2	1.2	1-2	1-2	1-2	1-2,3-4
S-SERIES	1.2	2-3	2-3	open	open	3.4
Enhanced Am486	1-2	1.2	1-2	1-2	1-2	1-2,3-4
AMD486DXL(3.45V)	2:3	open	2:3	open	open	open
486DX(5V)	open	2.3	2-3	open	apen	open
486SX	open	2-3	2-3	open	apen	open
CYRIX CX486	1.2	1-2	2.3	nado	2:3	2-3
CYRIX M1SC	1-2	1-2	2-3	1-2	1.2	1-2,3-4
CPU TYPE	JP29	JP30	JP31	JP32	JP33	JP34
P24T	1.2	1-2,3-4	2-3	open	1-2	2-3
P240	open	1-2,3-4	2-3	2-3	4-5	3-4
S-SERIES	open	1.2,3.4	2-3	1.2	4-5	open
Enhanced Am486	open	1-2,3-4	2-3	2-3	4-5	3-4
AMD486DXL(3.45V)	3-4	1-2,3-4	4.5	open	open	1-2,3-4
486DX(5V)	open	1-2,3-4	open	apen	open	3.4
486SX	open	2-3	open	apen	open	open
CYRIX CX486	2-3	1-2,3-4	1.2	open	2-3	3-4
CYRIX M1SC	open	1-2,3-4	2-3	2-3	4-5	3-4

# The jumper setting for Am5x86-P75 (X5-133) is same as P24D, and set J21 to "close".

The JP23 setting for AMD486DXL(3.45V) CPU please see following table; for other CPUs please set JP23 to "1.2".

486DX2	486DX4	JP23
2-3	1.2	

#### 2-1.2 CPU Speed setting

2. Yellow-----System Clock Selection. 3. Red------Regulator Voltage Selection.

1. White---

--- CPU Type Selection.

4. Black--

---Factory Setting.

DX50	DX40/DX2-80/DX4-120	DX33/DX2-66/DX4-100	DX25/DX2-50/DX4-75	CPU SPEED
OPEN	-120 OPEN	-100 OPEN	75 OPEN	J15
CLOSE	OPEN	CLOSE	OPEN	J14
OPEN	CLOSE	CLOSE	OPEN	J13

### Setting of CPU Voltage:

4V	3.45V	5γ	CPU Voltage
2:3	2-3	1.2	J38
3-5,4-6	1-3,2-4	open	J35

#### 2.1.3 Other jumper setting

4	_		<del></del>
	Asynchronous clock	Synchronous clock	J11
	2-3	1.2	
	EPROM	Flash ROM	J46
	2-3,4-5	1.2,5.6	6
, <del></del>	_		
Clear CMOS	Internal Battery	External Battery	J36

■■ J12 setting default 1-2, please do not revise it.