JP(A,B,C,D,E): CPU Core Voltage Selectors

	Setting		Setting
3.5V	ABCDE	2.9V	ABCDE
3.3V	ABCDE	2.8V	ABCDE
3.2V	ABCDE	2.5V	ABCDE

JP8 Flash ROM Voltage Jumper

Description	JP 8
12 Voltage Flash programming	1 12V / 5V
5 Voltage Flash programming	1 12V / 5V

J5 COMS RAM Discharge Jumper

Description	J 5
Normal Mode	1
Clear CMOS	1

JP3: Sound Pro Selector

Description	Setting
Enable	
Disable	

JP4 Microphone Type Selector

Description	Setting
Special	
Normal	