1 Battery input and eFuse (TPS259824LNRGE)



2 Servo rail 5.0 V 12 A (TPS56C215RNNR); EN is the hardware torque enable



3 Compute rail 5.0 V 3 A (TPS62933DRLR) and 3.3 V LDO (TLV75533PDBVR)



4 USB-C charge input and 2S charger (BQ25887RGER)



5 Radxa ZERO 3W socket, debug UART and analog monitor (ADS1115IDGSR)

6 Servo bus: three half duplex TTL chains (74LVC2G241DCUR)



7 Speaker amplifier (MAX98357AETE+T) and trunk IMU (BNO085)



8 Head board link (camera FPC runs direct from the computer) and mounting



Generated by ecad/gen: edit the generator, not this file

Duccky v1.0

Sheet: /

File: carrier.kicad_sch

Title: Duccky v1.0 trunk carrier board

Size: A0	Date:	Rev: A
KiCad 9.0.4	10:54	1/1