



HRVATSKI
ENGLISH

UPUTE ZA PERGOLU PERGOLA INSTRUCTIONS

- Odaberite kanal 1 za kontrolu LAMELA
- Select channel 1 for controlling pergola's LOUVERS

- Odaberite kanal 2 za kontrolu LED rasvjete
- Select channel 2 for LED lighting control

- Pritisnite LIJEVO na daljinskom upravljaču za promjenu kanala
- Press LEFT on the remote control to change the channel



- CH 1: Pritisnite GORE/DOLJE za podešavanje lamela
- CH 1: Press UP/DOWN to adjust louvers

- CH 2: Pritisnite GORE za promjenu moda, pritisnite DOLJE za gašenje svjetla
- CH 2: Press UP to change lighting mode, press DOWN to turn off LED lights

- CH 1: Pritiskom na funkcijske tipke birate predefinirane pozicije lamela
- CH 1: Change louver presets by pressing functional keys
- CH 2: Pritiskom na funkcijske tipke odabirete boju LED rasvjete
- CH 2: Change LED color presets by pressing functional keys