Amp Selector FX Diagram
- Relay number corresponds to Arduino pin number
- Relays 9-12 should never be all open at the same time
- Bypass   Guitar > Amp
- Amp FX   Guitar > FX > AMP
- Kat Loop   Guitar > AMP
                    Send > FX > Return

Guitar to Amp

NO   NC   NC   NO

FX In

R9   R10

FX Out

NO   NC   NC   NO

R11   R12

Katana Loop

Bypass -   R9   Closed
            R10   Closed
            R11   Closed
            R12   Closed

Amp FX -   R9   Open
            R10   Open
            R11   Closed
            R12   Closed

Kat Loop - R9   Closed
            R10   Closed
            R11   Open
            R12   Open