

NOTES on saving data in SRIM:

On UTS computers, you may need to change the output folder to the "downloads" folder of the user that is logged in (due to a permissions issue that prevents saving of files in the default "SRIM Outputs" folder).

In the TRIM window (the one that shows the cascade of moving atoms) there is a window, normally on the left of the screen, labelled Plots, below that is a sub box labelled "DISTRIBUTIONS" with purple and grey stripes. If you push the button labelled "F" next to the "Ion/Recoil Distribution" label it will open a dialogue box for you to create a file to put the ion data into. Every time you push that "F" button it will update the file... To save VACANCY.txt, use Damage Events, and to save RANGE.txt use Ion/Recoil Distribution.