Forklift FL-30 Service Manual

1. Capacity and specifications

The FL-30 forklift has a rated lifting capacity of 3000 kg.

The traction battery is 48 V.

The maximum lift height is 6 meters.

The forklift uses solid pneumatic tires.

Operators must wear a hard hat and a high-visibility vest.

2. Maintenance schedule

Check the battery water level every week.

Inspect the service brakes every 250 operating hours.

Change the hydraulic oil every 1000 operating hours.

Lubricate the mast chains every 50 operating hours.

3. Error codes and emergency procedure

E01 means low battery voltage. Charge the battery.

E02 means motor overheat. Stop the forklift and let it cool.

E03 means low hydraulic pressure. Check the hydraulic lines.

To lower the forks in an emergency, pull the emergency lowering valve.

The warranty period is 18 months for the frame.