Hydraulic Press H-200 Service Manual

1. Safety and specifications

The H-200 hydraulic press is designed for cold metal forming.

The maximum operating pressure is 180 bar.

The hydraulic reservoir uses ISO VG 46 mineral oil.

Always wear safety glasses and steel-toed boots when operating the press.

2. Maintenance schedule

Change the hydraulic oil every 500 operating hours.

Replace the oil filter every 250 operating hours.

Inspect hoses and fittings every 100 operating hours.

Lubricate the guide rails every 50 operating hours with lithium grease.

3. Troubleshooting and warranty

If pressure drops below 120 bar, inspect the pressure relief valve first.

An abnormal knocking noise usually indicates air in the hydraulic oil; bleed the system.

The press frame bolts require 120 Nm of torque.

The warranty period is 24 months for the frame and 12 months for hydraulic components.