

# Epson EcoTank ET-4850 – Complete Setup & User Quick Guide

Device: Epson Eco Tank ET-4850

Operating System: Windows 11 Pro

---

## Overview

This guide documents my complete hands-on experience setting up, configuring, and troubleshooting the Epson EcoTank ET-4850 printer. It combines official setup instructions with real-world adjustments I applied to make the process smooth and functional.

This is part of my personal IT portfolio, showcasing my ability to independently configure home-office equipment using documentation, diagnostic tools, and problem-solving skills.

---

## Power and Ink Installation

### Step 1 – Connect the Printer

- Unbox the printer and remove all protective tape, foam, and plastic.
  - Place the printer on a flat, stable surface near a power outlet.
  - Plug the power cable into the printer and connect it to the wall socket.
  - Press the Power button to turn on the printer.
- 

### Step 2 – Fill the Ink Tanks

- When turning on for the first time, the printer will prompt to fill the ink tanks.
  - Open the ink tank cover. You will see four tanks: Black (K), Cyan (C), Magenta (M), and Yellow (Y).
  - Open the Black ink bottle and align it with the Black tank nozzle.
  - Insert it gently. The ink flows automatically—no need to squeeze.
  - Once full, remove the bottle and close the cap. Repeat for the other colors.
  - Close the ink tank cover when all four tanks are filled.
- 

### Step 3 – Ink Charging Process

- After filling, the printer will ask to begin the ink charging process.
- Confirm on the screen. This will take about 10–15 minutes.
- Do not turn off or unplug the printer during this step.

---

## Wi-Fi and PC Setup

### Step 1 – Connect to Wi-Fi

- On the touchscreen, tap the Settings icon (gear symbol).
- Navigate to Network Settings > Wi-Fi Setup > Wi-Fi Setup Wizard.
- Select your Wi-Fi network and enter the password.
- Wait for the confirmation message indicating a successful connection.

---

### Step 2 – Add the Printer to Windows 11

- Ensure the computer is on the same Wi-Fi network as the printer.
- Press Windows + I → Go to Bluetooth & Devices > Printers & Scanners.
- Click Add device → Select Epson ET-4850 from the list.
- Wait for setup to complete.

---

## Firmware Update via Control Panel

- On the touchscreen, tap Settings → Scroll down to Firmware Update.
- The printer will check for available updates.
- If an update is available, tap Update, and follow the instructions.
- Wait until the process finishes. The printer may restart.

---

## Troubleshooting – Printing Issues

### Problem: Printer Detected but Not Printing

#### Solution 1 – Restart the Print Spooler

- Press Windows + R, type services.msc, and press Enter.
- Find Print Spooler, right-click, and choose Stop.
- Go to: C:\Windows\System32\spool\PRINTERS  
Delete all files in that folder.
- Go back to Print Spooler, right-click → Start.
- Try printing again.

#### Solution 2 – Adobe Acrobat “Print as Image”

- Open the PDF in Adobe Acrobat Reader.
- Press Ctrl + P → Choose Epson ET-4850 as printer.

- Click Advanced → Enable Print as Image.
  - Click OK and print.
- 

## Manual Scanner Activation (PC Use)

### Step 1 – Enable Scan from Printer

- On the touchscreen, tap Scan → Computer.
  - Tap Search Again to detect nearby PCs.
  - Select your computer once it appears.
- 

### Step 2 – Register with Epson Connect

- A registration sheet will be printed automatically.
  - Visit: <https://www.epsonconnect.com/activation>
  - Enter the code from the sheet and complete registration with your email.
- 

### Step 3 – Download Remote Print Driver

- Go to: <http://support.epson.net/rpdriver>
  - Enter the Epson Connect email address.
  - Follow the instructions to install the driver.
- 

### Step 4 – Open Scan Tool in Windows

- Press the Windows key and type “Windows Scan”.
  - Open the app and select EPSON ET-4850 as scanner.
  - For advanced scans, use Epson ScanSmart or third-party apps.
- 

### Step 5 – Scan Your Document

- Place the document on the glass or ADF.
- Select file type, resolution, and color settings.
- Click Preview, then Scan.

The file will be saved in your chosen folder.

---

## Epson Smart Panel App (Mobile Printing & Scanning)

### Step 1 – Install the App

- iOS: [App Store](#)
- Android: [Google Play](#)

### Step 2 – Connect to the Printer

- Open the app and follow the on-screen steps to connect via Wi-Fi.

### Step 3 – Choose Layout Style

- Select between Cards View or Tiles View for app layout (functionality is the same).
-

## References

Epson ET-4850 Official Support:

[https://epson.com/Support/Printers/All-In-Ones/ET-Series/Epson-ET-4850/s/SPT\\_C11CJ60202](https://epson.com/Support/Printers/All-In-Ones/ET-Series/Epson-ET-4850/s/SPT_C11CJ60202)

Firmware Update via Software:

<https://epson.com/Support/wa00870>

Epson Software Updater (Drivers + Firmware):

<https://epson.com/Support/wa00551>

Epson Connect Registration:

<https://www.epsonconnect.com/activation>

Remote Print Driver:

<http://support.epson.net/rpdriver>

Smart Panel App Overview:

<https://www.epson.com/smartpanel>

Common Printing Issues (FAQ):

[https://epson.com/faq/SPT\\_C11CJ60202](https://epson.com/faq/SPT_C11CJ60202)

User Manual (PDF – CPD-60031):

<https://files.support.epson.com/docid/cpd6/cpd60031.pdf>