IC1 NICERF_SX1280 DIO2 DIO2 DIO1 DIO1 DIO3 BUSY BUSY DIO3 VCC Not Fitted GND VCC VCC GND4 GND GND RESET RESET MISO MISO GND3 GND 100nF MOSI MOSI GND GND2 SCK GND GND SCK GND1 NSS NSS ANT ANT

