IC1 NICERF_SX1280 DIO2 DIO2 DIO1 DIO1 BUSY DIO3 **BUSY** DIO3 VCC Not Fitted GND VCC VCC GND4 RESET GND **GND** RESET MISO MISO GND GND3 100nF MOSI GND MOSI GND2 GND SCK SCK GND1 GND NSS NSS **ANT** ANT

