





File: USB_Input.sch














File: Indicators.sch

Schematic originally designed by Analog Life, LLC


Beagleboard.org


Sheet: /
File: BeagleConnect.sch


Title: BeagleConnect Leash


Size: C Date: 2020-08-31 Rev: A


KiCad E.D.A. kicad (5.1.6)-1 Id: 1/10
















Verify all connections with Erik Larson



When USER_BOOT button is pressed during USB power up, it pulls MSP_PUR high. This puts the MSP430 into programming mode.

The USER_BOOT button is also used as an input to the CC1352R $\,$ for it's programming, but is active low



Schematic originally designed by Analog Life, LLC

Beagleboard.org

Sheet: /USB Input/ File: USB_Input.sch

Title: BeagleConnect Leash

	Size: B	Date: 2020-08-31	Rev: A
ı	KiCad E.D.A.	kicad (5.1.6)-1	ld: 5/10

