

User Manual: Cookware

Prepared by: TASHA - The Home Brand

Copyright 2019

Some commonly asked questions:

Is TASHA cookware suitable for induction?

All our stainless steel ranges are suitable for induction. Also, several of our aluminium cookware ranges are induction suitable. Always check your product packaging to verify suitability for induction. More info is available on our product page. The best way to test if your current cookware is induction compatible is to hold a magnet to the base. If it clings to it, it is induction ready!

Some commonly asked questions:

Do I need to season my TASHA cookware?

Seasoning is not necessary. All you need to do is clean your pan before storing and use a little butter or oil when frying.

Some commonly asked questions:

or butter for my non-stick pan?

Do I need to use oil Yes, we recommend using a little oil or butter. Frying is the cooking of cooking or frying in food in oil or another fat. When frying food in a frying pan, you need a minimum amount of fat, which acts as a transfer of the heat between the pan and the food. If you want to prepare food without the use of fat, please consider other preparation techniques such as grilling, steaming, boiling,

Some commonly asked questions:

Can I use oil sprays?

DO NOT use oil sprays. These contain a mixture of additives which cause the oil to burn at very low temperatures. Small spray droplets heat up very rapidly and are more easily carbonized on the non-stick surface. This will affect the non-stick performance of the pan.

Cleaning Guide

Here is how to get the best of your cookware

- Always allow to cool fully before cleaning.
- Remove the lid and cooking accessories.
- Wash lid and accessories in warm, soapy water and dry thoroughly.
- Always empty any oil from the non-stick pan before cleaning.
- Fill the non-stick pan with warm water and mild detergent.
- Do not use abrasive cleaning pads or agents.
- Do not immerse the base in water or any other liquid.
- Wipe the base clean with a soft, damp cloth.

Disposal Guide

Dispose of all paper, cartons and plastic in accordance with your local recycling

regulations. At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.