

BARCODE → RS232 KONFIG - Seite 1 (Start/Ende/Speichern)



CONFIG_START: ###CONFIG###



END_LF: CFG:END=LF



END_NONE: CFG:END=NONE



END_STXETX: CFG:END=STXETX



END_CR: CFG:END=CR



END_CRLF: CFG:END=CRLF



END_ETX: CFG:END=ETX



SAVE: CFG:SAVE