

System

Component
(Sub Class)

CoSimComponent
(Base Class)

Initialization

initialize(t0)

Set initial time $t = t_0$

`_initialize_ports_from_specs()`

`_initialize_event_ports()`

abstract
Load model, apply parameters,
configure solver, set initial state

`_initialize_component(t0)`

`_detect_direct_feedthrough()`

abstract
Write internal state
to output ports

`_update_output_states(t0)`

`_record_outputs(t0)`

