

Enable RX Signal

Charge Current

Enable VBATT Signal

With jumper 450mA without jumper 100mA

Enable RTS Signal -

Enable CTS Signal -

Enable LED Signal -

