





SCK CEN Ref.: NA.CN\_EDP501 Third Party Ref.: 092-423-LE-I-60200

# Signal Database

Contract name: Design Engineering Contract

Project phase: Basic Design Phase (IIB)

SBS level: MYRRHA - MINERVA ACC - Nuclear Facilities - Process System Equipment & Piping

1	2022-06-09		G. Donoso (GDO)	A.M Hernandez (AHA)	S. Reyes (SRU)	
REV.	YY/MM/DD	ISSUED FOR	AUTHOR(S)	REVIEWER(S)	APPROVER	VALIDATED BY SCK CEN

#### ${\bf CLASSIFICATION}$

	Contains information for the design of structures, systems or components: Yes \( \square \) No \( \square \)							
De	Design verification : Not applicable $\square$ Head of OU/Supervisor $\boxtimes$ Verifier Level 1 $\square$ Level 2 $\square$							
CONTRO	L OF MODIFICATIONS							
Issue	Modifications							
0	First issue							

#### PRELIMINARY OR PENDING INFORMATION

Issue	Paragraphs	Subject	Status
0	6.1	MINERVA facility coordinates	Pending

#### DISTRIBUTION

External	Internal	No. copies/Format
SCK∙CEN	ADT, SRU, PBR, CRR, LCD, GDO, MUI, CPZ, AGD	$1/\mathrm{PDF} \\ 1/\mathrm{PDF}$





Consortium Tractebel Engie – Empresarios Agrupados Boulevard Simon Bolivar 34, 1000 Brussels, Belgium c/Magallanes, 3-28015 Madrid - Spain

www.tractebel-engie.be www.empresariosagrupados.es

© SCK CEN, 2020

Stichting van Openbaar Nut - Fondation d'Utilité Publique - Foundation of Public Utility

Registered Office:

Avenue Herrmann Debroux 40 - 1160 Brussel – Belgium

 ${\it Research~Centres:}$ 

Boeretang 200 - 2400 Mol - Belgium

Chemin du Cyclotron 6 - 1348 Ottignies-Louvain-la-Neuve - Belgium

www.sckcen.be

#### Copyright Rules

All property rights and copyright are reserved to SCK CEN. This document contains data, information, pictures and formats for dedicated use only and may not be communicated, copied, reproduced, distributed or cited without the explicit written permission of SCK CEN. Any infringement to this rule is illegal and entitles to claim damages from the infringer, without prejudice to any other right, e.g. in case of granting a patent or registration in the field of intellectual property.







## Table of Content

Table	of Content	4
1	Introduction	5
2	Objective and scope	6
3	Acronyms	7
4	Hardwared I/O data base fields description	8
5	Datalinked I/O data base fields description	12
6	Input Data List	13
7	Body of the document	14
Annex	A – Hardwared Signal Database	15
Annex	B – Datalinked Signal Database	16
	nces.	





#### 1 Introduction

The MINERVA project is embedded in the overall MYRRHA programme. Following the phased MYRRHA implementation strategy, the first facility that will be constructed at SCK•CEN, Mol (Belgium) will be the first part of the 600 MeV MYRRHA LINAC that will deliver intense proton beams up to 100 MeV. The 100 MeV accelerator together with the proton target facility is named MINERVA (MYRRHA Isotopes production coupling the linear accelerator to the Versatile proton target Facility).

Tractebel together with its Consortium Partner Empresarios Agrupados will act as Design Engineer of all the Structures, Systems and Components (SSC) necessary to operate the MINERVA Accelerator, and covered under the term <a href="Accelerator">Accelerator</a> Nuclear Facilities (ACC NF), except for the accelerator systems themselves, which are excluded from the Design. The Design Engineer mission covers the Design, Assistance with procurement and support during Construction.

The framework and more details about this project can be found in the "Project Execution Plan" Ref. [2].





## 2 Objective and scope

The purpose of this document is to define the design criteria to be applied to the Balance of Plant (BOP) Process Systems and Equipment of MINERVA ACC, as well as to describe the general characteristics of the involved process systems and equipment.





## 3 Acronyms

The complete list of acronyms used in the MINERVA project is included in the SCK CEN document "Abbreviations, Glossary and symbols" [Ref.4].





### 4 Hardwared I/O data base fields description

The following table defines for every record associated to a hardware I/O to the DCS the meaning of its fields, assigning a field name, field data type, field size and a field description of each defined parameter. The data base structure following covers digital and analog signals.

Index	Column Name	Data Type	Field Size	Description	Responsibility (Note 1)
1	OWNER	Text	10	Responsible party for IO point. Examples are: EA-E, EA-I&C, SIEMENS, WOOD, etc.	PE
2	SIGNAL ID	Text	17	Signal ID (Key field)	PE
3	FLD_DEV	Text	12	Device tag name (1st and 2nd KKS level identification)	PE
4	3_KKS	Text	5	3rd KKS level	PE
5	DESC (Note 2)	Text	40	Device description	PE
6	ACTIVE (Note 2)	Text	10	For booleans, logic "1" description	PE
7	INACTIVE (Note 2)	Text	10	For booleans, logic "0" description	PE
	FAILSAFE POSITION				
8	EST	Text	1	For booleans, enter "1" for give an alarm in the DCS for the ACTIVE status or "0" for the INACTIVE status. If left blank no alarm is required in the DCS	PE
9	PRI	Text	1	Priority level alarm in DCS	PE
10	SIG_TYPE	Text	2	Select from the following types: DI: Digital input DO: Digital output AI: Analog input AO: Analog output	PE
11	SIG_LEVEL	Text	10	Input voltage level for SIG_TYPE: 4-20 mA, 24 VDC, NAMUR, TCE (Thermocouple type E), TCK (Thermocouple type K), RTD, etc.	PE
12	PWR_SRC	Text	1	Signal power source: F: for field wetted signals S: (system) for DCS powered signals	PE
13	LINE MONITORING	Yes/No	-	If empty no line monitoring required	PE
14	LOCATION	Text	25	Physical location where the DCS Cabinet and associated termination board is located. A	PE





Index	Column Name	Data Type	Field	Description	Responsibility
mdex	Column Name	Data Type	Size	Description	(Note 1)
				location may have multiple cabinets from different controllers	
15	DEV_PARTITION	Text	1	This field is used to determine which termination boards to assign an I/O point during panel layout. For example, if 3 analog inputs have an A, B and C partition, three separate I/O cards will be assigned during engineering to these points, one for each inputs. This column also applies to redundant pumps, valves, etc.	PE
16	DEVICE_LO	Number	-	For analog, 0% of the device calibration range (4 mA)	PE
17	DEVICE_HI	Number	-	For analog, 100% of the device calibration range (20 mA)	PE
18	DEVICE_UNITS	Text	8	For analog, engineering units of the device calibration range	PE
19	DISPLAY_LO	Number	-	For analog, 0% of display value	PE
20	DISPLAY_HI	Number	-	For analog, 100% of display value	PE
21	DISPLAY_UNITS	Text	8	For analog, engineering units of display value	PE
22	PRECISION	Number	-	Analog scaling precision - defines the number of decimal places. If blank will be calculated based on display low and high values.	PE
23	SOE	Yes/No	-	Use checkbox, if point is used for sequence of events.	PE
24	HIST	Yes/No	-	Use checkbox, if point signal is to be stored in the Historian.	PE
25	PID	Text	30	P&ID KKS where device/equipment is depicted	PE
26	LOGIC	Text	30	Control logic diagram KKS where device is depicted	PE
27	SCHEM	Text	30	Wiring diagram KKS where device is depicted	PE
28	HMI_SCREEN	Text	10	HMI Screen ID where the device is depicted	PE
29	IS	Yes/No	-	Indicate if Intrinsically safety barrier is required for this signal	PE





30				Description	
30			Size		(Note 1)
	IS_MODEL	Texto	16	Intrinsically safety barrier Model $n^{Q}$	$^{\mathrm{CS}}$
31	IS_IN_TB_1	Text	10	Intrinsically safety barrier input terminal block (+)	CS
32	IS_IN_TB_2	Text	10	Intrinsically safety barrier input terminal block (-)	CS
33	IS_OUT_TB_1	Text	10	Intrinsically safety barrier output terminal block (+)	CS
34	IS_OUT_TB_1	Text	10	Intrinsically safety barrier output terminal block (-)	CS
	SAFETY CLASS				
	RELAY NEEDED				
	TYPE OF RELAY  O GROUP				
	CUBICLE (ORIGIN)	Text			
	TERMINAL STRIP	Text			
	(ORIGIN)				
	TERMINAL (ORIGIN)	Text			
	CABLE				
	CABLE REF				
	WIRE				
	DEVICE (DESTINATION)				
	CUBICLE (DESTINATION)				
	TERMINAL STRIP (DESTINATION)				
	TERMINAL (DESTINATION)				
	MULTICABLE TYPE				
	MULTICABLE WIRE				
35	CONTROLLER	Text	8	DCS controller ID where signal will be processed	CS
36	CARD_CABINET_ID	Text	20	DCS cabinet ID where the card associated to the signals is located	CS
37	CARD_ID	Text	16	DCS card ID within the cabinet	CS
38	CARD_TYPE	Text	15	Card model	CS
39	CARD_POINT_No	Number	-	I/O card point where signal will be assigned	CS





Index	Column Name	Data Type	Field Size	Description	Responsibility (Note 1)
40	TA_MODEL	Text	16	Terminal Assembly Model	CS
41	TA_TAG_ID	Text	16	Terminal Assembly tag identification	CS
42	MC_ID	Text	16	Marshalling cabinet ID where the signal from field is hardwired	CS
43	MC_TERM_STRIP_ID	Text	16	Marshalling terminal strip ID where the signal from field is hardwired	CS
44	MC_TB_N	Text	10	Marshalling terminal block  1st (+) & 2nd (-)	CS
<mark>45</mark>	MC_TB_2	$\frac{\mathrm{Text}}{\mathrm{Text}}$	10	Marshalling terminal block 2nd (-)	CS
46	MC_TB_3	Text	<del>10</del>	Marshalling terminal block 3rd	CS
47	MC_TB_4	Text	<del>10</del>	Marshalling terminal block 4th	CS
48	REMARKS	Text	255	Field for general remarks	PE
49	MOD	Text	2	Modification code indicating a change occurred:  A: Added  M: Modified  D: Deleted	PE
50	REV	Text	2	Revision - indicates the revision for the change. If the modification code has been changed this field should be also updated	PE
51	REV_COMMENT	Text	255	Revision comment. Explains the changes in the signal	PE
52	REV_DATE	Date/Tim e	-	Date when signal was entered or revised	PE

Note 1: CS (Control System Supplier), PE (Process Engineer).

Note 2: For Booleans the description of the signal is obtained by concatenating the fields "DESC" and "ACTIVE". For analog signals, the signal description will be the field "DESC".





### Datalinked I/O data base fields description

The following table defines for every record associated to a datalink I/O to the DCS the meaning of its fields, assigning a field name, field data type, field size and a field description of each defined parameter. The data base structure following covers digital and analog signals.

1	Index	Column Name	Data Type	Field Size	Description
PLC_NAME	1	OWNER	Text	10	Responsible party for IO point. Examples are: EA-E,
3					EA-I&C, SIEMENS, WOOD, etc.
Node_TCS	2	PLC_NAME	Text	50	PLC Description
Text   So	3	NODO	Text	2	PLC Id. (01, 02,)
6 N° LINKS 7 PROTOCOL 7 Ext 50 Ethernet, RS-485, RS-232, RS-422, OPC, Modbus 7 CP/IP 8 POINTNAME 9 SIG TYPE 1 Text 3 Select from the following types: DID, DOD, AID, AOD 10 FLD_DEV 1 Text 15 Device Tag Name (1st and 2nd KKS level identification) 11 3_KKS 1 Text 5 3rd KKS Levels 12 DESC 1 Text 60 Signal Description, second language (English). Limited to 60 Characters 13 ADDRESS 1 Text 25 Modbus address to be read. The address should be 5 characters in length. The first number should be the areas of memory in the Modbus device ("3" for input register or "4" for holding register). 14 BIT NUMBER Number 15 PARITY 1 Text 10 Select from the following (Odd, Even, None) 16 CONVERTER_REQ 17 Text 10 This documents the scope of who is supplying the converter. 17 CONVERTER_TYPE 18 CONVERTER_TYPE 19 CONVERTER_MOD 18 CONVERTER_MOD 19 CONVERTER_MOD 20 DISPLAY_LO Number 21 DISPLAY_UNITS 25 Engineering units of display value 26 DISPLAY_UNITS 27 Text 28 Echernet, Redundant 29 Engineering units of display value 20 DISPLAY_UNITS 20 Engineering units of display value 21 DISPLAY_UNITS 21 Text 25 Engineering units of display value 26 DISPLAY_UNITS 27 Text 28 ACTIVE 29 Text 20 Logic "0" description	4	Node_TCS	Text	10	Internal Id node number in a PLC's network
Text   Final Protect   Text   Text	5	IP_ADDRESS	Text	50	Ip Address
TCP/IP	6	Nº LINKs	Text	50	Simple, Redundant
8 POINTNAME Text 20 Signal Id 9 SIG TYPE Text 3 Select from the following types: DID, DOD, AID, AOD 10 FLD_DEV Text 15 Device Tag Name (1st and 2nd KKS level identification) 11 3_KKS Text 5 3rd KKS Levels 12 DESC Text 60 Signal Description, second language (English). Limited to 60 Characters 13 ADDRESS Text 25 Modbus address to be read. The address should be 5 characters in length. The first number should be the areas of memory in the Modbus device ("3" for input register or "4" for holding register). 14 BIT NUMBER Number Simple For Booleans, indicate the bit in the word, valid entries are 0-15 15 PARITY Text 10 Select from the following (Odd, Even, None) 16 CONVERTER_REQ Text 10 This documents the scope of who is supplying the converter. 17 CONVERTER_OTY Text 5 Number of converters required (PLC and DCS side) 18 CONVERTER_TYPE Text 10 Fiber, RS-485, etc 19 CONVERTER_MOD Text 20 Converter Model if required (PLC and DCS side) 20 DISPLAY_LO Number Simple 0% of display value 21 DISPLAY_HI Number Simple 100% of display value 22 DISPLAY_UNITS Text 5 Engineering units of display value 23 PRECISION Number Simple Analog scaling precision - Enter the number of decimal places to display. If blank will be calculated based on display low and high values. 24 ACTIVE Text 10 Logic "0" description	7	PROTOCOL	Text	50	Ethernet, RS-485, RS-232, RS-422, OPC, Modbus
9 SIG TYPE Text 3 Select from the following types: DID, DOD, AID, AOD  10 FLD_DEV Text 15 Device Tag Name (1st and 2nd KKS level identification)  11 3_KKS Text 5 3rd KKS Levels  12 DESC Text 60 Signal Description, second language (English). Limited to 60 Characters  13 ADDRESS Text 25 Modbus address to be read. The address should be 5 characters in length. The first number should be the areas of memory in the Modbus device ("3" for input register or "4" for holding register).  14 BIT NUMBER Number Simple For Booleans, indicate the bit in the word, valid entries are 0-15  15 PARITY Text 10 Select from the following (Odd, Even, None)  16 CONVERTER_REQ Text 10 This documents the scope of who is supplying the converter.  17 CONVERTER_OTY Text 5 Number of converters required (PLC and DCS side)  18 CONVERTER_TYPE Text 10 Fiber, RS-485, etc  19 CONVERTER_MOD Text 20 Converter Model if required (PLC and DCS side)  20 DISPLAY_LO Number Simple 0% of display value  21 DISPLAY_HI Number Simple 100% of display value  22 DISPLAY_UNITS Text 5 Engineering units of display value  23 PRECISION Number Simple Analog scaling precision - Enter the number of decimal places to display. If blank will be calculated based on display low and high values.  24 ACTIVE Text 10 Logic "0" description					TCP/IP
AOD    10   FLD_DEV   Text   15   Device Tag Name (1st and 2nd KKS level identification)     11   3_KKS   Text   5   3rd KKS Levels     12   DESC   Text   60   Signal Description, second language (English). Limited to 60 Characters     13   ADDRESS   Text   25   Modbus address to be read. The address should be 5 characters in length. The first number should be the areas of memory in the Modbus device ("3" for input register or "4" for holding register).    14   BIT NUMBER   Number   Simple   For Booleans, indicate the bit in the word, valid entries are 0-15     15   PARITY   Text   10   Select from the following (Odd, Even, None)     16   CONVERTER_REQ   Text   10   This documents the scope of who is supplying the converter.     17   CONVERTER_QTY   Text   5   Number of converters required (PLC and DCS side)     18   CONVERTER_TYPE   Text   10   Fiber, RS-485, etc     19   CONVERTER_MOD   Text   20   Converter Model if required (PLC and DCS side)     20   DISPLAY_LO   Number   Simple   0% of display value     21   DISPLAY_HI   Number   Simple   00% of display value     22   DISPLAY_UNITS   Text   5   Engineering units of display value     23   PRECISION   Number   Simple   Analog scaling precision - Enter the number of decimal places to display.   If blank will be calculated based on display low and high values.     24   ACTIVE   Text   10   Logic "0" description	8	POINTNAME	Text	20	Signal Id
Text 15 Device Tag Name (1st and 2nd KKS level identification)  11 3_KKS Text 5 3rd KKS Levels  12 DESC Text 60 Signal Description, second language (English). Limited to 60 Characters  13 ADDRESS Text 25 Modbus address to be read. The address should be 5 characters in length.  The first number should be the areas of memory in the Modbus device ("3" for input register or "4" for holding register).  14 BIT NUMBER Number Simple For Booleans, indicate the bit in the word, valid entries are 0-15  15 PARITY Text 10 Select from the following (Odd, Even, None)  16 CONVERTER_REQ Text 10 This documents the scope of who is supplying the converter.  17 CONVERTER_QTY Text 5 Number of converters required (PLC and DCS side)  18 CONVERTER_TYPE Text 10 Fiber, RS-485, etc  19 CONVERTER_MOD Text 20 Converter Model if required (PLC and DCS side)  20 DISPLAY_LO Number Simple 0% of display value  21 DISPLAY_HI Number Simple 100% of display value  22 DISPLAY_UNITS Text 5 Engineering units of display value  23 PRECISION Number Simple Analog scaling precision - Enter the number of decimal places to display.  If blank will be calculated based on display low and high values.  24 ACTIVE Text 10 Logic "0" description	9	SIG TYPE	Text	3	Select from the following types: DID, DOD, AID,
identification   identification					AOD
11 3_KKS Text 5 3rd KKS Levels  12 DESC Text 60 Signal Description, second language (English). Limited to 60 Characters  13 ADDRESS Text 25 Modbus address to be read. The address should be 5 characters in length.  The first number should be the areas of memory in the Modbus device ("3" for input register or "4" for holding register).  14 BIT NUMBER Number Simple For Booleans, indicate the bit in the word, valid entries are 0-15  15 PARITY Text 10 Select from the following (Odd, Even, None)  16 CONVERTER_REQ Text 10 This documents the scope of who is supplying the converter.  17 CONVERTER_QTY Text 5 Number of converters required (PLC and DCS side)  18 CONVERTER_TYPE Text 10 Fiber, RS-485, etc  19 CONVERTER_MOD Text 20 Converter Model if required (PLC and DCS side)  20 DISPLAY_LO Number Simple 0% of display value  21 DISPLAY_HI Number Simple 100% of display value  22 DISPLAY_UNITS Text 5 Engineering units of display value  23 PRECISION Number Simple Analog scaling precision - Enter the number of decimal places to display. If blank will be calculated based on display low and high values.  24 ACTIVE Text 10 Logic "0" description	10	FLD_DEV	Text	15	Device Tag Name (1st and 2nd KKS level
DESC DESC Text  60 Signal Description, second language (English). Limited to 60 Characters  Modbus address to be read. The address should be 5 characters in length. The first number should be the areas of memory in the Modbus device ("3" for input register or "4" for holding register).  PARITY Text 10 Select from the following (Odd, Even, None)  CONVERTER_REQ Text 10 This documents the scope of who is supplying the converter.  CONVERTER_TYPE Text 10 Text 10 Fiber, RS-485, etc 19 CONVERTER_MOD Text 20 DISPLAY_LO Number DISPLAY_HI Number Simple DISPLAY_UNITS Text 5 Engineering units of display value  DISPLAY_UNITS Text 5 Engineering units of display value  PRECISION Number Simple Analog scaling precision - Enter the number of decimal places to display. If blank will be calculated based on display low and high values.  ACTIVE Text 10 Logic "0" description					identification)
Limited to 60 Characters  Limited to 60 Characters  ADDRESS  Text  25 Modbus address to be read. The address should be 5 characters in length. The first number should be the areas of memory in the Modbus device ("3" for input register or "4" for holding register).  PARITY  Text  10 Select from the following (Odd, Even, None)  CONVERTER_REQ  Text  10 This documents the scope of who is supplying the converter.  CONVERTER_QTY  Text  Number of converters required (PLC and DCS side)  Simple Of display value  DISPLAY_LO  Number  DISPLAY_HI  Number  Simple  DISPLAY_UNITS  Text  Simple  PRECISION  Number  Simple  Limited to 60 Characters  Modbus address to be read. The address should be 5 characters in length. The first number should be the areas of memory in the Modbus device ("3" for input register or "4" for holding register).  For Booleans, indicate the bit in the word, valid entries are 0-15  Select from the following (Odd, Even, None)  This documents the scope of who is supplying the converter.  Converter_Converters required (PLC and DCS side)  Fiber, RS-485, etc  Converter Model if required (PLC and DCS side)  Of of display value  1 DISPLAY_HI  Number  Simple  DISPLAY_UNITS  Text  Simple  DISPLAY_UNITS  Text  Analog scaling precision - Enter the number of decimal places to display.  If blank will be calculated based on display low and high values.  ACTIVE  Text  10 Logic "0" description	11	3_KKS	Text	5	3rd KKS Levels
ADDRESS  Text  25  Modbus address to be read. The address should be 5 characters in length. The first number should be the areas of memory in the Modbus device ("3" for input register or "4" for holding register).  BIT NUMBER  Number  Simple  For Booleans, indicate the bit in the word, valid entries are 0-15  PARITY  Text  10  Select from the following (Odd, Even, None)  CONVERTER_REQ  Text  10  This documents the scope of who is supplying the converter.  Text  Number of converters required (PLC and DCS side)  CONVERTER_TYPE  Text  10  Fiber, RS-485, etc  19  CONVERTER_MOD  Text  20  Converter Model if required (PLC and DCS side)  DISPLAY_LO  Number  Simple  O'' of display value  DISPLAY_HI  Number  Simple  DISPLAY_UNITS  Text  Simple  Analog scaling precision - Enter the number of decimal places to display. If blank will be calculated based on display low and high values.  ACTIVE  Text  10  Logic "0" description	12	DESC	Text	60	Signal Description, second language (English).
characters in length. The first number should be the areas of memory in the Modbus device ("3" for input register or "4" for holding register).  14 BIT NUMBER Number Simple For Booleans, indicate the bit in the word, valid entries are 0-15  15 PARITY Text 10 Select from the following (Odd, Even, None)  16 CONVERTER_REQ Text 10 This documents the scope of who is supplying the converter.  17 CONVERTER_QTY Text 5 Number of converters required (PLC and DCS side)  18 CONVERTER_TYPE Text 10 Fiber, RS-485, etc  19 CONVERTER_MOD Text 20 Converter Model if required (PLC and DCS side)  20 DISPLAY_LO Number Simple 0% of display value  21 DISPLAY_HI Number Simple 0% of display value  22 DISPLAY_UNITS Text 5 Engineering units of display value  23 PRECISION Number Simple Analog scaling precision - Enter the number of decimal places to display. If blank will be calculated based on display low and high values.  24 ACTIVE Text 10 Logic "0" description					Limited to 60 Characters
The first number should be the areas of memory in the Modbus device ("3" for input register or "4" for holding register).  14 BIT NUMBER Number Simple For Booleans, indicate the bit in the word, valid entries are 0-15  15 PARITY Text 10 Select from the following (Odd, Even, None)  16 CONVERTER_REQ Text 10 This documents the scope of who is supplying the converter.  17 CONVERTER_QTY Text 5 Number of converters required (PLC and DCS side)  18 CONVERTER_TYPE Text 10 Fiber, RS-485, etc  19 CONVERTER_MOD Text 20 Converter Model if required (PLC and DCS side)  20 DISPLAY_LO Number Simple 0% of display value  21 DISPLAY_HI Number Simple 100% of display value  22 DISPLAY_UNITS Text 5 Engineering units of display value  23 PRECISION Number Simple Analog scaling precision - Enter the number of decimal places to display. If blank will be calculated based on display low and high values.  24 ACTIVE Text 10 Logic "0" description	13	ADDRESS	Text	25	Modbus address to be read. The address should be 5
the Modbus device ("3" for input register or "4" for holding register).  14 BIT NUMBER Number Simple For Booleans, indicate the bit in the word, valid entries are 0-15  15 PARITY Text 10 Select from the following (Odd, Even, None)  16 CONVERTER_REQ Text 10 This documents the scope of who is supplying the converter.  17 CONVERTER_QTY Text 5 Number of converters required (PLC and DCS side)  18 CONVERTER_TYPE Text 10 Fiber, RS-485, etc  19 CONVERTER_MOD Text 20 Converter Model if required (PLC and DCS side)  20 DISPLAY_LO Number Simple 0% of display value  21 DISPLAY_HI Number Simple 100% of display value  22 DISPLAY_UNITS Text 5 Engineering units of display value  23 PRECISION Number Simple Analog scaling precision - Enter the number of decimal places to display. If blank will be calculated based on display low and high values.  24 ACTIVE Text 10 Logic "0" description					characters in length.
Converter Model if required (PLC and DCS side)					The first number should be the areas of memory in
14 BIT NUMBER Number Simple For Booleans, indicate the bit in the word, valid entries are 0-15  15 PARITY Text 10 Select from the following (Odd, Even, None)  16 CONVERTER_REQ Text 10 This documents the scope of who is supplying the converter.  17 CONVERTER_QTY Text 5 Number of converters required (PLC and DCS side)  18 CONVERTER_TYPE Text 10 Fiber, RS-485, etc  19 CONVERTER_MOD Text 20 Converter Model if required (PLC and DCS side)  20 DISPLAY_LO Number Simple 0% of display value  21 DISPLAY_HI Number Simple 100% of display value  22 DISPLAY_UNITS Text 5 Engineering units of display value  23 PRECISION Number Simple Analog scaling precision - Enter the number of decimal places to display.  If blank will be calculated based on display low and high values.  24 ACTIVE Text 10 Logic "0" description					the Modbus device
entries are 0-15  PARITY Text 10 Select from the following (Odd, Even, None)  CONVERTER_REQ Text 10 This documents the scope of who is supplying the converter.  CONVERTER_QTY Text 5 Number of converters required (PLC and DCS side)  CONVERTER_TYPE Text 10 Fiber, RS-485, etc  19 CONVERTER_MOD Text 20 Converter Model if required (PLC and DCS side)  DISPLAY_LO Number Simple 0% of display value  DISPLAY_HI Number Simple DISPLAY_UNITS Text 5 Engineering units of display value  PRECISION Number Simple Analog scaling precision - Enter the number of decimal places to display.  If blank will be calculated based on display low and high values.  ACTIVE Text 10 Logic "0" description					("3" for input register or "4" for holding register).
15 PARITY Text 10 Select from the following (Odd, Even, None)  16 CONVERTER_REQ Text 10 This documents the scope of who is supplying the converter.  17 CONVERTER_QTY Text 5 Number of converters required (PLC and DCS side)  18 CONVERTER_TYPE Text 10 Fiber, RS-485, etc  19 CONVERTER_MOD Text 20 Converter Model if required (PLC and DCS side)  20 DISPLAY_LO Number Simple 0% of display value  21 DISPLAY_HI Number Simple 100% of display value  22 DISPLAY_UNITS Text 5 Engineering units of display value  23 PRECISION Number Simple Analog scaling precision - Enter the number of decimal places to display.  If blank will be calculated based on display low and high values.  24 ACTIVE Text 10 Logic "0" description	14	BIT NUMBER	Number	Simple	For Booleans, indicate the bit in the word, valid
16 CONVERTER_REQ Text 10 This documents the scope of who is supplying the converter.  17 CONVERTER_QTY Text 5 Number of converters required (PLC and DCS side)  18 CONVERTER_TYPE Text 10 Fiber, RS-485, etc  19 CONVERTER_MOD Text 20 Converter Model if required (PLC and DCS side)  20 DISPLAY_LO Number Simple 0% of display value  21 DISPLAY_HI Number Simple 100% of display value  22 DISPLAY_UNITS Text 5 Engineering units of display value  23 PRECISION Number Simple Analog scaling precision - Enter the number of decimal places to display.  If blank will be calculated based on display low and high values.  24 ACTIVE Text 10 Logic "0" description					entries are 0-15
CONVERTER_QTY   Text   5	15	PARITY	Text	10	Select from the following (Odd, Even, None)
17 CONVERTER_QTY Text 5 Number of converters required (PLC and DCS side)  18 CONVERTER_TYPE Text 10 Fiber, RS-485, etc  19 CONVERTER_MOD Text 20 Converter Model if required (PLC and DCS side)  20 DISPLAY_LO Number Simple 0% of display value  21 DISPLAY_HI Number Simple 100% of display value  22 DISPLAY_UNITS Text 5 Engineering units of display value  23 PRECISION Number Simple Analog scaling precision - Enter the number of decimal places to display.  If blank will be calculated based on display low and high values.  24 ACTIVE Text 10 Logic "0" description	16	CONVERTER_REQ	Text	10	This documents the scope of who is supplying the
18 CONVERTER_TYPE Text 10 Fiber, RS-485, etc  19 CONVERTER_MOD Text 20 Converter Model if required (PLC and DCS side)  20 DISPLAY_LO Number Simple 0% of display value  21 DISPLAY_HI Number Simple 100% of display value  22 DISPLAY_UNITS Text 5 Engineering units of display value  23 PRECISION Number Simple Analog scaling precision - Enter the number of decimal places to display.  If blank will be calculated based on display low and high values.  24 ACTIVE Text 10 Logic "0" description					converter.
19 CONVERTER_MOD Text 20 Converter Model if required (PLC and DCS side) 20 DISPLAY_LO Number Simple 0% of display value 21 DISPLAY_HI Number Simple 100% of display value 22 DISPLAY_UNITS Text 5 Engineering units of display value 23 PRECISION Number Simple Analog scaling precision - Enter the number of decimal places to display.  If blank will be calculated based on display low and high values.  24 ACTIVE Text 10 Logic "0" description	17	CONVERTER_QTY	Text	5	Number of converters required (PLC and DCS side)
20 DISPLAY_LO Number Simple 0% of display value 21 DISPLAY_HI Number Simple 100% of display value 22 DISPLAY_UNITS Text 5 Engineering units of display value 23 PRECISION Number Simple Analog scaling precision - Enter the number of decimal places to display.  If blank will be calculated based on display low and high values.  24 ACTIVE Text 10 Logic "0" description	18	CONVERTER_TYPE	Text	10	Fiber, RS-485, etc
21 DISPLAY_HI Number Simple 100% of display value  22 DISPLAY_UNITS Text 5 Engineering units of display value  23 PRECISION Number Simple Analog scaling precision - Enter the number of decimal places to display.  If blank will be calculated based on display low and high values.  24 ACTIVE Text 10 Logic "0" description	19	CONVERTER_MOD	Text	20	Converter Model if required (PLC and DCS side)
22 DISPLAY_UNITS  Text  5 Engineering units of display value  23 PRECISION  Number  Simple  Analog scaling precision - Enter the number of decimal places to display.  If blank will be calculated based on display low and high values.  24 ACTIVE  Text  10 Logic "0" description	20	DISPLAY_LO	Number	Simple	0% of display value
PRECISION  Number  Simple  Analog scaling precision - Enter the number of decimal places to display.  If blank will be calculated based on display low and high values.  24 ACTIVE  Text  10 Logic "0" description	21	DISPLAY_HI	Number	Simple	100% of display value
decimal places to display.  If blank will be calculated based on display low and high values.  24 ACTIVE Text 10 Logic "0" description	22	DISPLAY_UNITS	Text	5	Engineering units of display value
If blank will be calculated based on display low and high values.  24 ACTIVE Text 10 Logic "0" description	23	PRECISION	Number	Simple	Analog scaling precision - Enter the number of
high values.  24 ACTIVE Text 10 Logic "0" description					decimal places to display.
24 ACTIVE Text 10 Logic "0" description					If blank will be calculated based on display low and
					high values.
25 INACTIVE Text 10 Logic "1" description	24	ACTIVE	Text	10	Logic "0" description
	25	INACTIVE	Text	10	Logic "1" description





### 6 Input Data List

The following list includes all the documents that contain the different input data and/or requirements for the elaboration of the present Process System, Equipment & Piping Design Criteria document. All the input data are referred throughout the document as (ID  $N^0$ ), including the number of document according the list. The status of the different requirement/criteria is defined as Valid (V) or Preliminary (P).

No.			Source Document	Requirement/Data	Status
INO.	No.	Issue	Title	- Requirement/Data	
1	SCK-CEN\29155978	01-03-	MINERVA ACC Facility Requirements – Top Level	Lifetime installation	V
		19	Requirements	Design requirements for facility future expansions	
				Number of workers in the facility	
2					V
3					V
4					V
5					V
6					V
7					V
8					V





### 7 Body of the document

Ejemplo de como referenciar/repetir si fuse necesario requisitos de los documentos de SCK: According to (ID1), [Ref.1]:

- [TLR 012] The MINERVA BOP SSC shall take into account the requirements for the 100 MeV standalone facility and shall disregard any future requirement of the 600 MeV accelerator and of the reactor. Nevertheless, when sufficient data on the 600 MeV and reactor cases are available, and if the increase of the cost of all BOP SSC together remains below 5%, an assessment of the advantages of direct construction for the 600 MeV and/or the reactor shall be carried out.
- [TLR 013] The installation of a second injector shall be foreseen in the MINERVA masterplan and building design; space reservations are to be provided for the second injector and its auxiliary systems, a building/room is to be constructed only when the second injector shall be installed.





## **Annex A – Hardwared Signal Database**





# **Annex B – Datalinked Signal Database**





### **References**

- [1] MINERVA/4AV/0693237/000/00 Project Execution Plan
- [2] MINERVA/4NT/0691961/000/00 Applicable Codes and Standards
- [3] SCK·CEN/8905079 Abbreviations, Glossary and Symbols
- [4] SCK-CEN\29756272 MINERVA Naming Convention



