
To enable the Pico to run UNTETHERED to the computer




```
from machine import Pin
led=Pin(0,Pin.OUT)
button = Pin(14,Pin.IN, Pin.PULL_DOWN)
buzzer=Pin(12,Pin.OUT)
while True:
    if button.value() == 1:
        led.on()
        buzzer.on()
else:
    led.off()
    buzzer.off()
```

After we have confirmed that the circuit and codes are working according to what we want, we can make the Pico run on its own using an external power source:

- 1. A wall socket with a USB charger
- 2. A power bank
- 3. Solar Panel





The next time you plug this Pico to your computer, main.py will also

Run automatically.

To stop the main.py from running, click the STOP icon, or type CTRL – C