

RESET BUTTON

BOOT / FOR USER

IO0_BTN_

C8


GND


100nF


PTS645SH50SMTR92LFS

BUTTON FOR CHANGING MOVE OR MICROPHONE MODE


BUTTON FOR CHANGING MODE OF LED









ESP32-WROOM-32U



SEVEN SEGMENT DISPLAY FOR INDICATION OF LED MODE



INPUT FOR MICROPHONE



INPUT FOR MOVE DETECTION

