VinaCAD Express Tools User Guide

I. Installation

- Close VinaCAD before installation. Reopen VinaCAD to start using Express Tools.

II. Video tutorials

VinaCAD – Express Tools

III. Features

1. Drawings, text, and blocks

Command	Function
FDT	Find and select matching Text and MText objects in a selected area or the entire drawing.
RENAMETEXT	Change multiple text values at once.
RENAMELAYER	Rename multiple layers at once.

Command	Function
BB	Create a block based on a selected block.
BBE	Erase component objects directly inside a block.
CPD	Move an elevation block to a new position and recalculate its value from the elevation difference.

Command	Function
IPT	Import objects from the template file into the current drawing for use.

2. Drawing lists and component table

Command	Function
XLDM	Set the attributes in title blocks for the drawing list.
VBDM	Compile the drawing list and draw its table in VinaCAD.
DSHBV	Automatically number the attributes of the configured drawing blocks.

Command	Function
XLSDM	Set the attributes in a drawing-list block to edit.
SDM	Edit an existing drawing-list table.

Command	Function
XLCK	Select text to include in the component schedule.
TKCK	Count the selected text entries and check for duplicates.

3. Dimensions and checks

Command	Function
XLDCD	Set the attributes for cumulative dimensions.
DCD	Apply cumulative dimensions to the selected dimension area.

Command	Function
KTD	Check for duplicate dimensions (continued).

4. Reinforcement and reference tables

Command	Function
XLTKCT	Set reinforcement splice and hook conditions.
QS	Edit the reinforcement table.
QF	Calculate the total quantity.
QD	Edit the structural-steel table.

Command	Function
TS	Automatically number and draw table for slab reinforcement.

Command	Function
TDD	Automatically number and schedule reinforcement at the end of a precast beam.

Command	Function
BTCNN	Show the standard table of minimum reinforcement anchorage and splice lengths.
DTT	Show the reinforcement-area reference table.
BT	Show the concrete-strength reference table.
NEO	Show the table of minimum reinforcement anchorage lengths in the selected area.
NOI	Show the table of minimum reinforcement anchorage lengths in the selected area.

5. Piles

Command	Function
TDC	Export pile coordinates.
VC	Automatically draw piles with existing coordinates.

Command	Function
XLDTC	Configure pile naming.
DTC	Automatically name selected piles by row or column.

6. Architecture and construction

Command	Function
WW	Create wall objects.
EW	Erase walls and automatically process related objects created by WW.
TW	Trim and repair walls at gaps or wall ends, including objects related to WW.
WWT	Change the thickness of walls created by WW.
WWO	Create or move wall boundaries by an offset distance.

Command	Function
FN	Create or adjust the thickness of the stucco layer along a wall boundary.

Command	Function
AD	Insert and position doors on a wall or floor plan.
AW	Insert and position windows on a wall or floor plan.

Command	Function
ZXW	Create an axis grid.

Command	Function
LTP	Create a staircase section from geometric parameters.
LG	Draw railing segments from entered parameters and extend existing segments.

7. Geometry and 2D details

Lệnh	Chức năng
CLG	Draw wings catching the wind.
HG	Draw the wind-guiding vanes.
VCD	Draw an airflow control damper.

LiL	Draw an L-shaped joint on the air duct.
OC1	Draw lace in the middle section.
OC2	Draw the lace at the end.

8. Bolts and nuts

Command	Function
BULON	Create and insert a bolt block using the entered radius.
BULON1	Place sample bolt block 1 using length and the chosen direction.
BULON2	Place sample bolt block 2 using length and the chosen direction.

Command	Function
DAIOC	Create and insert a nut block using length .
DAIOC1	Place sample nut block 1 using length and the chosen direction.
DAIOC2	Place sample nut block 2 using length and the chosen direction.

9. Straight ducts and transitions

Command	Function
B1	Draw a rectangular duct.
B2	Draw a reducing duct.
B3	Draw a branch-duct head.
B4	Draw a square-to-round duct transition.
BZ	Draw a Z-shaped duct.
BZ2	Draw a Z-shaped air duct using two elbows.

Command	Function
BB1	Draw a 3D rectangular duct.
BB2	Draw a 3D reducing duct.
BBZ	Draw a 3D branch-duct head.

10. Branch ducts and fittings

Command	Function
E1	Draw a duct elbow.
E2	Draw a reducing duct elbow.
E3	Draw a downward duct elbow.

Command	Function
EE1	Draw a 3D duct elbow.
EE2	Draw a 3D reducing duct elbow.
EE3	Draw a 3D downward duct elbow.

Command	Function
EEX	Draw a duct branch with one straight and one curved outlet.
EEY	Draw a duct branch with two curved outlets.
EEZ	Draw a duct branch with one straight and two curved outlets.

11. Flexible ducts and air outlets

Command	Function
S1	Draw an insulated flexible duct with one horizontal end and one downward end.
S2	Draw an insulated flexible duct with two horizontal ends.
S3	Draw an insulated flexible duct with two downward ends.

Command	Function
R1	Draw an uninsulated flexible duct with one horizontal end and one downward end.
R2	Draw an uninsulated flexible duct with two horizontal ends.
R3	Draw an uninsulated flexible duct with two downward ends.

Command	Function
DD	Draw a supply-air outlet symbol.
DDI	Draw a 3D supply-air outlet.
DIFF	Create and insert a supply-air outlet block.

Command	Function
GRILL	Create and insert a standard return-air grille block.
GRILLV	Create and insert an egg-crate return-air grille block.

12. Version information, user guide, and language settings

Command	Function
ABOUTEXPRESS	Show Express Tools version information and open the PDF user guide.

Command	Function
EXPRESSLANGUAGE	Change the Express Tools language.

Command	Function
EXPRESSFEEDBACK	Open the Google Form feedback link.